https://wiki.teltonika-gps.com/view/ADAS_Configuration

ADAS Configuration

 $\frac{\text{Main Page}}{\square} > \frac{\text{Video Solutions}}{\square} > \frac{\text{DSM}}{\square} > \text{ADAS Configuration}$

Contents

- <u>1 FMx640 Configuration</u>
- <u>2 ADAS configuration for FMx650</u>
 - 2.1 Connecting two cameras simultaneously for FMx650
- <u>3 FMx125/FMX225 Configuration</u>
- <u>4 Crash Detection Functionality using DOUT</u>

FMx640 Configuration

It is important to note that ADAS cameras with Serial Numbers (S/N) starting with "9C" are exclusively compatible with FMX6 devices. However, cameras with Serial Numbers beginning with "9B" are typically designed for use with FMX125/225 devices. In the event you receive a camera with a Serial Number starting with "9B," it is crucial to check for a red circle sticker on the camera. The presence of this red sticker indicates that the camera, despite its "9B" Serial Number, is actually compatible with FMX6 devices, functioning equivalently to cameras with a "9C" Serial Number. This is due to the serial numbers being pre-attached to the camera case by the manufacturer and remaining constant for warranty purposes. If your camera with a "9B" Serial Number has this red sticker, proceed to connect it to a computer, install the required drivers, and visit IP 10.0.0.1 in a browser. Here, you will find more details about the camera, which will confirm its compatibility with FMX6 devices, as the actual Serial Number displayed will start with "9C.

NOTE: You need to insert an SD card into the FMX640 device; otherwise, you will not receive any video or photo on the server.

×

devices	
which start	
with 9C -	
will	
provide a	
red sticker,	
as shown	
on the	
picture.	
ADAS	
devices	
which start	
with 9B -	
WILL NOT	
NOTE! provide a	
red circle	
sticker.	
The picture	
has been	
only made	
for	
explanation	
purposes,	
and does	
not show	
the real	
replication	
of the	
sticker for	
9B.	

Device Configuration

It is necessary to change Data Protocol to <u>Codec 8 Extended</u>



Configure the Domain and Port to send the data to the desired server.

Domain		
Port	d 🍣	
Protocol		
ТСР	UDP	
TLS Encryption		
None	TLS/DTLS	

In RS232/RS485 settings enable ADAS under RS232 mode in order for the configurator to open

additional settings for ADAS accessory.

Please also note, a new baudrate "460800" is now supported. Please set baudrate settings to either Auto or 460800. This baudrate will allow faster photo/video transfers however, it is required ADAS FW version of 0.5.95 or later, be updated via SD card, for this update please contact the sale manager or fil the VipHelp Desk.

×

Once ADAS under RS232 mode is enabled, new tabs will open with additional configurable settings to "ADAS" and "ADAS IO".

In these settings it is important to remember that when a feature is enabled under "ADAS" tab, in order for the FMX640 device to send data about this feature to the server, it has to be given a priority "Low, Medium, High" inside of "ADAS IO" tab.

Crash event video settings

×

These settings are responsible for video length before and after the event. User can set up to 20 seconds of video data to be saved before the crash and a maximum of 10 seconds after the crash. A minimum of 5 seconds is required between the both settings.

Please note, more seconds means longer sending periods and more data usage.

Image/video settings

×

Image/video resolution can be chosen between 640x480 and 1280x720.

Please note, 1280x720 resolution is almost twice as large as the 640x480. This means that videos would take much larger storage space and sending them to the server would take more time.

Forward vehicle start alarm FVSA

×

This setting enables front vehicle movement detection and sets up an alarm once the vehicle starts moving.

Sensitivity ranging from 1 to 5 where 1 is least sensitive and 5 is the most sensitive option. Warning sound can be set by the user to their liking.

Speed limit recognition SLR

×

This setting allows fleet management companies or users to set maximum speed limit for that one particular vehicle and if that speed is exceeded, the driver is notified.

Sensitivity setting would indicate how sensitive the ADAS camera would be to exceeding speed limit, 1 would be least sensible giving driver the most room for exceeding the speed limit whereas 5 would strictly stick to the speed limit.

Lane departure warning LDW

×

This feature allows ADAS camera to track driver's lane changing and will notify the driver if the vehicle is moving out of its lane. This feature is also effective if the driver falls asleep and the vehicle starts to swivel.

Activation speed is a setting from which this feature activates.

Sensitivity settings determines how sensitive the camera will be to swiveling on the road meaning 1, swiveling in lane should not activate this feature while 5 which is the highest sensitivity will activate the feature if the vehicle swivels more than it should.

Warning sound repeat can be turned on which will keep on making warning sound until vehicle returns to lane.

Forward collision warning FCW

×

This feature if enabled, notified the driver if the vehicle is getting too close to the obstacle in front.

Sync with brake allows the ADAS camera to deactivate warning sounds if it detects vehicle stopping meaning the driver is aware of obstacle in the front.

Vibration activation will notify the driver when the vehicle is hitting small object which are too small for camera to notice so instead, vehicle starts to vibrate during collision with small objects and therefore the feature will activate warning sounds. Sensitivity setting will determine whether weak vibration should be detected or not.

Repeat function will keep the warning sounds on until the event will deactivate

Safety distance alert SDA

×

This feature activates if the vehicle in front is too close and the distance should be increased.

Re-Alert setting gives warning if the same vehicle in the front gets too close every time.

SDA sensitivity

Level 1 Level 2 Level 3 (Default) Level 4 Level 5 0.6 sec 0.9 sec 1.2 sec 1.5 sec 2.0 sec

Pedestrian collision warning PCW

×

This feature if enabled, notified the driver if the vehicle is getting too close to the obstacle in front.

Vibration activation will notify the driver when the vehicle is hitting small object which are too small for camera to notice so instead, vehicle starts to vibrate during collision with small objects and therefore the feature will activate warning sounds. Sensitivity setting will determine whether weak vibration should be detected or not.

Forward proximity warning FPW

×

This feature once enabled, provides warning if there is an object in the front of the vehicle or within ADAS camera's proximity.

Sensitivity from 1 to 5 is responsible for distance the event triggers, 1 is the least sensitive option while 5 is the strongest sensitivity.

Event Indication

×

This feature allows ADAS system to work in sync with FMX640 safety driving features such as Ecodriving, Over Speeding and Geofence. These features usually work with buzzers, LEDs and etc. connected straight to FMX640 device as outputs however, FMX640 devices can be connected straight with ADAS system which has sound warnings and the need for external peripherals is not required anymore.

File upload settings

×

File upload settings feature is responsible for image and video sending to user's preferred server if they require these files to be sent to another server or even the same server but different port.

Periodic image-sending functionality is also available with configurable sending intervals.

Image and Video sending can also be triggered by different inputs such as DINs for photos and videos, and different FMX640 features such as Crash, Towing, Idling and etc for photos.

Video duration can also be configured before and after the trigger event.

Overlay

×

Image and video records can have specific overlays on it recorded in order to provide additional information to the viewer.

Available information to display can be chosen between "Date and time", "GPS information" and "Speed".

GPS information can have a configurable update period which can be specified by the user allowing the device to use more or less network resources.

If you choose to use the "Speed" overlay, you will have four different options to choose from: **GPS**, **CAN adapter, FMS or K-Line**. Once you select one of these options, it will be used as the source for your speed information. Speed overlay settings can be useful in case wiring schemes are not available for specific vehicles, that way it would allow more flexible speed source configuration.

The overlay information update period determines how often information will be updated.

Garbage collector

×

ADAS system can save files inside of itself or FMX640 device if an additional microSD card is connected. However, from time to time, a lot of files can be accumulated which in turn will fill up the free space overcrowding the card and new files will stop producing. To reduce the hassle of taking out the card and deleting the contents inside of it manually, garbage collector functionality is introduced. It automatically deletes all records older than the specified days thus freeing up the space in the microSD card allowing it efficiently operate for longer periods of time.

ADAS IO

New IO elements called "ADAS" will appear in the configurator. Under this tab, the user can select either low or high priority on different features which they would like to receive on their server. Selecting priority will also allow the users to receive specific ADAS functionalities and ignore the ones they do not need.

×

ADAS configuration for FMx650

(!) Required firmware version - 03.00.14.Rev.116. Firmware errata.

• Make sure **Data Protocol** is set to <u>Codec 8 Extended</u>



• In RS232 \ RS485 settings tab, make sure to enable Camera interface by "Enable", and select ADAS in the Mode drop-down menu, afterwards ADAS COM1 and Camera I/O should appear in the tab list.



• Make sure to change Camera I/O camera state Priorities to Low

Manual CAN IO	COM1 ADAS Right turn signal		None	Low	Hi
Manual CAN Requests	COM1 ADAS Brake signal		None	Low	Ні
Manual CAN Commands	COM1 ADAS RPM		None	Low	н
Tachograph Data			None	2011	
RS232 \ RS485	COM1 ADAS LDW left		None	Low	H
ADAS COM1	COM1 ADAS LDW right		None	Low	Hi
Camera I/O	COM1 ADAS Distance left	cm	None	Low	Н
CAN \ Tachograph	COM1 ADAS Distance right	cm	None	Low	н
ContiPressureCheck	COM1 ADAS Time till collision		None	Low	Hi

• In appeared *ADAS COM1* tab, make sure to **configure everything by your needs**, and do not forget to complete the "**Domain**" and "**Port**" settings in *File upload settings*

×

• **NOTE:** This is a base setup for the device to work properly. Other device configuration is made according to your needs.

The new feature for FMx650 ADAS configuration, which is available from **03.00.14.Rev.114**-**Rev.116 iCamera** allows you to connect two of your cameras at once. Method for connection and configuration stays the same, for this you are only required to choose **two** cameras in "**RS232** \ **RS485**" tab from the configurator.

In the new functionality, you are able to connect any combo of the cameras by your wish, as an example: you are able to connect *ADAS/DSM*, *ADAS/DualCam*, *DSM/Dualcam*, *DashCam/DualCam*, *DSM/DSM*, *DualCam/DualCam* and etc.

Manual CAN IO					
Manual CAN Requests	R	S232 Setting	s 🚺 ———		
Manual CAN Commands		COM1 settings			
Tachograph Data		Camera interface			
RS232 \ RS485		Disable Enable			
CAN \ Tachograph		Mode	Silent Mod	le	~
ContiPressureCheck		Baudrate	Default		~
Custom Scenarios					
Mobileye		COM2 setti	ngs		
Reefer IO		Camera inte	erface		_
Transcan 2 IO		Disab	le	Enable	
Transcan Advance IO		Mode	Silent Mod	le	~
Euroscan IO		Baudrate	Default		~
TK Touchprint IO					
Simbiotecha PLC IO					

FMx125/FMX225 Configuration

ADAS functionality is intended for use with devices, that have RS232. It was implemented in **FMB.Ver.03.27.01.Rev.242**. New RS232 mode was implemented for ADAS camera data reading and a new ADAS IO section was created.

In order for ADAS functionality to work "ADAS Camera" RS232 mode has to be selected (151 parameter ID, value 21).

RS232 Mode	
Mode	
Log Mode	NMEA
LLS	LCD
RFID HID	RFID MF7
Garmin FMI	TCP Ascii
TCP Binary	TCP Ascii Buffered
TCP Binary Buffered	Mercury C4
UL202 Fuel Sensor	MDAS9 Camera

Note:

1) Please use Codec08 extended protocol with ADAS functionality

×

2) RS232 baudrate should be configured 115200 bps

×

3) New IO elements called "ADAS" will appear in the configurator. Under this tab, the user can select either low or high priority on different features which they would like to receive on their server. Selecting priority will also allow the users to receive specific ADAS functionalities and ignore the ones they do not need.

×

Crash Detection Functionality using DOUT

The crash detection feature is a crucial capability provided by our device. It enhances evidential documentation through video or photo evidence in the event of a crash. However, activating this functionality necessitates a direct connection of the camera to a power source. Nonetheless, such a direct connection can lead to **battery drainage**.

To circumvent this issue, we recommend utilizing DOUT and a relay for connection. This setup enables control via SMS or GPRS command, or through predefined scenarios within our device. By activating DOUT post-ignition, the camera receives power, allowing it to function and record evidence even after the ignition is turned off following a crash. **For your convenience, the connection scheme can be found here:** <u>ADAS First Start</u>

It is important to note that in the event of a fatal crash where fatalities may occur, we cannot guarantee the retrieval of video or photo evidence due to the severity of the accident. Moreover, both the camera and the device itself may sustain irreparable damage in such instances