

FMC001 GSM Operators settings

[Main Page](#) > [OBd Trackers](#) > [FMC001](#) > [FMC001 Configuration](#) > **FMC001 GSM Operators settings**

GSM settings

Operator lists

FMC001 can work in different modes (use different settings) according to the operator list defined. Operator list is used for Data Acquisition mode switching (see [Data acquisition settings](#) section for more details). Modes are changed based on the GSM operator FMC001 is connected to.

The screenshot displays the 'GSM Settings' configuration page. On the left is a sidebar menu with options like Security, System, GPRS, Data Acquisition, SMS \ Call Settings, GSM Operators (highlighted), Features, Accelerometer Features, Auto Geofence, Manual Geofence, Trip \ Odometer, Bluetooth, Bluetooth 4.0, Beacon List, 1-Wire, I/O, OBD II, CAN Adapter, and RS232 \ RS485. The main area shows two lists: 'Roaming Operator List' and 'Operator Black List'. Each list has 20 rows, numbered 1 to 20, with a dropdown menu next to each number. Below each list are 'Import CSV' and 'Export CSV' buttons. The interface is dark-themed with blue accents.

Configuring device roaming and blacklist operators is recommended to optimize device performance by mitigating additional latency.

If the roaming operator list is left empty, FMC001 will automatically detect the home operator. If the home operator is written to the roaming operator list, it will still be detected as a home operator. Any operator not in the roaming operator list (except the home operator) will be recognized as an unknown operator and FMC001 will work in Unknown mode (make sure it is configured to allow data sending - GPRS context is enabled).

If the user wants FMC001 to not connect and work with a particular operator it has to be written to *Operator Blacklist*. Up to 50 operators may be entered into this list.

The Operator search procedure is initiated every 15 minutes. During the search, FMC001 tries to connect to the operator providing the strongest signal. It will prioritize operators that are specified in the operator list. If no operators from the operator list are available, the device will try to connect to an operator from the blacklist. If the device connects to an operator from the blacklist, the best operator search procedure is initiated instantly. During the time when the device is connected to a

blacklisted operator, no GPRS connection would be initiated and no data would be sent via GPRS. However, the ability to send SMS commands to the device would remain. If no suitable operator is found on both lists, the device will try to connect to a remaining available operator with the strongest signal.