

FMC640 Manual Geofence settings

[Main Page](#) > [EOL Products](#) > [FMC640](#) > [FMC640 Configuration](#) > **FMC640 Manual Geofence settings**



FMC640 has 100 configurable Geofence zones and it can generate an event when a defined Geofence zone border is crossed. *Frame border* is an additional border around Geofence zone used to prevent false events when object stops on the border of the area and as a result records are made inside and outside the defined area because of GNSS errors. The event is generated only when both (Geofence and frame) borders are crossed. See figure to the right for details: blue track is considered to have entered the area while red track is not.

Shape can be a rectangle or a circle as defined by the user.

Priority of Geofence event is categorized into Low, High or Panic levels. These levels define the priority of event information that is sent to the server. For more details about priorities look in [I/O settings section](#).

Generate event allows to choose when record will be generated.

Eventual records controls where scenario status value appears: when disabled it will exist in each AVL record and when enabled the value will be appended only to eventual records.

OverSpeeding helps to configure OverSpeeding scenarios separately for each different *Geozone*. Regular OverSpeeding and geozones' OverSpeeding function independently. If digital output control is enabled in a regular OverSpeeding scenario, geozones OverSpeeding scenario will control it too i.e when the device is in more than one geozone and OverSpeeding is detected in any zone then the digital output turns on. Digital output turns off only when OverSpeeding is not detected anywhere.

X1 is used to set geofence zone left bottom corner X coordinate (longitude) while *Y1* is used to set Y coordinate (latitude).

X2 or *R* are used to set accordingly geofence zone upper right corner X coordinate (longitude) when Rectangular zone is used or circle radius when Circular zone is used. *Y2* sets geofence zone upper right corner Y coordinate (latitude) for a Rectangular zone.

The screenshot displays the configuration interface for a geofence zone. The left sidebar contains a list of settings, with 'Manual Geofence Settings' highlighted. The main configuration area is titled 'Manual geofence selection' and shows '1 geozone' selected. Below this, the 'Manual geofence 1' settings are detailed:

- Feature:** A 2x2 grid of buttons: 'Disable' (selected), 'Low Priority', 'High Priority', and 'Panic Priority'.
- Generate Event:** A 2x2 grid of buttons: 'On Exit' (selected), 'On Entrance', and 'On Both'.
- Eventual Records:** A 2x2 grid of buttons: 'Disable' (selected), 'Enable', and two empty buttons.
- Shape Type:** A 2x2 grid of buttons: 'Circle' (selected), 'Rectangle', and 'Polygon'.
- Radius:** A numeric input field set to 5.
- Latitude (Y1):** A numeric input field set to 0,0.
- Longitude (X1):** A numeric input field set to 0,0.
- Max Allowed Speed (km/h):** A numeric input field set to 90.

To the right of the settings is a map showing a geofence zone (yellow dashed line) around a building complex. A blue track is shown entering the zone, while a red track is shown not entering. The map includes street names like Gedimino pr., Jogailos g., and Vilniaus g., and various landmarks like DNB, Zara, Maxima X, and Novotel Vilnius. The bottom of the map shows coordinates: 54° 41' 12,04'' N, 25° 16' 47,81'' E.