

# FMM920 Trip/Odometer settings

[Main Page](#) > [Basic Trackers](#) > [FMM920](#) > [FMM920 Configuration](#) > **FMM920 Trip/Odometer settings**



## Contents

- [1 Trip Settings](#)
- [2 Advanced Trip Settings](#)
- [3 Odometer](#)

## Trip Settings



*Trip* section offers user to configure the *Trip* feature. *Trip* starts when Ignition according *Ignition source* is ON and Movement according *Movement source* is ON and also 'Start Speed' is exceeded. *Start Speed* defines the minimum GPS speed in order to detect *Trip* start.

*Ignition OFF Timeout* is the timeout value to detect *Trip* end once the Ignition (configured ignition source) is off.

I/O Trip Odometer must be enabled to use *Distance counting mode* feature. When it is set to **Continuous**, *Trip* distance is going to be counted continuously (from *Trip* start to *Trip* end) and written to I/O *Trip Odometer* value field. When *Trip* is over and the next *Trip* begins, *Trip Odometer* value is reset to zero.

When *Mode* is set to **Between Records**, the distance is going to be counted between every record made. This value is written to I/O *Trip Odometer* value field and is reset to zero every new record until the *Trip* ends. If later all Odometer values are summed up manually, the distance driven during the whole duration of the *Trip* can be obtained.



## Advanced Trip Settings



Advanced trip settings allow configuring a number of *Eco Score allowed Events* per 100 km.

I/O Eco score must be enabled to get the value onto the server. Eco score is dependent on overspeeding, Eco/Green driving (harsh acceleration, braking, cornering), excessive idling and high RPM events (latter one requires OBD BT dongle). If less of parameters/scenarios are activated - it is easier to have higher Eco score. ECO scoring is differentiated by separate Trips.

There are six Eco evaluation events:

- Harsh acceleration.
- Harsh braking.
- Harsh cornering.
- Over-speeding (will only count events with value 1 (start) and ignore value 0 (end)).
- Excessive Idling (will only count events with value 1 (start) and ignore value 0 (end)).
- High RPM.

Eco score value can range from 10 (excellent) to 0.00 (very bad):

- Excellent 8.00 - 10
- Good 6.00 - 7.99
- Not Good 4.00 - 5.99
- Bad 2.00 - 3.99
- Very Bad 0 - 1.99

**How Eco score is rated:**

- Eallowed - ECO Score Allowed Events
- d - trip distance traveled in KM
- Egen - Total generated events

**ECO score calculation example:**

Example 1

Example 2

When Total events < 1, we ignore the formula and then Eco Score is equal to 10.

✘ If *Eco Score Allowed Events* value is configured as 0, then Eco score can have only two values: 0 (when total events > 0) or 10 (when total events = 0).

✘ Score is updated every 1 km driven or every 5 minutes of *Trip* duration.

✘ Do not forget to activate "Eco score" in I/O section.

✘ If RPM is enabled under OBD and LVCAN - events will be doubled.

# Odometer



*Calculation Source* allows to choose Odometer calculation source between **GNSS**, **OBD**.  
*Odometer Value* sets the starting total odometer value.