

How to check available OBDII data?

[Main Page](#) > [Frequently Asked Questions - FAQ](#) > **How to check available OBDII data?**


Please follow this tutorial to check what OBD data is available from the vehicle

1. Send [obdinfo](#) SMS/GPRS command to the device.
2. The device responds with: Protocol, VIN, Adaptive Timing value, requested PID counter, OBD application state, available vehicle PIDs, mil status, number of DTCs.

For example: Protocol:6 VIN: WVWZZZAUZFW125650, TM:0, CNT:11, ST:PROTOCOL
DETECTION, P1:0x98180001, P2:0x1, P3:0xE0800020, P4:0x0, Fuel:OFF, MIL:0, DTC:0, ID0

3. According to the old info response, you can check available OBD parameters via OBD PID Reader. OBD reader can be found [here](#)

```
?rot:6,VIN:WOLMRF4SFGB098880, TM:20, CNT:11, ST:DATA
REQUESTING, P1:0x983BA011, P2:0xB0018001, P3:0x80000000, P4:0x0
```



Protocol:6 - specifies the protocol supported by the car.

VIN: WVVZZZAUZFW125650 - specifies car VIN number.

ST: PROTOCOLDETECTION - specifies the OBD application state.

P1:0x98180001,P2:0x1,P3:0xE0800020,P4:0x0 - specifies available vehicle PIDs. These values denote the available parameters in a given car. If all PID values are 0 (P1:0x0,P2:0x0,P3:0x0,P4:0x0), it means that OBD parameters are not readable.

MIL:0 - mil status, indicates the state of the LED (0- OFF, 1-ON).

DTC:0 - the number of errors.

Please find additional information here:

1. [OBDII protocols supported by the FMB001 and FM3001](#)
2. [OBDII parameter list](#)