

NBL-3



Contents

- [1 Introduction to the product](#)
- [2 Product Specification](#)
- [3 Updating NBL-3 firmware](#)
- [4 Device configuration](#)
- [5 Setting up Private/Business mode](#)
- [6 NBL-3 broadcasting behaviour](#)
- [7 Testing NBL-3 RFID card reading and Buttons](#)
 - [7.1 Using Telonika Configurator](#)
 - [7.2 Using Terminal application](#)
- [8 NBL-3 packet](#)

Introduction to the product



Description:

Netronix NBL-3 - wireless Bluetooth® RFID reader with additional buttons.

NBL-3 is great in these use cases:

- Authorized driving - track who is driving your vehicle. You will receive a card ID every time a driver applies a card to NBL-3 reader.
- [Business/Private mode](#) - this solution will allow your company car to be used by employees for personal purposes without violating the EU General Data Protection Regulations by masking all the personal data while vehicle is used in Private mode. Moreover, self-employed people can easily convert their own car into a business asset and ensure that the data provided (Example - distance traveled) is correct and shown only working hours' driven distance. Private/business mode can be easily switched by any of the NBL-3 buttons.
- [ID read notification](#) - functionality allows to control digital output while card is present.
- [Remember iButton](#) - functionality allows to remember RFID card ID value and send it to server while Trip scenario is detected.

Features:

- Mifare® Classic, Desfire card supports
- Bluetooth® low energy module
- Operating frequency - 13,56MHz
- Built in two LED indicators
- Built in two buttons

- Built in light sensor
- UID and card DATA available
- Configure via BL link
- Firmware update via Bluetooth®

Product Specification

Supply voltage	two AAA batteries
Sensor	Humidity
	Temperature
	Light
	Magnetic field
	Low battery voltage
Operating temperature	-20°C to +70°C
Size (mm)	100 x 58 x 18
Type	RFID reader

Updating NBL-3 firmware

Please visit <https://netronix.pl/en/nbl-readers/nbl-3> download section for manual and NBL tool.

Device configuration

NBL-3 support is available from firmware version **03.29.00.Rev.233**.

Setting up NBL-3 device to connect with FMB device.

Go to Teltonika configurator -> Bluetooth® 4.0 and set it up like it shown in this screenshot (MAC address will depend on your particular NBL sensor):



Mandatory setting condition: Non Stop Scan



Then go to I/O settings:

Make sure to enable the BLE RFID #1 parameter (ID: 51740). We would recommend to set the operand to „[On Change](#)“.



Configuration options can be navigated in the windows below.



Setting up Private/Business mode

Make sure to enable Private/Business mode in Trip/Odometer settings. It can be done using SMS commands or a configurator. Not every device has these parameters visible in the configurator, therefore they should be configured via SMS commands. It can be done by sending *setparam* SMS (how to send SMS commands: https://wiki.teltonika-gps.com/view/FMB120_SMS/GPRS_Commands). Set it to High or Low priority (parameter ID: 11850). Enable triggers as NBL Button1 or NBL Button2 (parameter ID: 11811).



Don't forget to set up data masking in Private mode if necessary.



Don't forget to save all these changes to the device and you are ready to test the NBL-3 sensor.

[More information about Private/Business Driving Mode Functionality.](#)

NBL-3 broadcasting behaviour

- When NBL-3 device captures RFID value it keeps broadcasting it for roughly a minute (it varies). NBL-3 manufacturer Netronix states that it is currently impossible to detect when the same RFID is attached to NBL-3 device again (when RFID value is still present after first read). New RFID read can only be indicated after NBL-3 value retention timeout is finished. When attaching different cards each time to reader, all will be read without issues.
- During testing another behaviour was spotted, that if Netronix NBL reader being configured in Advanced mode, only configured features are being shown in I/O elements. However FW stops detecting button states and cannot trigger immobilizer feature even when RFID card is being successfully read in I/O. As well as for immobilizer, Private/Business mode does not change state while pressing buttons. Issue being fixed when same MAC being configured as NBL reader in second connection. For that reason 2 BLE Connections need to be used for correctly working functions of single reader.

Testing NBL-3 RFID card reading and Buttons

Using Telonika Configurator

Power up the FMB device, connect it to PC and open Configurator application. Configure devices as shown above.

When the RFID card is not enabled, the BLE RFID #1 parameter (AVL ID: 451) will show a specific value.

Example (Status tab => I/O Info):



When the RFID card is activated (card touched to NBL-2 and followed by two beeps) BLE RFID #1

parameter should look like this:



Using Terminal application

Power up the FMB device, connect it to PC and start logging it into the Terminal application.

When the RFID card is not enabled, the BLE RFID #1 parameter (AVL ID: 451) will show a specific value.

Example:

IO ID[451]: 0x0000000000000000

When the RFID card is activated (card touched to NBL-3 and followed by two beeps) BLE RFID #1 parameter should look like this:

IO ID[451]: 0x0004193EF2576680

When Private/Business mode is enabled (Button1 or Button2 is pressed):

IO ID[451]: 0x0000000000000000

and

IO ID[391]: 1

NBL-3 packet

NBL-T data is being read via broadcast packets only. The packet structure is described below:

EIR Type	Description / Value	LEN
Flags - 0x01	0x06 GeneralDiscoverable, BrEdrNotSupported	3B
Complete name - 0x09	'NBL-3'	7B

Data format

BYTE: 0..1 2 3 4..5 6..7 8 9 10..18

Field: UUID Status Batt Temp Humi Light CID_Len CID

Field Description

UUID 'NX'

Data format:

MSB

LSB

Prox Temp Humi Light Card 0 B1 B2

• **Prox** - state of magnetic field sensor

• **Motion** - if 1, the measured temperature is outside the defined values

• **Motion** - if 1, the measured humidity is outside the defined range

• **Light** - if 1, the measured light is outside the defined range

• **Card** - if 1, the ID is read

• **Btn1** - state of button 1

• **Btn2** - state of button 2

Batt Battery level (%)

Temp Temperature

Humi Humidity

Light Light (8 oldest bits)

CID_Len ID length

CID ID card number

Service data - 0x16

Status

21B

Total packet length: 31B.