

TFT100 Auto Geofence settings

[Main Page](#) > [E-Mobility Trackers](#) > [TFT100](#) > [TFT100 Configuration](#) > **TFT100 Auto Geofence settings**

Auto Geofence

Auto Geofence

Scenario Settings

<input checked="" type="radio"/> Disable	<input type="radio"/> Low Priority
<input type="radio"/> High Priority	<input type="radio"/> Panic Priority

Eventual Records

<input type="radio"/> Disable	<input checked="" type="radio"/> Enable
-------------------------------	---

Generate Event

<input checked="" type="radio"/> On Exit	<input type="radio"/> On Entrance
<input type="radio"/> On Both	

Activation Timeout (s)

Radius (m)

Deactivate By

<input checked="" type="radio"/> Power Voltage	<input type="radio"/> Digital Input 1
<input type="radio"/> Engine RPM	

Send SMS To

SMS Text

AutoGeofence is based on the last known position after the movement has stopped. You can be notified using this function if your device leaves certain area. The shape and size of Geofence zones are set by parameters. It is possible to state whether entering or leaving the geofence triggers an asynchronous message. AutoGeofencing options can be configured by following parameters:

- **Eventual Records** - is used to enable or disable *Eventual Records* functionality.
- **Generate Event** - Event generation can take place on Geofence Entrance, Exit or on Both.
- **Activation timeout** - defines the delay between the creation of AutoGeofence within set radius. Activation timeout defines the delay between the creation of AutoGeofence within set Radius value around machine's most recent position and when the ignition is off.
- **Radius** - value around device's most recent position and when the ignition is off.
- **Call settings** - Disable or enable the availability to disable scenario with a call. This should be configured in [SMS/Call section](#), configure *Incoming Call Settings* to **Auto Geofence Off** and set authorized numbers if such are used.

AutoGeofence can be deactivated by:

- **Power Voltage** - If power voltage becomes higher than low voltage level (defined in Ignition settings).
- **Digital Input 1** - If DIN1 voltage becomes equal or higher than **2.5 V** (if *Analog input value* is selected as 15V) or than **9 V** (if *Analog input value* is selected as 150V).
- **Engine RPM** - If engine RPM value becomes higher than 0.

NOTE AutoGeofencing does not require entering coordinates, instead it requires GPS visibility.