

# TFT100 GSM Operators settings

[Main Page](#) > [E-Mobility Trackers](#) > [TFT100](#) > [TFT100 Configuration](#) > **TFT100 GSM Operators settings**




## Contents

- [1 Roaming operator list](#)
- [2 Operator black list](#)
- [3 Common Settings](#)

TFT100 can work in different modes (use different settings) according to the operator list defined. Operator list is used for Data Acquisition mode switching (see [Data acquisition settings](#) section for more details). Modes are changed based on GSM operator TFT100 is connected to.

## Roaming operator list



If roaming operator list is left empty, TFT100 will automatically detect home operator. If home operator is written to the roaming operator list, it will still be detected as home operator. Any operator not in the roaming operator list (except the home operator) will be recognized as unknown operator and TFT100 will work in *Unknown mode* (make sure it is configured to allow data sending - GPRS context is enabled). Operator search procedure is initiated as normal every 15 minutes and tries to connect to an operator providing the **strongest** signal. It will prioritize operators which are specified in the operator list. If no operators from the operator list are available, the device will try to connect to an operator from the blacklist. If no suitable operator is found on both lists, the device will try to connect to a remaining available operator with the strongest signal.

**NOTE!** Up to 50 operators may be entered to this list.

# Operator black list

Operator Black List

1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0

Import CSV

Export CSV

If user **does not want** TFT100 to connect and work with a particular operator it has to be written to *Operator Blacklist*. If device connects to an operator from the blacklist, best operator search procedure is initiated instantly. During the time when device is connected to blacklisted operator no GPRS connection would be initiated and no data would be sent via GPRS. However, the ability to send SMS commands to the device would remain.

**NOTE!** Up to 50 operators may be entered to this list.

## Common Settings

Common settings

Ban List Control

Disable Enable

- **Ban list control** - Enables or disables the Black list.