

Template:FMM SMS/Call settings

SMS Data Sending

These settings allow sending AVL data using binary SMS. AVL data will be sent by SMS only when there is no GPRS connection. This setting does not affect replies to SMS request messages - answers are always sent back to the sender's telephone number.

The screenshot displays the Teltonika FMM125 configuration web interface. At the top, there are utility buttons: 'Load from device', 'Save to device', 'Update firmware', 'Reset configuration', 'Load from file', 'Save to file', 'Read records', and 'Reboot device'. The device information shows IMEI 352000000000000, FW 01.00.00 Rev:00, and Configuration 1.00.0.0. A left sidebar lists various configuration categories, with 'SMS \ Call Settings' selected. The main content area is divided into three sections: 'SMS Data Sending' with 'Allow SMS Data Sending' set to 'Disable' and a 'Data Send Number' field; 'SMS Commands' with 'Login' and 'Password' fields and an 'SMS Event Time Zone' dropdown set to 'UTC+00:00'; and 'Incoming Call Settings' with 'Incoming Call Action' set to 'Do Nothing' and 'Report Position' as an option. Two tables, 'Authorized Numbers' and 'GSM Predefined Numbers', each have 20 rows and 'Import CSV'/'Export CSV' buttons at the bottom.

SMS commands

Essential fields in *SMS/Call settings* are *Login* and *Password*. The login and password are used with every SMS sent to FMB1YX. If login and password are not set, in every SMS sent to FMB1YX device two spaces before command have to be used (<space><space><command>).

Command structure with set login and password:

<login><space><password><space><command>, for example: "asd 123 getgps"

Phone numbers have to be written in international standard, using "+" is optional but not necessary (in both cases number will be recognized, but when number is without "+" symbol, IDD Prefix will not be generated, which depends on location of the phone). If no numbers are entered, configuration and sending commands over SMS are allowed from all GSM numbers.