


Template:FMU GSM Operators settings

FMU1YX can work in different modes (use different settings) according to the operator list defined. Operator list is used for Data Acquisition mode switching (see [Template:FMU Data acquisition settings](#) section for more details). Modes are changed based on GSM operator FMU1YX is connected to.



If roaming operator list is left empty, FMU1YX will automatically detect home operator. If home operator is written to the roaming operator list, it will still be detected as home operator. Any operator not in the roaming operator list (except the home operator) will be recognized as unknown operator and FMU1YX will work in Unknown mode (make sure it is configured to allow data sending - GPRS context is enabled).

If user wants FMU1YX to not connect and work with a particular operator it has to be written to *Operator Blacklist*. Up to 50 operators may be entered to this list.

Operator search procedure is initiated as normal every 15 minutes and tries to connect to an operator providing the strongest signal. It will prioritize operators which are specified in the operator list. If no operators from the operator list are available, the device will try to connect to an operator from the blacklist. If device connects to an operator from the blacklist, best operator search procedure is initiated instantly. During the time when device is connected to blacklisted operator no GPRS connection would be initiated and no data would be sent via GPRS. However, the ability to send SMS commands to the device would remain. If no suitable operator is found on both lists, the device will try to connect to a remaining available operator with the strongest signal.