

# FM3622 SMS events

[Main Page](#) > [EOL Products](#) > [FM3622](#) > [FM3622 Configuration](#) > **FM3622 SMS events**

SMS events functionality allows FM3622 to send a configured SMS when an event is triggered. This event can be triggered by:

- [Green Driving](#)
- [Over Speeding](#)
- [Authorized driving](#)
- [Immobilizer](#)
- [Trip start/stop](#)
- [Geofence](#)
- [Autogeofence](#)
- [I/O event](#)

When any of the above events is triggered, FM3622 sends a configured SMS message to a defined phone number. If SMS events is activated, but there are no numbers defined in SMS events PreDefined Numbers list (figure below), then the device will not send any messages.



The sent SMS messages format is according to:

*"Date Time EventText"*

For example, if FM3622 is configured to send an SMS (figure below "SMS Events" section), when Digital Input 1 reaches High level, with priority High and configured to generate event on both range enter and exit(figure below "IO" section), then the sent SMS is:

*"2016/1/20 12:00:00 Digital Input 1"*



The SMS Text field can be altered and any text can be entered. Maximum message length is 90 symbols (numbers, letters and symbols in ASCII, except for comma ",").

ATTENTION! If FM3622 is in Deep Sleep mode and SMS event occurs with LOW priority (which does not wake up FM3622), then the device does not send the message. It is saved in device memory until it wakes up from Deep Sleep mode and GSM modem starts working normally. After it wakes up, all the messages that are saved in memory will be sent, but keep in mind that only 10 messages can be saved in memory - all other messages will not be saved, until there is room in device memory.

## Configuration

---

### Scenarios

To configure SMS events for scenarios, open Scenarios window and Enable desired scenario. Then go to GSM ->SMS -> SMS events window and activate SMS event for Enabled scenario. Figure

below shows how to enable Green Driving and Immobilizer SMS Events.



When any of the scenarios events occurs, a text message will be sent to the predefined number.

## **TRIP**

In order to configure Trip SMS events click on Trip window and Enable Trip feature (figure below). Then go to GSM -> SMS -> SMS Events settings and Enable Trip SMS event. After enabling SMS Events (figure below), trip event will be triggered and message sent, when Trip starts (GNSS speed exceeds the speed in Start Speed (ex. 5 km/h) and when Trip stops, that is ignition is turned off longer then the time written in Ignition Off Timeout (ex. 60 seconds).



## **Geofence**

Geofence SMS event is triggered and message sent when the device exits and/or enters a configured Geofence zone. The Geofence zone must be configured to generate an event On Exit, On Enter or On Both (figure below). If No Event is selected, then it is not possible to turn on SMS events. If several zones are created then SMS events can be turned on separately for each zone entering different text message.



## **AutoGeofence**

SMS events for AutoGeofence are configured the same as in Geofence. AutoGeofence is in Features -> Auto geofencing, for SMS events configuration, go to GSM -> SMS -> SMS Events (figure below).



## **I/O events**

FM3622 sends SMS event message when a configured I/O property enters and/or exits its configured High/Low boundaries or Hysteresis event generation is chosen (Monitoring does not generate event, so SMS event could not be configured). Every IO element SMS event can be configured to send individual message to different numbers.

