

FMB140 Security info

[Main Page](#) > [CAN Trackers & Adapters](#) > [FMB140](#) > [FMB140 Configuration](#) > **FMB140 Security info**

In security section user can see SIM card and configurator keyword security information.

- The state and status of currently connected SIM card (SIM1 or SIM2) can be observed here. If a SIM card with PIN code is used, user can enter it in this section. The remaining attempts to enter PIN code are shown as well.
- When SIM PIN code is entered correctly user can change PIN code or disable it from the SIM card. When SIM PIN is disabled and user would like to enable it again, user must enter the previously used PIN code.
- If two SIM cards are inserted into the device, user can change PIN codes for both of them.
- Configuration security keyword can be set to configurator. Keyword can be saved in configuration file (.cfg), so there is no need to connect the device to the configurator to configure the keyword. Minimum keyword length is 4 symbols and maximum length is 10 symbols. Only uppercase and lowercase letters and numbers are supported. Keyword can be configured to .cfg configuration file when the device is not connected.

The screenshot shows the Teltonika FMB140 configurator interface. At the top, there is a navigation bar with buttons for 'Load from device', 'Save to device', 'Update firmware', 'Reset configuration', 'Load from file', 'Save to file', 'Read records', and 'Reboot device'. On the right side of this bar, there is a SIM card icon and text indicating 'IMEI', 'FW 03.25.15 Rev:', and 'Configuration 6.1.17.0'. The left sidebar contains a menu with various settings categories. The main content area is divided into sections: 'Device Info' showing fields like Device Name, Last Start Time, Power Voltage, Ext Storage, and Battery Voltage; 'GNSS Info' with sub-sections for 'GNSS Status', 'Satellites' (Visible and In Use), and 'Location' (Latitude/Longitude, Altitude, HDOP, Speed, Angle, PDOP). The bottom of the interface has social media icons and a settings gear icon.

*Please note that This feature will only show up in configurator when device is connected to a computer.