

FMB240 SMS/GPRS Commands

[Main Page](#) > [CAN Trackers & Adapters](#) > [FMB240](#) > [FMB240 Manual](#) > **FMB240 SMS/GPRS Commands**

Commands apply for these devices:

[FMB001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FMB130](#) [FMB202](#) [FMB204](#) [FMB208](#) [FMB900](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMT100](#) [FMC001](#) [FMC003](#) [FMC00A](#) [FMM001](#) [FMM003](#) [FMM00A](#) [FMC125](#) [FMC130](#) [FMM125](#) [FMM130](#) [FMU125](#) [FMU126](#) [FMU130](#) [MTB100](#) [FMB140](#)

All commands are case sensitive. When user tries to send SMS/GPRS message to device that operates in Deep Sleep mode, it cannot arrive to it because the GSM/GPRS module is disabled most of the time. Device will receive the SMS message when it exits Deep Sleep mode, but GPRS commands will not be received after exiting Deep Sleep Mode.

If the device is in GPS Sleep or Online Deep Sleep mode, sent SMS/GPRS message will arrive to the device.

SMS command structure:

<SMS login><space><SMS password><space><command><space><value>

SMS command [getinfo](#) example:

- If you have set SMS login and password: login pass getinfo
- If SMS login and password are not set leave two spaces before command: getinfo

GPRS commands require [Codec 12](#) protocol.

□

Contents

- [1 Commands apply for these devices:](#)
- [2 Common commands](#)
- [3 Bluetooth Commands](#)
- [4 Commands Related to Features](#)
- [5 OBD Commands](#)
- [6 CAN Adapter Commands](#)

To search for compatible products, [Expand all content](#)

Common commands

Command	Description	Response	HW Support	Parameter Group
---------	-------------	----------	------------	-----------------

[getinfo](#)

Device runtime system information.

Yes

Common commands

[getver](#)

Returns code version, device IMEI, modem app version, RTC time, Init time, Uptime and BT MAC address.

Yes

Common commands

[getstatus](#)

Modem Status information.

Yes

Common commands

FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMU125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FM3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMU125
FMU130
FMC800
FMM800
FMM80A
FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMU125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FM3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMU125
FMU130
FMC800
FMM800
FMM80A
FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMU125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FM3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMU125
FMU130
FMC800
FMM800
FMM80A

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
getgps	Current GPS data, date and time.	Yes	Common commands	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A
getio	Readout analog input,digital input and output.	Yes	Common commands	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A
gps	Returns location information with Google maps link.	Yes	Common commands	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A

					FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 EMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
radio #	Returns IO status, # AVL ID.	Yes		Common commands	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 EMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
cpureset	Resets device	No		Common commands	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 EMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
fwstats	Get data about FW and restarts	Yes		Common commands	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 EMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	

getrecord

SMS command initiates saving and sending of high priority record.

No

Common commands

FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMU125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FMB3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMU125
FMU130
FMC800
FMM800
FMM80A

getimeiccid #

Response is sent to SMS/GPRS command sender and also to GSM number provided. #
- GSM number using international format e.g. 37069012345

Yes

Common commands

FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMU125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FMB3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMU125
FMU130
FMC800
FMM800
FMM80A

getimsi

Sends the IMSI number of the SIM card inserted as a response to the sender.

If two SIM cards are inserted in the device, the response will be the IMSI number of the currently active SIM card.

Note: This command is supported from 03.10.02 firmware version.

Yes

Common commands

FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMU125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FMB3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMU125
FMU130
FMC800
FMM800
FMM80A

[getops](#)

Returns list of all currently visible operators.

Yes

Common commands

[allver](#)

Responds with information about hardware and firmware versions and storage space

Yes

Common commands

[getparam](#) #

Returns selected parameter value.
- first [ID value](#). # - second [ID value](#). # - third [ID value](#).
SMS command is limited to 160 characters.

Yes

Common commands

[getparam](#) #;#;...

FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMB125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FMB3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMB125
FMB130
FMC800
FMM800
FMM80A
FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMB125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FMB3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMB125
FMB130
FMC800
FMM800
FMM80A
FMBXXX
FMB001
FMC001
FMB010
FMB110
FMB120
FMB122
FMB125
FMB125
FMB130
FMB140
FMB150
FMC150
FMM150
FMB900
FMB920
FMB962
FMB964
FMB3001
FMB202
FMB204
FMB206
FMT100
MTB100
EMP100
FMC001
FMC125
FMC130
FMM001
FMM125
FMM130
FMB125
FMB130
FMC800
FMM800
FMM80A

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
setparam #:#	Sets selected parameter value [Parameter ID] : [New Parameter Value] ; [Parameter ID] : [New Parameter Value]... SMS command is limited to 160 characters.	Yes	Common commands		
setparam #:#;#:#;...			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
flush #,#,#,#,#,#,#	Redirects device to other server. 1.# - IMEI. 2.# - APN. 3.# - LOGIN. 4.# - PASS. 5.# - IP. 6.# - PORT. 7.# - MODE (0-TCP/1-UDP).	Yes	Common commands		
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
countrecs	Returns records number.	Yes	Common commands		
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
web_connect	Forces device to connect to Fota WEB immediately.	Yes	Common commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
deleterecords	Delete all records from SD card.	Yes	Common commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
setdigout ## Y1 Y2 Z1 Z2	Set digital output. 1.# - 0; 1 or ? (0 - OFF, 1 - ON, ? - Ignore) for DOUT1. 2.# - 0; 1 or ? (0 - OFF, 1 - ON, ? - Ignore) for DOUT2. Y1 - timeout value for DOUT1 if needed (in seconds). Y2 - timeout value for DOUT2 if needed (in seconds). Z1 - maximum speed value for DOUT1 if needed. Z2 - maximum speed value for DOUT2 if needed.	Yes	Common commands	
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB900 FMB910 FMB920 FMB962 FMB964 FMB202 FMB204 FMB209 FMC125 FMM125 FMU125 FMC130 FMM130 FMU130 FMU126 MSP500	

[illegible]

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
defaultcfg	Load default configuration.	Yes		Common commands
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
setkey # #	Add new or change current configuration keyword. If device is locked, keyword cannot be changed. 1.# - old keyword (if adding new keyword space). 2.# - new keyword.	Yes		Common commands
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
delkey #	Remove existing keyword (If device is locked, keyword cannot be changed). # - old keyword.	Yes		Common commands
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
bbread #	Return black box information (HEX value of event ID and HEX value of custom data field (optional)). # - returns entered number of latest events. When # is omitted the latest events are packed to single SMS.	Yes	Common commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
bbinfo #	Return same information as bbread command but additional all events timestamp is written in HEX. # - returns entered number of latest events. When # is omitted the latest events are packed to single SMS.	Yes	Common commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
sdformat	Format SD card.	Yes	Common commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	

Bluetooth Commands

Command	Description	Response	HW Support	Parameter Group
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
btgetlist #	Returns requested Bluetooth list. # - 0,1 or 2 (0 - Discovered, 1 - Paired, 2 - Connected, 3 - Discovered BT4/BLE devices).	Yes		Bluetooth commands
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
btscan	Starts Bluetooth scan.	Yes		Bluetooth commands

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMM130 FMM125 FMM130 FMC800 FMM800 FMM80A	
<i>btvisible #</i>	Sets Bluetooth to visible with TMO. # - visibility TMO (from 1 to 255 seconds).	Yes	Bluetooth commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMM130 FMM125 FMM130 FMC800 FMM800 FMM80A	
<i>btrelease #</i>	Disconnects from current device and pauses auto connect functionality for TMO. # - none or TMO (from 1 to 255 seconds).	Yes	Bluetooth commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMM130 FMM125 FMM130 FMC800 FMM800 FMM80A	
<i>btunpair #</i>	Unpair Bluetooth device. # - all, BT address (all - unpair all devices, BT address - unpair only specified MAC address).	Yes	Bluetooth commands	
			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMM130 FMM125 FMM130 FMC800 FMM800 FMM80A	

Commands Related to Features

- FMBXXX [FMB001](#)
- [FMC001](#)
- [FMB010](#)
- [FMB110](#)
- [FMB120](#)
- [FMB122](#)
- [FMB125](#)
- [FMU125](#)
- [FMB130](#)
- [FMB140](#)
- [FMB150](#)
- [FMC150](#)
- [FMM150](#)
- [FMB900](#)
- [FMB920](#)
- [FMB962](#)
- [FMB964](#)
- [FM3001](#)
- [FMB202](#)
- [FMB204](#)
- [FMB206](#)
- [FMT100](#)
- [MTB100](#)
- [FMP100](#)
- [FMC001](#)
- [FMC125](#)
- [FMC130](#)
- [FMM001](#)
- [FMM125](#)
- [FMM130](#)
- [FMU125](#)
- [FMU130](#)
- [FMC800](#)
- [FMM800](#)
- [FMM80A](#)

			FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
fc_reset	Resets fuel consumption parameters.	Yes	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	Commands related to features
towingreact	Towing reactivation.	Yes	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	Commands related to features
auto_calibrate:get	Returns the state of calibration.	Yes	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	Commands related to features

				FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
odoset :#	Set total odometer value. # - new odometer value in km.	Yes			Commands related to features	
				FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
odoget	Display current odometer value.	Yes			Commands related to features	
				FMB965 FMB930	Commands related to features	
go2sleep	Puts device to sleep ignoring going to sleep condition and stays asleep for the set time. Note: This command is supported from 03.27.10.Rev.482 firmware version.	Yes		FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A		
on_demand_trackingX	X=0 - Stops Tracking on Demand functionality. X=1 - Starts Tracking on Demand functionality. X=2 - Generates one high priority record and initiates data sending to server. Note: This command is supported from 03.25.06 firmware version.	Yes			Commands related to features	

OBD Commands

Command	Description	Response	HW Support	Parameter Group
---------	-------------	----------	------------	-----------------

obdinfo	Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth OBD dongle. Response displays all available information from OBD.	Yes	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	OBD Commands
faultcodes	Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth OBD dongle. Response displays all visible fault codes.	Yes	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	OBD Commands
cleardtc	Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth OBD dongle. Command clears all vehicle stored fault codes.	Yes	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	OBD Commands

				FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	
<i>getvin</i>	Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth OBD dongle. Response displays vehicle VIN code.	Yes		OBD Commands	

CAN Adapter Commands

Command	Description	Response	HW Support	Parameter Group
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
<i>lvcansetprog #</i>	Set program number to CAN Adapter # - three to five digit vehicle specific number	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
<i>lvcangetprog</i>	Get program number from CAN Adapter	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcangetinfo	Get information about connected CAN adapter	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
<i>lvcansimpletacho #</i>	Add or remove simpletacho start byte. # - 0 or 1 (0 - don't add start byte, 1 - add start byte).	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanclear #	Clear Total Mileage (counted), Engine Work Time (counted), Fuel Consumed (counted) parameters values. # - parameter (0 - Engine work time (counted), 1 - Fuel Consumed (counted), 2 - Vehicle Mileage (counted))..	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
<i>allcanmode</i>	Turn on ALL-CAN300 mode.	Yes		CAN Adapter Commands

			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanmode	Turn on LV-CAN200 mode.	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanfaultcodes	Read DTC fault codes.	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanopenalldoors	Toggle CAN-CONTROL to open [unlock] all doors	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanclosealldoors	Toggle CAN-CONTROL to close [lock] all doors	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanopentruunk	Toggle CAN-CONTROL to open [unlock] trunk	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanblockengine	Toggle CAN-CONTROL to block vehicle engine (if command is not supported, please, visit FAQ)	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanunblockengine	Toggle CAN-CONTROL to unblock vehicle engine (if command is not supported, please, visit FAQ)	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanturninglights	Toggle CAN-CONTROL to flash lights One flash of all turn lights ordered trough accidental / blinking turn light switch	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcanhorn	Toggle CAN-CONTROL to activate single horn sound	Yes		CAN Adapter Commands
			FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
lvcansetting#,#	This command is used to set specific counters for vehicles. From that moment of setting the value, vehicle will continue to count from the specified value. 1.#: 0 - setting total engine work time (seconds) 1 - setting total mileage of the vehicle (km) 2 - resetting total fuel consumption to 0 is available (liters) 3 - setting total CNG use (kg) 4 - setting electric engine work time (seconds) 5 - setting wheel speed sensor impulses (impulses) 2.# - value(0 to 0xFFFFFFFF or ? (? - is used to get the current setting value)) Note: This command is supported from 03.25.15.Rev.145 firmware version.	Yes	FMB140	CAN Adapter Commands
lvcanrefresh	This command forces FMB1YX connection to FOTA WEB to report current CAN adapter status. Note: This command is supported from 03.25.16.Rev.281 firmware version.	Yes	FMB140	CAN Adapter Commands

lvcanreset	This command forces CAN adapter reset. Note: This command is supported from 03.25.16.Rev.281 firmware version.	Yes	FMB140	CAN Adapter Commands
lvcancheck	This command reports CAN lines connection information. Note: This command is supported from 03.25.16.Rev.281 firmware version.	Yes	FMB140	CAN Adapter Commands