

FTC961 First Start

[Main Page](#) > [Basic Trackers](#) > [FTC961](#) > **FTC961 First Start**

Small and smart waterproof tracker



Contents


- [1 HOW TO INSERT MICRO-SIM CARD AND CONNECT THE BATTERY](#)
- [2 PC CONNECTION \(WINDOWS\)](#)
- [3 HOW TO INSTALL USB DRIVERS \(WINDOWS\)](#)
- [4 CONFIGURATION \(WINDOWS\)](#)
- [5 MOUNTING RECOMMENDATIONS](#)

HOW TO INSERT MICRO-SIM CARD AND CONNECT THE BATTERY

1. Gently remove FTC961 **side cover** using **plastic pry tool**
2. Insert **Nano-SIM** card as shown. Make sure that Nano-SIM card **cut-off corner** is pointing towards SIM slot.
3. Battery is already connected, so after configuring device fully close casing
4. Device is ready to be mounted.



Nano-SIM card insertion/removal must be performed when device is powered off -

-  **external voltage and internal battery disconnected. Otherwise Nano-SIM card might be damaged or device will not detect it.**

PC CONNECTION (WINDOWS)

1. Power- up FTC961 with DC voltage (10-70V) power supply using power wires. LEDs should start blinking.
2. Connect device to computer using Micro-USB cable and install USB driver, see "How to install USB drivers (Windows)"

HOW TO INSTALL USB DRIVERS (WINDOWS)

1. Please download COM port drivers from [here](#).
2. Extract and run TeltonikaCOMDriver.exe.
3. Click Next in driver installation window.
4. In the following window click Install button.
5. Setup will continue installing the driver and eventually the confirmation window will appear. Click Finish to complete the setup.

CONFIGURATION (WINDOWS)

At first FTC961 device will have default factory settings set. These settings should be changed according to the user's needs. Main configuration can be performed via [Teltonika Configurator tool \(TCT\)](#).

MOUNTING RECOMMENDATIONS

DEVICE FASTENING

- Locate the battery in your vehicle. If present remove the battery cover to access the battery.
- There is a double sided tape on the back of the device, use it to attach the device on the battery, so that the GNSS antenna and LEDs indicators are facing up.

CONNECTING POWER SOURCE

- Device power wire is designed to be directly connected to the positive terminal fastener of the vehicle battery.

CONNECTING GROUND WIRE

- Connect ground wire to the vehicle frame or metal parts that are fixed to the frame.
- If the wire is fixed with the bolt, the loop must be connected to the end of the wire.
- Device ground wire is designed to be directly connected to the negative terminal fastener of the vehicle battery.