## **MTB100 GSM Operators settings**

<u>Main Page</u> > <u>EOL Products</u> > <u>MTB100</u> > <u>MTB100 Configuration</u> > **MTB100 GSM Operators settings** 

## **GSM settings**

## **Operator lists**

MTB100 can work in different modes (use different settings) according to the operator list defined. Operator list is used for Data Acquisition mode switching (see <u>Data acquisition settings</u> section for more details). Modes are changed based on the GSM operator MTB100 is connected to.

Security	GSM Settings		
System	Roaming Operator List Operator	lack List	
GPRS			
Data Acquisition	1 0 1 0		
SMS \ Call Settings	2 0 2 0		
GSM Operators	3 0 3 0 4 0 4 0		
Features	4 0 4 0 5 0 5 0	_	
Accelerometer Features	6 0 6 0		
Auto Geofence	7 0 7 0		
Manual Geofence	8 0 8 0		
Trip \ Odometer	9 0 9 0		
	10 0 10 0	_	
Bluetooth	11 0 11 0		
Bluetooth 4.0	12 0 12 0		
Beacon List	13 0 13 0	_	
1-Wire	14 0 14 0 15 0 15 0	_	
	16 0 16 0	_	
OBD II	17 0 17 0		
CAN Adapter	18 0 18 0		
	19 0 19 0		
RS232 \ RS485	20 0 20 0		
	Import CSV Import	CSV	
	Export CSV Export		
🥂 f 🔚 💙 🔂 in 🖉			(

## Configuring device roaming and blacklist operators is recommended to optimize device performance by mitigating additional latency.

If the roaming operator list is left empty, MTB100 will automatically detect the home operator. If the home operator is written to the roaming operator list, it will still be detected as a home operator. Any operator not in the roaming operator list (except the home operator) will be recognized as an unknown operator and MTB100 will work in Unknown mode (make sure it is configured to allow data sending – GPRS context is enabled).

If the user wants MTB100 to not connect and work with a particular operator it has to be written to *Operator Blacklist*. Up to 50 operators may be entered into this list.

The Operator search procedure is initiated every 15 minutes. During the search, MTB100 tries to connect to the operator providing the strongest signal. It will prioritize operators that are specified in the operator list. If no operators from the operator list are available, the device will try to connect to an operator from the blacklist. If the device connects to an operator from the blacklist, the best operator search procedure is initiated instantly. During the time when the device is connected to a

blacklisted operator, no GPRS connection would be initiated and no data would be sent via GPRS. However, the ability to send SMS commands to the device would remain. If no suitable operator is found on both lists, the device will try to connect to a remaining available operator with the strongest signal.