https://wiki.teltonika-gps.com/view/TFT100\_CAN\_I/O\_settings

# **TFT100 CAN I/O settings**

<u>Main Page</u> > <u>E-Mobility Trackers</u> > <u>TFT100</u> > <u>TFT100</u> Configuration > **TFT100** CAN I/O settings

## Contents

- <u>1 CAN Protocol</u>

  <u>1.1 Bosch CAN Powertrain</u>

  <u>1.1 Bosch CAN Powertrain I/O</u>
  <u>1.2 Askoll</u>

  <u>1.2 Askoll</u>
  <u>1.2.1 Askoll I/O</u>

  <u>1.3 Default J1939</u>

  <u>1.3 Default J1939 I/O</u>

  <u>1.4 Manual CAN</u>

  <u>1.4.1 Manual CAN I/O</u>

  <u>1.5 Manual J1939</u>

  <u>1.5.1 Manual J1939 I/O</u>

  <u>1.6 FLEX</u>

  <u>1.6.1 FLEX I/O</u>
  <u>1.7 Debug</u>
- <u>3 CAN I/O reset</u>

## **CAN Protocol**

```
★ ATTENTION
CAN interface does not work when device does not have external power available.
```

**CAN I/O** category offers users an ability to select one of CAN protocols to read specific data through TFT100 CAN interface.

TFT100 currently has 6 implemented CAN protocols and DEBUG function:

- Bosch CAN Powertrain
- Askoll
- Default J1939
- Manual CAN
- Manual J1939
- FLEX
- Debug feature

**Bosch**, **Askoll**, **Default J1939** and **FLEX** CAN protocols come with specific CAN I/O parameters that can be read, monitored, configured and their values sent to the configured server. **Manual CAN** and **Manual J1939** protocols do not include dedicated specific I/O parameters however it welcomes user to configure what has to be read from the transport based on their transport CAN communication protocol.

### **Bosch CAN Powertrain**

CAN Protocol	
CAN Protocol	5
None	Bosch
Askoll	Default 11030
ASKOII	Delault J1939
Manual CAN	Manual J1939

**Bosch CAN Powertrain protocol** allows users to read parameters from their transport, if the transport uses *Bosch* motor. The protocol is enabled by selecting **Bosch** parameter in *CAN Protocol* field as shown in the image on the right hand side.

#### **Bosch CAN Powertrain I/O**

Specific **Bosch CAN Powertrain** I/O parameters were implemented to our device's firmware that can be read, configured and sent to the server just like regular I/O parameters. The parameters that were added can be seen in the image below.

	The	
	parameters	
	were	
	added	
	upon	
	clients'	
	request.	
NOTEL	Bosch CAN	
NUIE:	protocol	
	contains	
	way more	
	parameters	
	that can be	
	added by	
	us if	
	necessary.	

	Ν							
Input Name	45	Units	Priority				Low Level	High Level
Park Brake			None	Low	High	Panic	0 🤹	
Selected Charge Mode			None	Low	High	Panic	0 👶	
Charger State			None	Low	High	Panic	0 🐥	
Charger Voltage		mV	None	Low	High	Panic	0 🐳	
Charger Current		mA	None	Low	High	Panic	0 🐥	
Charger Control Mode			None	Low	High	Panic	0 🐥	
BMS COM Timeout			None	Low	High	Panic	0 👶	
Charger CRC Violation			None	Low	High	Panic	0 👶	
Charger MC Violation			None	Low	High	Panic	0 👶	
Charger Status			None	Low	High	Panic	0 🗘	
Actual Voltage		mV	None	Low	High	Panic	0 👶	
Charger Internal Fault			None	Low	High	Panic	0 👶	
Charger Energy		Wh	None	Low	High	Panic	0 👶	
Charger Current Actual		mA	None	Low	High	Panic	0 👶	
Throttle Position		%	None	Low	High	Panic	0 🗘	
Brake Pressed			None	Low	High	Panic	0 🗘	
Charge Plugged			None	Low	High	Panic	0 👶	
Kill Switch Active			None	Low	High	Panic	0 👶	
Vieletand Balanca Status			Mana	1	115-b	Denie	n ^	

- The AVL ID list of Bosch CAN Powertrain parameters can be found in here.
- SMS/GPRS commands that were developed for Bosch CAN Powertrain protocol can be found in <u>here</u>.

### Askoll

CAN Protocol	
CAN Protocol	}
None	Bosch
Askoll	Default J1939
Manual CAN	Manual J1939

**Askoll** CAN protocol allows users to read parameters from their e-scooters manufactured by *Askoll*. The protocol is enabled by selecting **Askoll** parameter in *CAN Protocol* field as shown in the image on the right hand side.

#### Askoll I/O

Specific **Askoll** I/O parameters were implemented to our device's firmware that can be read, configured and sent to the server just like regular I/O parameters. The parameters that were added can be seen in the image below.

CAN I/O								
Input Name	ß	Units	Priority			Low Level	High Level	
Charger Voltage		mV	None	Low	High	Panic	0 🗘	
Charger Current		mA	None	Low	High	Panic	0 🐥	
Malfunction Indication			None	Low	High	Panic	0 🐥	
Estimated Range		km	None	Low	High	Panic	0 🐥	
SoC Battery		%	None	Low	High	Panic	0 🐳	
Remaining Capacity		Ah	None	Low	High	Panic	0 🐳	
Total Distance		km	None	Low	High	Panic	0 🗘	
Trip Distance		m	None	Low	High	Panic	0 🗘	
Vehicle Speed		km/h	None	Low	High	Panic	0 🗘	
Ignition Fast Status			None	Low	High	Panic	0 🗘	
Helmet Status			None	Low	High	Panic	0 🗘	
Top Case sensor			None	Low	High	Panic	0 🗘	
Central Stand Up			None	Low	High	Panic	0 🗘	
Emergency			None	Low	High	Panic	0 🐳	
Over-Under Temperature			None	Low	High	Panic	0 🐳	
Regenereration Disabled			None	Low	High	Panic	0 🐳	
Battery On/Off			None	Low	High	Panic	0 🐳	
Warning UnderVoltage			None	Low	High	Panic	0 🐥	
Marping QuarValtage			Mana	1.000	Ulab	Dania	n ^	

- The AVL ID list of Askoll parameters can be found in here.
- SMS/GPRS commands that were developed for Askoll protocol can be found in <u>here</u>.

### Default J1939

## ×

**Default J1939** protocol support was added to TFT100 device's firmware since it is one of the most popular CAN protocols used in heavy duty (i.e. *forklifts*) machinery industry. If the machinery communicates via J1939 CAN protocol, the device will be able to read provided parameter's data and transmit readings to your configured server. To use **Default J1939** CAN protocol user should select **Default J1939** parameter in *CAN Protocol* field as shown in the image on the right hand side.

**Default J1939** can be tested **NOTE!** on FW 55.00.09.rev.04 or newer

To read data with this functionality, the user must have:

- TFT100 device with CAN interface;
- 55.00.09.Rev.04 or newer firmware;
- Machinery with CAN interface, which communicates via J1939 protocol.

#### Default J1939 I/O

All **Default J1939** CAN I/O parameters can be configured like standard I/O parameters. User can

set priority, high level, low level parameter limits, eventual record, operand, SMS text and number to which SMS notification would be sent.

Input Name	Units	Priority				Low Level	High Level	Event C	Only		Operand	Send SMS To	SMS Text
Accelerator Pedal 1 Low Idle Switch		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Accelerator Pedal 1 Low Idle
Accelerator Pedal Kickdown Switch		None	Low	High	Panic	0 0	0 🗘	Crash	Yes	No	Monitoring ~	~	Accelerator Pedal Kickdown
Road Speed Limit Status		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Road Speed Limit Status
Road Speed Limit Status		None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Accelerator Pedal 2 Low Idle
Accelerator Pedal Position 1	%	None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Accelerator Pedal Position 1
Engine Percent Load At Current Speed	%	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Engine Percent Load At Cun
Remote Accelerator Pedal Position		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Remote Accelerator Pedal P
Accelerator Pedal 2 Position	%	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Accelerator Pedal 2 Position
Vehicle Acceleration Rate Limit Status		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Vehicle Acceleration Rate Li
Momentary Engine Maximum Power Enable Feedback		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Momentary Engine Maximu
DPF Thermal Management Active		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	DPF Thermal Management /
SCR Thermal Management Active		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	SCR Thermal Management /
Actual Maximum Available Engine - Percent Torque	%	None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Actual Maximum Available (
Estimated Pumping - Percent Torque	%	None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Estimated Pumping - Percer
Engine Torque Mode		None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Engine Torque Mode
Actual Engine - Percent Torque (Fractional)	%	None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Actual Engine - Percent Torc
Driver's Demand Engine - Percent Torque	%	None	Low	High	Panic	0 🗘	0 🗢	Crash	Yes	No	Monitoring ~	~	Driver's Demand Engine - P
Actual Engine - Percent Torque	%	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Actual Engine - Percent Torc
Engine Speed	rpm	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Engine Speed

• The AVL ID list of Default J1939 parameters can be found in here.

## **Manual CAN**

CAN Protocol	
CAN Protocol	à
None	Bosch
Askoll	Default J1939
Manual CAN	Manual J1939

The **Manual CAN** protocol is enabled by selecting **Manual CAN** parameter in *CAN Protocol* field as shown in the image on the right hand side. Then user can configure CAN parameters in <u>Manual CAN</u> <u>Settings</u> tab.

Manual CAN can be tested **NOTE!** on FW 55.00.09.rev.04 or newer

The main benefit, of using **Manual CAN** functionality is that user is able to read data via CAN BUS without requiring additional CAN protocol development from the device's firmware side. To read data with this functionality, the user must have:

- TFT100 device with CAN interface;
- 55.00.09.Rev.04 or newer firmware;
- Transport with CAN interface;
- Transport's CAN communication protocol (with information about frames, parameters, ID's, baud rate).

#### Manual CAN I/O

Up to 30 I/O parameters (Priority, Event Only, Operand, Send SMS To, SMS text) for **Manual CAN** functionality can be configured in CAN I/O tab.

NOTE!	It is important to not forget that <u>Manual</u> <u>CAN</u> <u>Settings</u> tab <b>must</b> <b>be</b> <b>configured</b> as well.
-------	--

CAN I/O																															
Input Name	Units	Priority	ority																				Low Level	High Level	Event C	nly		Operand	Send SMS To	SMS Text	
Manual CAN0		None Low	High	Panic			Crash	Yes	No	Monitoring ~	v	Manual CAN0																			
Manual CAN1		None Low	High	Panic			Crash		No	Monitoring ~	v	Manual CAN1																			
Manual CAN2		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	v	Manual CAN2																			
Manual CAN3		None Low	High	Panic			Crash	Yes	No	Monitoring ~	Ý	Manual CAN3																			
Manual CAN4		None Low	High	Panic			Crash	Yes	No	Monitoring ~	Ý	Manual CAN4																			
Manual CAN5		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	Ý	Manual CAN5																			
Manual CAN6		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	Ý	Manual CAN6																			
Manual CAN7		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	Ý	Manual CAN7																			
Manual CAN8		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	Ý	Manual CAN8																			
Manual CAN9		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	v	Manual CAN9																			
Manual CAN10		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	v	Manual CAN10																			
Manual CAN11		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸	v	Manual CAN11																			
Manual CAN12		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	v	Manual CAN12																			
Manual CAN13		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	v	Manual CAN13																			
Manual CAN14		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	v	Manual CAN14																			
Manual CAN15		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	v	Manual CAN15																			
Manual CAN16		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	v	Manual CAN16																			
Manual CAN17		None Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	v	Manual CAN17																			
Manual CAN18		None Low	High	Panic			Crash	Yes	No	Monitoring ~	v	Manual CAN18																			
Manual CAN19		None Low	High	Panic			Crash	Yes	No	Monitoring ~	v	Manual CAN19																			
Manual CAN20		None Low	High	Panic			Crash	Yes	No	Monitoring ~	~	Manual CAN20																			
Manual CAN21		None Low	High	Panic			Crash	Yes	No	Monitoring ~	, v	Manual CAN21																			

- The AVL ID list of Manual CAN parameters can be found in here.
- Full Manual CAN and Manual CAN Settings description can be found in <u>here</u>.
- Example on how to configure Manual CAN functionality can be found in <u>here</u>.

## Manual J1939

CAN Protocol	
CAN Protocol	2
None	Bosch
Askoll	Default J1939
Manual CAN	Manual J1939

Manual J1939 protocol support was added to TFT100 device's firmware as an addition to Default

**J1939** protocol in case the given **Default J1939** I/O elements are not enough. With this functionality, the user is able to configure which **J1939** parameters he would like to read from the transport that uses **J1939** protocol. **Manual J1939** protocol is enabled by selecting **Manual J1939** parameter in *CAN Protocol* field as shown in the image on the right hand side. Then user can configure CAN parameters in <u>Manual CAN Settings</u> tab.

```
Manual J1939
can be tested
NOTE! on FW
55.00.09.rev.08
or newer
```

To read data with this functionality, the user must have:

- TFT100 device with CAN interface;
- 55.00.09.Rev.08 or newer firmware;
- Machinery with CAN interface, which communicates via J1939 protocol;
- Machinery's J1939 protocol documentation (with required SPN's and PGN's).

#### Manual J1939 I/O

Up to 29 I/O parameters (Priority, Event Only, Operand, Send SMS To, SMS text) for **Manual J1939** functionality can be configured in CAN I/O tab the same way as for **Manual CAN** functionality.

	It is
	important
	to not
	forget that
	<u>Manual</u>
NOTE!	<u>CAN</u>
	<u>Settings</u>
	tab <b>must</b>
	be
	configured
	as well.

Children														
Input Name	Units	Priority				Low Level	High Level	Event O	nly		Operand	Send SMS To	SMS Text	
Manual CAN0		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	Ý	Manual CAN0	
Manual CAN1		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN1	
Manual CAN2		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN2	₽
Manual CAN3		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN3	
Manual CAN4		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN4	
Manual CAN5		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN5	
Manual CAN6		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN6	
Manual CAN7		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN7	
Manual CAN8		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸 🗸	Ý	Manual CAN8	
Manual CAN9		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN9	
Manual CAN10		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN10	
Manual CAN11		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN11	
Manual CAN12		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN12	
Manual CAN13		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN13	
Manual CAN14		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN14	
Manual CAN15		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN15	
Manual CAN16		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN16	
Manual CAN17		None	Low	High	Panic			Crash	Yes	No	Monitoring 🗸	~	Manual CAN17	
Manual CAN18		None		High	Panic			Crash	Yes	No	Monitoring ~	~	Manual CAN18	

### FLEX

×

The FLEX protocol is enabled by selecting FLEX parameter in CAN Protocol field.

#### FLEX I/O

Specific **FLEX** I/O parameters were implemented to our device's firmware that can be read, configured and sent to the server just like regular I/O parameters.

• 7	Гhе	AVL	ID	list	of	FLEX	parameters	can	be	found	in	<u>here</u> .
-----	-----	-----	----	------	----	------	------------	-----	----	-------	----	---------------

CAN VO													
Input Name	Units	s Priority				Low Level	High Level	Event Only			Operand	Send SMS To	SMS Text
Throttle Position	%	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring ~	~	Throttle Position
Brake Pressed		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Brake Pressed
Charge Plugged		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Charger Plugged
Kill Switch Active		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Kill Switch Active
Kickstand Release Status		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Kickstand Release Status
Powertrain State		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Powertrain State
Malfunction Indication		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Malfunction Indication
Estimated Range	km	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Estimated Range
SoC Battery	%	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	SoC Battery
Remaining Capacity	Ah	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Remaining Capacity
Full Charge Capacity	Ah	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Full Charge Capacity
Drive Mode		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Drive Mode
Total Distance	km	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Total Distance
Vehicle Speed	km/h	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Vehicle Speed
Ignition Status		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Ignition Status
Top Case sensor		None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Top Case Sensor
Max Available Power	w	None	Low	High	Panic	0 🗘	0 🗘	Crash	Yes	No	Monitoring 🗸	~	Max Available Power
Handlebar Lock		None	Low	High	Panic	0 0	0 🗘	Crash	Yes	No	Monitoring ~	~	Handlebar Lock

#### Debug

#### ×

Debug Protocol is used to read all incoming message through CAN, it works as a CAN reader. By default it will print incoming messages into Terminal, including CAN ID and Data.

#### ×

When the DEBUG protocol is selected, CAN Log option will appear.

By Enabling CAN Log parameter it will store CAN received data and CAN ID in a file.



To download saved file go to Status Tab and Maintenance section, press "Dump" button.

GNSS Info	GSM	Info	I/O Info		Maintenanc	e		
د Log / Dum	o ——				DOUT			
Log					DOUT 1	OFF	OFF	
Dump	þ	Open directory			DOUT 2	OFF	OFF	
Accelerome	eter —	1						
Read								

After downloading, follow **"Open directory"** button. After unzipping file there will be CAN folder with "0.log" file. Maximum file size is 5MB. After exceeding limit it will rewrite data.

## J1939 Settings

×

Some J1939 PGN's are not sent periodically, so they must be requested. In order to request PGN device must be registered to J1939 network. To register device user should configure **J1939** Source Address and **J1939 Name** parameters:

• **J1939 Source Address** parameter is used to set TFT source address on J1939 network. If device with selected source address already exists on network, user should change it to another address which might be free, or PGN's which must be requested will not be received.

• J1939 Name parameter is used to set TFT name on J1939 network.

## CAN I/O reset

## \* This parameter is available only with FW 55.01.10.Rev.00 or newer

If CAN IO reset parameter configured as 0 it will keep captured CAN data, otherwise if data is not received anymore it will reset I/Os after configured timeout.

Possible values (in seconds):

**0** - Data will not be cleaned. If external power is removed it will still keep the value.

**1-3600** - Data will be cleaned within timeout period if no more data is received or external power removed.

CAN IO resets in any case after NOTE! device restart or CAN Protocol switching.

×

#### I/O reset description

- **Disabled** All I/O's will be reset, when no CAN data received in at least one of I/O's.
- Enabled Only I/O's with Reset timeout \*\* parameter enabled (in Manual CAN Settings

section) and which received no data will be reset.