FMA delkey

delkey

Deletes device current configuration keyword.
Example: "delkey"