
FMB002 Manual Geofence settings

FMB002 has 50 configurable Geofence zones and it can generate an event when a defined Geofence zone border is crossed. *Frame border* is an additional border around Geofence zone used to prevent false events when object stops on the border of the area and as a result records are made inside and outside the defined area because of GNSS errors. The event is generated only when both (Geofence and frame) borders are crossed. See figure to the right for details: blue track is considered to have entered the area whereas red track is not.
Shape can be a rectangle or a circle as defined by the user.
Priority of Geofence event is categorized into Low, High or Panic levels. These levels define the priority of event information that is sent to the server. For more details about priorities look in I/O settings section.
Generate event allows to choose when record will be generated.
Eventual records controls where scenario status value appears: when disabled it will exist in each AVL record and when enabled the value will be appended only to eventual records.
OverSpeeding helps to configure OverSpeeding scenarios separately for each different *Geozone*. Regular OverSpeeding and geozones' OverSpeeding function independently. If digital output control is enabled in a regular OverSpeeding scenario, geozones OverSpeeding scenario will control it too i.e when the device is in more than one geozone and OverSpeeding is detected in any zone then the digital output turns on. Digital output turns off only when OverSpeeding is not detected anywhere.

X1 is used to set geofence zone left bottom corner X coordinate (longitude) whereas *Y1* is used to set Y coordinate (latitude).
X2 or *R* are used to set accordingly geofence zone upper right corner X coordinate (longitude) when Rectangular zone is used or circle radius when Circular zone is used. *Y2* sets geofence zone upper right corner Y coordinate (latitude) for a Rectangular zone.


Teltonika.Configurator v1.5.5.29406
TELTONIKA
Load from file
Save to file
Device not connected
Device type: FMB125
Configuration: 7.1.1.0
Security
System
GPRS
Data Acquisition
SMS \ Call Settings
GSM Operators
Features
Accelerometer Features
Auto Geofence
Manual Geofence
Trip \ Odometer
Bluetooth
Bluetooth 4.0
Beacon List
1-Wire
I/O
OBD II
CAN Adapter
RS232 \ RS485
Manual geofence selection
1 geozone
Manual geofence 1
Feature
Disable
Low Priority
High Priority
Panic Priority
Generate Event
No Event
On Exit
On Entrance
On Both
Eventual Records
Disable
Enable
Frame Border (m)
1
Shape Type
Circle
Rectangle
Radius (m)
5
Latitude (Y1)
0,0
Longitude (X1)
0,0
Overspeeding
Disable
Enable
Max Allowed Speed (km/h)
90
Send SMS To
SMS Text
Geozone Zone 1
Vilnius
54° 44' 29,29'' N 25° 15' 9,62'' E
© OpenStreetMap contributors