

# FMB125 Configuration

[Main Page](#) > [Professional Trackers](#) > [FMB125](#) > **FMB125 Configuration**

## **Teltonika Configurator**

- [Status info](#) [Show more]
  - [Device Info](#)
  - [GNSS Info](#)
  - [GSM Info](#)
  - [I/O Info](#)
  - [FMS I/O Info](#)
  - [Tachograph Data Info](#)
  - [Maintenance](#)
  - [OBD Info](#)
  - [CAN Adapter Info](#)
  
- [Security info](#)
- [System settings](#) [Show more]
  - [System](#)
  - [Static Navigation Settings](#)
  - [Sleep Mode](#)
  
- [GPRS settings](#) [Show more]
  - [GPRS Settings](#)
  - [FOTA WEB settings](#)
  
- [Data acquisition settings](#)
- [SMS settings](#) [Show more]
  - [SMS Data Sending](#)
  - [SMS commands](#)

- [GSM Operators settings](#)
- [Features](#) **[Show more]**
  - [Green Driving](#)
  - [Over Speeding](#)
  - [Jamming](#)
  - [Using authorized numbers to control DOUT via call](#)
  - [Immobilizer](#)
  - [iButton read notification](#)
  - [GNSS Fuel Counter](#)

- [Accelerometer Features](#) **[Show more]**

- [Excessive Idling](#)
- [Unplug Detection](#)
- [Towing Detection](#)
- [Crash Detection](#)
- [Crash Data Visualisation](#)

- [Auto Geofence settings](#)
- [Manual Geofence settings](#)
- [Trip/Odometer settings](#) **[Show more]**

- [Trip Settings](#)
- [Advanced Trip Settings](#)
- [Odometer](#)

- [Bluetooth® settings](#) **[Show more]**

- [General functionality](#)
- [Auto Connect to External Device](#)

- [Bluetooth® 4.0 settings](#)
- [1-Wire](#)
- [Beacon List](#)
- [I/O settings](#) **[Show more]**

- [Input Name](#)
  - [Current Value](#)
  - [Units](#)
  - [Priority](#)
  - [High and Low Level](#)
  - [Event Only](#)
  - [Operands](#)
  - [Avg Const](#)
  - [Send SMS To](#)
  - [SMS Text](#)
- 
- [SMS events](#)
  - [CAN Adapter](#)
  - [RS-232 and RS-485](#)