FMB630 External Devices

External Devices do not depend on selected profile; they are common for all profiles. To configure these parameters choose the TAB named “External Devices” and make all necessary changes.

Parameter Name	Parameter description
FMS/Tachograph Settings	**Are used to configure CAN line and Tachograph setting such as Enable/Disable, baudrate, operation mode, tachograph ignition source, tachograph type.**
Tacho Web	**User can enable Web DDD synchronization functionality; enter tacho web server domain and port.User can enable Web DDD synchronization functionality; enter tacho web server domain and port.**
Tacho Web start delay	**When ignition is on Tacho web starts after this delay.**
Analog Input Settings	**User can change the range of analog inputs. There are two possible changes: 10 V (0-10 V) and 30 V (0-30 V).**
COM1 and COM2 Settings	**Configures COM1 and COM2 ports. User can configure baudrate, working mode, enable/disable timestamp and change CMD ID(used to identify from which COM port data came)**
COM start/end byte	**COM1 and COM2 start and end byte are filter for TCP Binary link mode.**
RS485 Settings(COM1)	**Configures RS485 settings such as activation of RS485 protocol, baudrate and working mode.**
LLS Sensor Settings	**Allows user to set LLS sensors addresses in preffered order**