FMM00A Teltonika Data Sending Parameters ID

Document updated according firmware FMB.Ver.03.29.00 and newer.

FMB AVL ID's consist of these **parameters groups**:

□

Contents

- 1 Permanent I/O elements
- 2 Eventual I/O elements
- 3 OBD elements
- 4 OBD OEM elements
- 5 BLE Sensors I/O elements
- 6 CAN adapters elements

Permanent I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
239	Ignition	1	Unsigned	0	1	-	-	0 – Ignition Off 1 – Ignition On	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements

240	Movement	1	Unsigned	0	1	-	-	0 – Movement Off 1 – Movement On	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
80	Data Mode	1	Unsigned	0	5	-	-	0 – Home On Stop 1 – Home On Moving 2 – Roaming On Stop 3 – Roaming On Moving 4 – Unknown On Stop 5 – Unknown On Moving	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements

21	GSM Signal	1	Unsigned	0	5	-	-	Value in range 1-5	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements
200	Sleep Mode	1	Unsigned	0	4	-	-	0 - No Sleep 1 – GPS Sleep 2 – Deep Sleep 3 – Online Sleep 4 - Ultra Sleep	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements

69	GNSS Status	1	Unsigned	0	3	-	-	0 - GNSS OFF 1 – GNSS ON with fix 2 - GNSS ON without fix 3 - GNSS sleep	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements
181	GNSS PDOP	2	Unsigned	0	500	0.1		Coefficient, calculation formula	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements

182	GNSS HDOP	2	Unsigned	0	500	0.1		Coefficient, calculation formula	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O Elements
66	External Voltage	2	Unsigned	0	65535	0.001	V	Voltage	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements

24	Speed	2	Unsigned	0	350	-	km/h	GNSS Speed	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
205	GSM Cell ID	2	Unsigned	0	65535	-	-	GSM base station ID	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements

206	GSM Area Code	2	Unsigned	0	65535	-	-	Location Area code (LAC), it depends on GSM operator. It provides unique number which assigned to a set of base GSM stations.	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
67	Battery Voltage	2	Unsigned	0	65535	0.001	V	Voltage	FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Permanent I/O elements

68	Battery Current	2	Unsigned	0	65535	0.001	A	Current	FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMC800 FMM800 FMM80A	Permanent I/O elements
241	Active GSM Operator	4	Unsigned	0	4294967295	-	-	Currently used GSM Operator code	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements

199	Trip Odometer	4	Unsigned	0	2147483647	-	m	Trip Odometer value	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
16	Total Odometer	4	Unsigned	0	2147483647	-	-	Total Odometer value in meters	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements

1	Digital Input 1	1	Unsigned	0	1	-	-	Logic: 0/1		FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	Permanent I/O elements
9	Analog Input 1	2	Unsigned	0	65535	0.001	V	Voltage		FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	Permanent I/O elements
179	Digital Output 1	1	Unsigned	0	1	-	-	Logic: 0/1		FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	Permanent I/O elements

12	Fuel Used GPS	4	Unsigned	0	4294967295	0.001	l	Fuel Used	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Permanent I/O elements
13	Fuel Rate GPS	2	Unsigned	0	32767	0.01	l/100km	Average Fuel Use	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Permanent I/O elements

17	Axis X	2	Signed	-8000	8000	-	mG	X axis value	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
18	Axis Y	2	Signed	-8000	8000	-	mG	Y axis value	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements

19	Axis Z	2	Signed	-8000	8000	-	mG	Z axis value	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
11	ICCID1	8	Unsigned	0	0xffffffffffffffff	-	-	Value of SIM ICCID, MSB	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements

10	SD Status	1	Unsigned	0	1	-	-	0 - not present 1 - present	FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100	Permanent I/O elements
2	Digital Input 2	1	Unsigned	0	1	-	-	Logic: 0/1	FMBXXX FMB900 FMB910 FMB920 FMC920 FMM920 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB202 FMB204 FMB206 FMB640	Permanent I/O elements
3	Digital Input 3	1	Unsigned	0	1	-	-	Logic: 0/1	FMBXXX FMB110 FMB120 FMB122 FMB140 FMB150 FMC150 FMM150 FMB202 FMB204 FMB206 FMB640	Permanent I/O elements
6	Analog Input 2	2	Unsigned	0	65535	0.001	V	Voltage	FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM130 FMB140	Permanent I/O elements

180	Digital Output 2	1	Unsigned	0	1	-	-	Logic 0/1	FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB202 FMB204 FMB206	Permanent I/O elements
72	Dallas Temperature 1	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 – Sensor not ready if 2000 – Value read error if 3000 – Not connected if 4000 – ID failed if 5000 – same as 850	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
73	Dallas Temperature 2	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 – Sensor not ready if 2000 – Value read error if 3000 – Not connected if 4000 – ID failed if 5000 – same as 850	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
74	Dallas Temperature 3	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 – Sensor not ready if 2000 – Value read error if 3000 – Not connected if 4000 – ID failed if 5000 – same as 850	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements

75	Dallas Temperature 4	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 – Sensor not ready if 2000 – Value read error if 3000 – Not connected if 4000 – ID failed if 5000 – same as 850	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
76	Dallas Temperature ID 1	8	Unsigned	0	0xffffffffffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
77	Dallas Temperature ID 2	8	Unsigned	0	0xffffffffffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
79	Dallas Temperature ID 3	8	Unsigned	0	0xffffffffffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements

71	Dallas Temperature ID 4	8	Unsigned	0	0xffffffffffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
78	iButton	8	Unsigned	0	0xffffffffffffffff	-	-	iButton ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FMU130 FMC130 FMM130 FMB202 FMB204 FMB206	Permanent I/O elements
207	RFID	8	Unsigned	0	0xffffffffffffffff	-	-	RFID ID	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
201	LLS 1 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS232/RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
202	LLS 1 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS232/RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
203	LLS 2 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
204	LLS 2 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
210	LLS 3 Fuel Level	2	Unsigned	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
211	LLS 3 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements

212	LLS 4 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
213	LLS 4 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
214	LLS 5 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
215	LLS 5 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
15	Eco Score	2	Unsigned	0	65535	0.01	-	Average amount of events on some distance	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Permanent I/O elements
113	Battery Level	1	Unsigned	0	100	-	%	Battery capacity level	FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Permanent I/O elements

238	User ID	8	Unsigned	0	0xffffffffffffffff	-	-	MAC address of NMEA receiver device connected via Bluetooth	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMU125 FMU130 FMC800 FMM800 FMM80A	Permanent I/O elements
237	Network Type	1	Unsigned	0	1	-	-	0 - 3G 1 - GSM 2 - 4G 3 - LTE CAT M1 4 - LTE CAT NB1 99 - Unknown	FMBXXX FM3001 FMU125 FMU126 FMU130 FMC125 FMC130 FMC150 FMM125 FMM130 FMM150 FMC001 FMM001 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements
4	Pulse Counter Din1	4	Unsigned	0	4294967295	-	-	Counts pulses, count is reset when records are saved	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	Permanent I/O elements

5	Pulse Counter Din2	4	Unsigned	0	4294967295	-	-	Counts pulses, count is reset when records are saved	FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM130	Permanent I/O elements
263	BT Status	1	Unsigned	0	4	-	-	0 - BT is disabled 1 - BT Enabled, not device connected 2 - Device connected, BTv3 Only 3 - Device connected, BLE only 4 - Device connected, BLE + BT	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Permanent I/O elements
264	Barcode ID	Variable	ASCII	0	32	-	-	Barcode ID	FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100	

303	Instant Movement	1	Unsigned	0	1	-	-	Logic: 0/1 returns movement value	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100	Permanent I/O elements
327	UL202-02 Sensor Fuel level	2	Signed	-150	32767	0.1	mm	UL202-02 Sensor Fuel level	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
483	UL202-02 Sensor Status	1	Unsigned	0	255	-	-	UL202-02 sensor status codes	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
380	Digital output 3	1	Unsigned	0	1	-	-	Logic: 0/1	FMBXXX FMB130 FMU130 FMC130 FMC150 FMM130	Permanent I/O elements
381	Ground Sense	1	Unsigned	0	1	-	-	Logic: 0/1	FMB130 FMU130 FMC130 FMM130 FMB140	Permanent I/O elements

387	ISO6709 Coordinates	34	HEX	0	0x7fffff ffffffffff	-	-	ISO6709 Coordinates Latitude, Longitude (in Degrees, Minutes and Seconds) and Altitude: IO value format: ±DDMMSS.SSSS±DDDMMSS.SSSS±AAA.AAA/	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Permanent I/O elements
636	UMTS/LTE Cell ID	4	Unsigned	0	0xFFF FFFFF	-	-		FMBXXX FMU125 FMU126 FMU130 FMC001 FMC125 FMC130 FMM001 FMM125 FMM130 FMC150 FMM150 FMC800 FMM800 FMM80A	Permanent I/O elements
403	Driver Name	35	Unsigned	-	-	-	-	Driver name extracted from card, displayed without delimiters ($ signs)	FMBXXX FMU126	Permanent I/O elements
404	Driver card license type	1	Unsigned	0	8	-	-	None - 0 B.1 license type - 1 B.2 license type - 2 B.3 license type - 3 B.4 license type - 4 T.1 license type - 5 T.2 license type - 6 T.3 license type - 7 T.4 license type - 8	FMBXXX FMU126	Permanent I/O elements
405	Driver Gender	1	Unsigned	0	2	-	-	None - 0 Male - 1 Female - 2	FMBXXX FMU126	Permanent I/O elements
406	Driver Card ID	4	Unsigned	0	4294967295	-	-	None - 0 Male - 1 Female - 2	FMBXXX FMU126	Permanent I/O elements
407	Driver card expiration date	1	Unsigned	0	9999	-	-		FMBXXX FMU126	Permanent I/O elements
408	Driver Card place of issue	4	Unsigned	0	65535	-	-	Extracted from card	FMBXXX FMU126	Permanent I/O Elements
409	Driver Status Event	1	Unsigned	0	2	-	-	Registered - 0 Deregistered - 1 Swapping - 2	FMBXXX FMU126	Permanent I/O elements

329	AIN Speed	2	Unsigned	0	65535	-	-		MSP500	Permanent I/O elements
500	MSP500 vendor name	40	ASCII	0	40	-	-	Name of the integrator who installed the device	MSP500	Permanent I/O elements
501	MSP500 vehicle number	40	ASCII	0	40	-	-	Vehicle number on which the device is installed	MSP500	Permanent I/O elements
502	MSP500 speed sensor	1	unsigned	0	1	-	-	Status of the speed sensor	MSP500	Permanent I/O elements
637	Wake Reason	1	Unsigned	0	1	-	-	True if device was woken by RTC alarm	FMB965	Permanent I/O elements
10800	EYE Temperature 1	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10801	EYE Temperature 2	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10802	EYE Temperature 3	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10803	EYE Temperature 4	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10804	EYE Humidity 1	1	Unsigned	0	100	-	%	Humidity measured by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10805	EYE Humidity 2	1	Unsigned	0	100	-	%	Humidity measured by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10806	EYE Humidity 3	1	Unsigned	0	100	-	%	Humidity measured by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10807	EYE Humidity 4	1	Unsigned	0	100	-	%	Humidity measured by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10808	EYE Magnet 1	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10809	EYE Magnet 2	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10810	EYE Magnet 3	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10811	EYE Magnet 4	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10812	EYE Movement 1	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10813	EYE Movement 2	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10814	EYE Movement 3	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10815	EYE Movement 4	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10816	EYE Pitch 1	1	Signed	-90	90	-	-	Pitch angle measured by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10817	EYE Pitch 2	1	Signed	-90	90	-	-	Pitch angle measured by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10818	EYE Pitch 3	1	Signed	-90	90	-	-	Pitch angle measured by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10819	EYE Pitch 4	1	Signed	-90	90	-	-	Pitch angle measured by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10820	EYE Low Battery 1	1	Unsigned	0	1	-	-	Low Battery indication for EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10821	EYE Low Battery 2	1	Unsigned	0	1	-	-	Low Battery indication for EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10822	EYE Low Battery 3	1	Unsigned	0	1	-	-	Low Battery indication for EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10823	EYE Low Battery 4	1	Unsigned	0	1	-	-	Low Battery indication for EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10824	EYE Battery Voltage 1	1	Unsigned	0	0xFF	-	-	Battery Voltage of EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10825	EYE Battery Voltage 2	1	Unsigned	0	0xFF	-	-	Battery Voltage of EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10826	EYE Battery Voltage 3	1	Unsigned	0	0xFF	-	-	Battery Voltage of EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10827	EYE Battery Voltage 4	1	Unsigned	0	0xFF	-	-	Battery Voltage of EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10832	EYE Roll 1	2	Signed	-180	180	-	-	Roll angle measured by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10833	EYE Roll 2	2	Signed	-180	180	-	-	Roll angle measured by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10834	EYE Roll 3	2	Signed	-180	180	-	-	Roll angle measured by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10835	EYE Roll 4	2	Signed	-180	180	-	-	Roll angle measured by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10836	EYE Movement count 1	2	Unsigned	0	32767	-	-	Movement count measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10837	EYE Movement count 2	2	Unsigned	0	32767	-	-	Movement count measure by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10838	EYE Movement count 3	2	Unsigned	0	32767	-	-	Movement count measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10839	EYE Movement count 4	2	Unsigned	0	32767	-	-	Movement count measure by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10840	EYE Magnet count 1	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10841	EYE Magnet count 2	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10842	EYE Magnet count 3	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

10843	EYE Magnet count 4	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910	Permanent I/O elements

383	AXL Calibration Status	1	Unsigned	0	3	-	-	Shows calibration status: 0- no calibration, 1- calibrated, 2- not configured, 3- fully calibrated	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 FMB910 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

451	BLE RFID #1	8	HEX	0	0xffffffffffffffff	-	-	BLE NBL-T RFID ID for Connetionless mode #1 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

452	BLE RFID #2	8	HEX	0	0xffffffffffffffff	-	-	BLE NBL-T RFID ID for Connetionless mode #2 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

453	BLE RFID #3	8	HEX	0	0xffffffffffffffff	-	-	BLE NBL-T RFID ID for Connetionless mode #3 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

454	BLE RFID #4	8	HEX	0	0xffffffffffffffff	-	-	BLE NBL-T RFID ID for Connetionless mode #4 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

455	BLE Button 1 state #1	1	Unsigned	0	1	-	-	BLE NBL-T Button 1 status for Connetionless mode #1 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

456	BLE Button 1 state #2	1	Unsigned	0	1	-	-	BLE NBL-T Button 1 status for Connetionless mode #2 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

457	BLE Button 1 state #3	1	Unsigned	0	1	-	-	BLE NBL-T Button 1 status for Connetionless mode #3 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

458	BLE Button 1 state #4	1	Unsigned	0	1	-	-	BLE NBL-T Button 1 status for Connetionless mode #4 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

459	BLE Button 2 state #1	1	Unsigned	0	1	-	-	BLE NBL-T Button 2 status for Connetionless mode #1 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

460	BLE Button 2 state #2	1	Unsigned	0	1	-	-	BLE NBL-T Button 2 status for Connetionless mode #2 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

461	BLE Button 2 state #3	1	Unsigned	0	1	-	-	BLE NBL-T Button 2 status for Connetionless mode #3 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

462	BLE Button 2 state #4	1	Unsigned	0	1	-	-	BLE NBL-T Button 2 status for Connetionless mode #4 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

622	Frequency DIN1	2	Unsigned	0	65535	0.1	Hz	Frequency of input signal present on DIN1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

623	Frequency DIN2	2	Unsigned	0	65535	0.1	Hz	Frequency of input signal present on DIN2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements

Eventual I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max				FMBXXX FMB001 FMC001 FMB010 FMB003 FMB020 FMB001 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC130 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 TMT250 MSP500 FMC800 FMM800 FMM80A	
155	Geofence zone 01	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start		Eventual I/O elements

156	Geofence zone 02	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
157	Geofence zone 03	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
158	Geofence zone 04	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
159	Geofence zone 05	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
61	Geofence zone 06	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
62	Geofence zone 07	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
63	Geofence zone 08	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
64	Geofence zone 09	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
65	Geofence zone 10	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB930 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements

70	Geofence zone 11	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
88	Geofence zone 12	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
91	Geofence zone 13	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
92	Geofence zone 14	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
93	Geofence zone 15	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
94	Geofence zone 16	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
95	Geofence zone 17	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
96	Geofence zone 18	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements
97	Geofence zone 19	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC900 FM4800 FM4804	Eventual I/O elements

98	Geofence zone 20	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
99	Geofence zone 21	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
153	Geofence zone 22	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
154	Geofence zone 23	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
190	Geofence zone 24	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
191	Geofence zone 25	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
192	Geofence zone 26	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
193	Geofence zone 27	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements
194	Geofence zone 28	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FM4800 FM4804	Eventual I/O elements

195	Geofence zone 29	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB123 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
196	Geofence zone 30	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
197	Geofence zone 31	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
198	Geofence zone 32	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
208	Geofence zone 33	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
209	Geofence zone 34	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
216	Geofence zone 35	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
217	Geofence zone 36	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements
218	Geofence zone 37	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB062 FMB064 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM004	Eventual I/O elements

219	Geofence zone 38	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
220	Geofence zone 39	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
221	Geofence zone 40	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
222	Geofence zone 41	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
223	Geofence zone 42	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
224	Geofence zone 43	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
225	Geofence zone 44	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
226	Geofence zone 45	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements
227	Geofence zone 46	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX FM8001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FM1125 FMB140 FMB150 FMC150 FM4150 FMB000 FMB020 FMB962 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM000 FMM80A	Eventual I/O elements

228	Geofence zone 47	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX [FMB001](#) [FMC001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [MSP500](#) [FMC800](#) [FMM480](#) [FMM484](#)	Eventual I/O elements
229	Geofence zone 48	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX [FMB001](#) [FMC001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [MSP500](#) [FMC800](#) [FMM480](#) [FMM484](#)	Eventual I/O elements
230	Geofence zone 49	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX [FMB001](#) [FMC001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [MSP500](#) [FMC800](#) [FMM480](#) [FMM484](#)	Eventual I/O elements
231	Geofence zone 50	1	Unsigned	0	3	-	-	0 – target left zone 1 – target entered zone 2 – over speeding end 3 – over speeding start	FMBXXX [FMB001](#) [FMC001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [MSP500](#) [FMC800](#) [FMM480](#) [FMM484](#)	Eventual I/O elements
175	Auto Geofence	1	Unsigned	0	1	-	-	0 – target left zone 1 – target entered zone	FMBXXX [FMB001](#) [FMC001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [MSP500](#) [FMC800](#) [FMM480](#) [FMM484](#)	Eventual I/O elements
250	Trip	1	Unsigned	0	1	-	-	0 – trip stop 1 – trip start From 01.00.24 fw version available with BT app new values: 2 – Business Status 3 – Private Status 4-9 – Custom Statuses	FMBXXX [FMB001](#) [FMC001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [MSP500](#) [FMC800](#) [FMM480](#) [FMM484](#)	Eventual I/O elements
255	Over Speeding	1	Unsigned	0	255	-	km/h	At over speeding start km/h, at over speeding end km/h	FMBXXX [FMB001](#) [FMB010](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMM125](#) [FMB130](#) [FMC530](#) [FM4530](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB920](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#)	Eventual I/O elements
257	Crash trace data	Variable	HEX	0	1200	-	-	Crash trace data	FMBXXX [Expand] [FMB001](#) [FMC001](#) [FMB010](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FM1125](#) [FMB130](#) [FMB140](#) [FMB150](#) [FMC530](#) [FMM150](#) [FMB930](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMB202](#) [FMB204](#) [FMB206](#) [FMT100](#) [MTB100](#) [FMP100](#) [FMC800](#) [FMC530](#) [FMM480](#) [FMM125](#) [FM4130](#) [FM1125](#) [FM3130](#) [FMC800](#) [FMM484](#)	Eventual I/O elements
285	Blood alcohol content	2	Unsigned	0	9999	-	-	Alcohol content in blood in perlims and mode. First 14 bits from MSB are perlims multiplied by 1000 and last to bits are 0 - Passive test, 1 Active test, 2 and 3 are reserved.	[FMB125](#)	Eventual I/O elements

251	Idling	1	Unsigned	0	1	-	-	0 – moving 1 – idling	FMBXXX [Expand] FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FM3125 FM6300 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC900 FMC125 FMC130 FMM001 FMM125 FMM130 FMT175 FMU130 FMC800 FMM800 FMM80A	Eventual I/O elements
253	Green driving type	1	Unsigned	1	3	-	-	1 – harsh acceleration 2 – harsh braking 3 – harsh cornering	FMBXXX FM3001 FMB010 FMB110 FMB120 FMB122 FMB125 FM1125 FMC125 FMM125 FMB130 FM1130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Eventual I/O elements
246	Towing	1	Unsigned	0	1	-	-	0 – steady 1 – towing	FMBXXX FM3001 FMB014 FMB110 FMB120 FMB122 FMB123 FM1125 FMC125 FMM125 FMB130 FM1130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Eventual I/O elements
252	Unplug	1	Unsigned	0	1	-	-	0 – battery present 1 – battery unplugged	FMBXXX FM3001 FMC001 FMM001 FMB002 FMB003 FMB010 FMB020 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMB920 FMB962 FMB964 FMB202 FMB204 FMB208 FMB209 FMC125 FMM125 FM1125 FM1126 FMC130 FMM130 FM1130 MSP500 FMT100 FMP100 FMC800 FMM800 FMM80A	Eventual I/O elements
247	Crash detection	1	Unsigned	1	6	-	-	1 – real crash detected (device is calibrated) 2 – limited crash trace (device not calibrated) 3 – limited crash trace (device is calibrated) 4 – full crash trace (device not calibrated) 5 – full crash trace (device is calibrated) 6 – real crash detected (device not calibrated)	FMBXXX [Expand] FMB001 FMC800 FMB010 FMB110 FMB120 FMB122 FMB125 FM1125 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC900 FMC125 FMC130 FMM001 FMM125 FMM130 FM1125 FM1130 FMC800 FMM800 FMM80A	Eventual I/O elements
248	Immobilizer	1	Unsigned	0	2	-	-	0 – iButton not connected 1 – iButton connected (Immobilizer) 2 – iButton connected (Authorized Driving)	FMBXXX FMB110 FMB120 FMB122 FMB125 FM1125 FMC125 FMM125 FMB130 FMB140 FMB150 FMC150 FMM150 FM1130 FMC130 FMM130 FMB202 FMB204 FMB206	Eventual I/O elements
254	Green Driving Value	1	Unsigned	0	255	acc and braking: 0.01	G or rad	Depending on green driving type: if harsh acceleration or braking - g*100 (value 123 -> 1.23g). If Green driving source is „GPS" - harsh cornering value is rad/s*100. If source is „Accelerometer" - g*100.	FMBXXX FM3001 FMB010 FMB110 FMB120 FMB122 FMB125 FM1125 FMC125 FMM125 FMB130 FM1130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMM80A	Eventual I/O elements
249	Jamming	1	Unsigned	0	1	-	-	0 – jamming stop 1 – jamming start	FMBXXX FM3001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB123 FMB130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB002 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Eventual I/O elements
14	ICCID2	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Value of SIM ICCID, LSB	FMBXXX FM3001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB123 FMB125 FM1125 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 FMM80A	Eventual I/O elements

									FMBXXX (Expand) FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMC300 FMM640 FMM840A	
243	Green driving event duration	2	Unsigned	0	65535	-	ms	Duration of event that did generate Green driving	FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC300 FMC125 FMC130 FMM601 FMM125 FMM130 FMT175 FMU130 FMC800 FMM800 FMM80A	Eventual I/O elements
236	Alarm	1	Unsigned	0	1	-	-	0 - Reserved 1 - Alarm event occured		Eventual I/O elements
258	EcoMaximum	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Element stores maximum accelerometer values in mg on all axis during Eco driving event 8 Bytes: 2B Zeros 2B - X axis 2B - Y axis 2B - Z axis	FMT100	Eventual I/O elements
259	EcoAverage	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Element stores average accelerometer values in mg on all axis during Eco driving event 8 Bytes: 2B Zeros 2B - X axis 2B - Y axis 2B - Z axis	FMT100	Eventual I/O elements
260	EcoDuration	2	Unsigned	0	65535	-	ms	Duration of Eco driving event in milliseconds	FMT100	Eventual I/O elements
283	Driving State	1	Unsigned	0	3	-	-	1 - Ignition ON 2 - Driving 3 - Ignition OFF	FMT100	Eventual I/O elements
284	Driving Records	2	Unsigned	0	65535	-	-	Number of Records between Ignition ON and Ignition OFF	FMT100	Eventual I/O elements
391	Private mode	1	Unsigned	0	255	-	-	Private mode state 0 - Private mode off 1 - Private mode on	FMBXXX FM3001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	Eventual I/O elements
317	Crash event counter	1	Unsigned	0	255	-	-	Connects trace with specific eventual crash record	FMBXXX FM3001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMC800 FMB202 FMB204 FMB206 FMT100 MTB100 FMC300 FMM800 FMM80A	Eventual I/O elements
449	Ignition On Counter	4	Unsigned	0	2147483647	-	s	Duration in seconds which is counted while Ignition state is On	FMBXXX FM3001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	Eventual I/O elements

OBD elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range Min	Value range Max	Multiplier	Units	Description	HW Support	Parameter Group
256	VIN	17	ASCII	0	0xff	-	-	VIN number	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

30	Number of DTC	1	Unsigned	0	255	-	-	Number of DTC	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
31	Engine Load	1	Unsigned	0	100	-	%	Calculated engine load value	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
32	Coolant Temperature	1	Signed	-128	127	-	°C	Engine coolant temperature	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
33	Short Fuel Trim	1	Signed	-100	99	-	%	Short term fuel trim 1	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

34	Fuel pressure	2	Unsigned	0	765	-	kPa	Fuel pressure	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
35	Intake MAP	1	Unsigned	0	255	-	kPa	Intake manifold absolute pressure	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
36	Engine RPM	2	Unsigned	0	16384	-	rpm	Engine RPM	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
37	Vehicle Speed	1	Unsigned	0	255	-	km/h	Vehicle speed	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

38	Timing Advance	1	Signed	-64	64	-	°	Timing advance	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
39	Intake Air Temperature	1	Signed	-128	127	-	°C	Intake air temperature	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
40	MAF	2	Unsigned	0	65535	0.01	g/sec	MAF air flow rate	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
41	Throttle Position	1	Unsigned	0	100	-	%	Throttle position	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

42	Runtime since engine start	2	Unsigned	0	65535	-	s	Runtime since engine start	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
43	Distance Traveled MIL On	2	Unsigned	0	65535	-	km	Distance ormattin MIL on	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
44	Relative Fuel Rail Pressure	2	Unsigned	0	5178	0.1	kPa	Relative fuel rail pressure	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
45	Direct Fuel Rail Pressure	2	Unsigned	0	65535	10	kPa	Direct Fuel Rail Pressure	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

46	Commanded EGR	1	Unsigned	0	100	-	%	Commanded EGR	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
47	EGR Error	1	Signed	-100	100	-	%	EGR error	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
48	Fuel Level	1	Unsigned	0	100	-	%	Fuel level	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
49	Distance Since Codes Clear	2	Unsigned	0	65535	-	km	Distance traveled since codes cleared	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

50	Barometic Pressure	1	Unsigned	0	255	-	kPa	Barometic pressure	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
51	Control Module Voltage	2	Unsigned	0	65535	0.001	V	Control module voltage	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
52	Absolute Load Value	2	Unsigned	0	25700	-	%	Absolute load value	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
759	Fuel Type	1	Unsigned	0	255	-	-	0 Not available 1 Gasoline 2 Methanol 3 Ethanol 4 Diesel 5 LPG 6 CNG 7 Propane 8 Electric 9 Bifuel running Gasoline 10 Bifuel running Methanol 11 Bifuel running Ethanol 12 Bifuel running LPG 13 Bifuel running CNG 14 Bifuel running Propane 15 Bifuel running Electricity 16 Bifuel running electric and combustion engine 17 Hybrid gasoline 18 Hybrid Ethanol 19 Hybrid Diesel 20 Hybrid Electric 21 Hybrid running electric and combustion engine 22 Hybrid Regenerative 23 Bifuel running diesel	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

53	Ambient Air Temperature	1	Signed	-128	127	-	°C	Ambient air temperature	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
54	Time Run With MIL On	2	Unsigned	0	65535	-	min	Time run with MIL on	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
55	Time Since Codes Cleared	2	Unsigned	0	65535	-	min	Time since codes cleared	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
56	Absolute Fuel Rail Pressure	2	Unsigned	0	65535	0.1	kPa	Absolute fuel rail pressure	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

57	Hybrid battery pack life	1	Unsigned	0	100	-	%	Hybrid battery pack remaining life	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
58	Engine Oil Temperature	1	Unsigned	0	215	-	°C	Engine oil temperature	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
59	Fuel injection timing	2	Signed	-21000	30200	0.01	°	Fuel injection timing	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
540	Throttle position group	1	Unsigned	0	100	–	%	Throttle Position Value From PID Group	FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements
541	Commanded Equivalence R	1	Unsigned	0	200	0.01	-	Fuel-Air Commanded Equivalence Ratio	FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements
542	Intake MAP 2 bytes	2	Unsigned	0	2048	-	kPa	Intake Manifold Absolute Pressure	FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements

543	Hybrid System Voltage	2	Unsigned	0	1024	-	V	Hybrid vehicle system voltage	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
544	Hybrid System Current	2	Signed	-3277	3277	-	A	Hybrid vehicle system current	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
281	Fault Codes	variable	ASCII	0	128	-	-	Fault Codes (values separated via ",")	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
60	Fuel Rate	2	Unsigned	0	32767	0.01	L/h	Engine fuel rate, L/h*100	FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

OBD OEM elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
389	OBD OEM Total Mileage	4	Unsigned	0	0xffffffff	-	km	Total mileage received by requesting vehicle specific PID	FMB003	OBD OEM elements
390	OBD OEM Fuel Level	4	Unsigned	0	0xffffffff	0.1	l	Fuel level in litres received by requesting vehicle specific PID	FMB003	OBD OEM elements
402	OEM Distance Until Service	4	Unsigned	0	0xffffffff	-	km	Distance till next service received by requesting vehicle specific PID	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements
410	OEM Battery charge state	1	Unsigned	0	1	-	-	0 – Not charging 1 – Charging	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements
411	OEM Battery charge level	1	Unsigned	0	100	-	%	Represents battery charged level	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements
412	OEM Battery power consumption	2	Unsigned	0	65535	-	kWh/100km	Represents battery power consumption	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements
755	OEM Remaining distance	2	Unsigned	0	65535	-	km	Remaining distance until fuel tank empty or battery (EV) depleted	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements
1151	OEM Battery State Of Health	2	Unsigned	0	65535	-	%	Battery State of Health	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements
1152	OEM Battery Temperature	2	Signed	-32768	32767	-	°C	Battery pack temperature	FMB001 FMC001 FMM001 FMB003 FMC003 FMM003	OBD OEM elements

BLE Sensors I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					

385	Beacon	Variable	HEX	0	1024	-	-	List of Beacon IDs	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 FMC800 FMM800 FMM80A	Permanent I/O elements

548	Advanced BLE Beacon data	1024	HEX	0	1024	-	-	List of Beacon Ids and their data when advanced Beacon mode is selected	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 FMC800 FMM800 FMM80A	Eventual I/O elements

25	BLE Temperature #1	2	Signed	-4000	12500	0.01*	°C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

26	BLE Temperature #2	2	Signed	-4000	12500	0.01*	°C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

27	BLE Temperature #3	2	Signed	-4000	12500	0.01*	°C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

28	BLE Temperature #4	2	Signed	-4000	12500	0.01*	°C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

29	BLE Battery #1	1	Unsigned	0	100	-	%	Battery level of sensor #1	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

20	BLE Battery #2	1	Unsigned	0	100	-	%	Battery level of sensor #2	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

22	BLE Battery #3	1	Unsigned	0	100	-	%	Battery level of sensor #3	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

23	BLE Battery #4	1	Unsigned	0	100	-	%	Battery level of sensor #4	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

86	BLE Humidity #1	2	Unsigned	0	1000	0.1*	%RH	Humidity From firmware version 03.28.00 and up: 32735 - sensor not found 32734 - failed sensor data parsing 32733 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

104	BLE Humidity #2	2	Unsigned	0	1000	0.1*	%RH	Humidity From firmware version 03.28.00 and up: 32735 - sensor not found 32734 - failed sensor data parsing 32733 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

106	BLE Humidity #3	2	Unsigned	0	1000	0.1*	%RH	Humidity From firmware version 03.28.00 and up: 32735 - sensor not found 32734 - failed sensor data parsing 32733 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

108	BLE Humidity #4	2	Unsigned	0	1000	0.1*	%RH	Humidity From firmware version 03.28.00 and up: 32735 - sensor not found 32734 - failed sensor data parsing 32733 - abnormal sensor state	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

270	BLE Fuel Level #1	2	Unsigned	0	65535	-	-	Fuel Level	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

273	BLE Fuel Level #2	2	Unsigned	0	65535	-	-	Fuel Level	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

276	BLE Fuel Level #3	2	Unsigned	0	65535	-	-	Fuel Level	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

279	BLE Fuel Level #4	2	Unsigned	0	65535	-	-	Fuel Level	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

306	BLE Fuel Frequency #1	4	Unsigned	0	2147483647	-	-	Frequency value of BLE fuel sensor #1	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

307	BLE Fuel Frequency #2	4	Unsigned	0	2147483647	-	-	Frequency value of BLE fuel sensor #2	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

308	BLE Fuel Frequency #3	4	Unsigned	0	2147483647	-	-	Frequency value of BLE fuel sensor #3	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

309	BLE Fuel Frequency #4	4	Unsigned	0	2147483647	-	-	Frequency value of BLE fuel sensor #4	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

335	BLE Luminosity #1	2	Unsigned	0	0xFFFF	-	lx	Luminosity value of BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

336	BLE Luminosity #2	2	Unsigned	0	0xFFFF	-	lx	Luminosity value of BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

337	BLE Luminosity #3	2	Unsigned	0	0xFFFF	-	lx	Luminosity value of BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

338	BLE Luminosity #4	2	Unsigned	0	0xFFFF	-	lx	Luminosity value of BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

331	BLE 1 Custom #1	Variable	HEX	0	-	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

463	BLE 1 Custom #2	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

464	BLE 1 Custom #3	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

465	BLE 1 Custom #4	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

466	BLE 1 Custom #5	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

332	BLE 2 Custom #1	Variable	HEX	0	-	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

467	BLE 2 Custom #2	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

468	BLE 2 Custom #3	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

469	BLE 2 Custom #4	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

470	BLE 2 Custom #5	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

333	BLE 3 Custom #1	Variable	HEX	0	-	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

471	BLE 3 Custom #2	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

472	BLE 3 Custom #3	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

473	BLE 3 Custom #4	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

474	BLE 3 Custom #5	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

334	BLE 4 Custom #1	Variable	HEX	0	-	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

475	BLE 4 Custom #2	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

476	BLE 4 Custom #3	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

477	BLE 4 Custom #4	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

478	BLE 4 Custom #5	4	UNSIGNED LONG INT	0	4294967295	-	-	Custom IO element for BLE sensor	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy

CAN adapters elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
81	Vehicle Speed	1	Unsigned	0	255	-	km/h	Vehicle Speed	FMBXXX FMB110 FMB120 FMB122 FMB123 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
82	Accelerator Pedal Position	1	Unsigned	0	102	-	%	Value in percentages	FMBXXX FMB110 FMB120 FMB122 FMB123 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
83	Fuel Consumed	4	Unsigned	0	2147483647	0.1	l	Value in liters	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
84	Fuel Level	2	Unsigned	0	65535	0.1	l	Value in liters	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
85	Engine RPM	2	Unsigned	0	16384	-	rpm	Value in rounds per minute	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
87	Total Mileage	4	Unsigned	0	4294967295	-	m	Value in meters	FMBXXX FMB110 FMB120 FMB122 FMB123 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
89	Fuel level	1	Unsigned	0	100	-	%	Value in percentages	FMBXXX FMB110 FMB120 FMB122 FMB123 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
90	Door Status	2	Unsigned	0	16128	-	-	Door status value: Min - 0, Max - 16128 Door status is represented as bitmask converted to decimal value. Possible values: 0 - all doors closed 0x100 (256) - front left door is opened 0x200 (512) - front right door is opened 0x400 (1024) - rear left door is opened 0x800 (2048) - rear right door is opened 0x1000 (4096) - hood is opened 0x2000 (8192) - trunk is opened 0x3F00 (16128) - all doors are opened or combinations of values	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
100	Program Number	4	Unsigned	0	99999	-	-	Value: Min - 0, Max - 99999	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
101	Module ID 8B	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Module ID 8 Bytes	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
388	Module ID 17B	17	HEX	0	0x7FFFFFFFFFFFFFFFFF	-	-	Module ID 17 Bytes	FMBXXX FMB110 FMB120 FMB122 FMB124 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
102	Engine Worktime	4	Unsigned	0	1677215	-	min	Engine work time	FMBXXX FMB110 FMB120 FMB122 FMB123 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300, CANCONTROL
103	Engine Worktime (counted)	4	Unsigned	0	1677215	-	min	Total engine work time	FMBXXX FMB110 FMB120 FMB122 FMB123 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300, CANCONTROL
105	Total Mileage (counted)	4	Unsigned	0	4294967295	-	m	Total Vehicle Mileage	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
107	Fuel Consumed (counted)	4	Unsigned	0	2147483647	0.1	l	Total Fuel Consumed	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
110	Fuel Rate	2	Unsigned	0	32768	0.1	l/h	Fuel rate	FMBXXX FMB110 FMB120 FMB122 FMB125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
111	AdBlue Level	1	Unsigned	0	100	-	%	AdBlue	FMBXXX FMB110 FMB120 FMB122 FMB123 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300

112	AdBlue Level	2	Unsigned	0	65535	0.1	1	AdBlue level	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
114	Engine Load	1	Unsigned	0	130	-	%	Engine Load	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
115	Engine Temperature	2	Signed	-600	1270	0.1	°C	Engine Temperature	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, ALLCAN300, CANCONTROL
118	Axle 1 Load	2	Unsigned	0	32768	-	kg	Axle 1 load	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
119	Axle 2 Load	2	Unsigned	0	32768	-	kg	Axle 2 load	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
120	Axle 3 Load	2	Unsigned	0	32768	-	kg	Axle 3 load	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
121	Axle 4 Load	2	Unsigned	0	32768	-	kg	Axle 4 load	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
122	Axle 5 Load	2	Unsigned	0	32768	-	kg	Axle 5 load	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
123	Control State Flags	4	Unsigned	0	4294967295	-	-	Control state flags	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300, CANCONTROL
124	Agricultural Machinery Flags	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Agricultural machinery flags	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
125	Harvesting Time	4	Unsigned	0	16777215	-	min	Harvesting time	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
126	Area of Harvest	4	Unsigned	0	4294967295	-	m^2	Area of harvest in square meters	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
127	Mowing Efficiency	4	Unsigned	0	4294967295	-	m^2/h	Mowing efficiency	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
128	Grain Mown Volume	4	Unsigned	0	4294967295	-	kg	Mown volume	FMBXXX FMB110 FMB120 FMB124 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
129	Grain Moisture	2	Unsigned	0	100	-	%	Grain moisture	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
130	Harvesting Drum RPM	2	Unsigned	0	65535	-	rpm	Harvesting drum rpm	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
131	Gap Under Harvesting Drum	1	Unsigned	0	255	-	mm	Gap under harvesting drum	FMBXXX FMB110 FMB120 FMB122 FMB123 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
132	Security State Flags	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Security state flags	FMBXXX FMB110 FMB120 FMB122 FMB125 FMO125 FMC125 FMM125 FMB130 FMO130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300, CANCONTROL

133	Tachograph Total Vehicle Distance	4	Unsigned	0	4294967295	-	m	Tacho Total Vehicle Distance	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
134	Trip Distance	4	Unsigned	0	4294967295	-	m	Trip distance	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
135	Tachograph Vehicle Speed	2	Unsigned	0	255	-	km/h	Tacho vehicle speed	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
136	Tacho Driver Card Presence	1	Unsigned	0	3	-	-	Tacho Driver Card Presence	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
137	Driver 1 States	1	Unsigned	0	255	-	-	Driver 1 States	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
138	Driver 2 States	1	Unsigned	0	255	-	-	Driver 2 States	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
139	Driver 1 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Continuous Driving Time, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
140	Driver 2 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Continuous Driving Time, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
141	Driver 1 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Break Time, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
142	Driver 2 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Break Time, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
143	Driver 1 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 1 Duration Of Selected Activity, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
144	Driver 2 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 2 Duration Of Selected Activity, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
145	Driver 1 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Driving Time, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
146	Driver 2 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Driving Time, minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
147	Driver 1 ID High	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Driver 1 ID High	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
148	Driver 1 ID Low	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Driver 1 ID Low	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
149	Driver 2 ID High	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Driver 2 ID High	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
150	Driver 2 ID Low	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Driver 2 ID Low	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
151	Battery Temperature	2	Signed	-600	1270	0.1	°C	Battery temperature in Celsius	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300
152	HV Battery Level	1	Unsigned	0	100	-	%	Battery level in percent	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300, CANCONTROL
160	DTC Faults	1	Unsigned	0	255	-	-	DTC faults Count	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130 FMB140 FMB150 FMC150 FMM150	ALLCAN300, CANCONTROL
161	Slope of Arm	2	Signed	-3276	3276	-	Degrees °	Slope Of Arm	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
162	Rotation of Arm	2	Signed	-180	180	-	Degrees °	Rotation Of Arm	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300
163	Eject of Arm	2	Unsigned	0	6553	-	m	Eject of arm	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0725 FMC725 FMM125 FMB130 FM0730 FMC730 FMM130	ALLCAN300

164	Horizontal Distance Arm Vehicle	2	Unsigned	0	6553	-	m	Horizontal Distance Arm Vehicle	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
165	Height Arm Above Ground	2	Unsigned	0	6553	-	m	Height Arm Above Ground	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
166	Drill RPM	2	Unsigned	0	65535	-	rpm	Drill RPM	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
167	Amount Of Spread Salt Square Meter	2	Unsigned	0	655	-	g/m²	Amount Of Spread Salt Square Meter	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
168	Battery Voltage	2	Unsigned	0	6553	-	V	Battery Voltage	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
169	Amount Of Spread Fine Grained Salt	4	Unsigned	0	1677722	-	T	Amount Of Spread Fine Grained Salt	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
170	Amount Of Coarse Grained Salt	4	Unsigned	0	1677722	-	T	Amount Of Coarse Grained Salt	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
171	Amount Of Spread DiMix	4	Unsigned	0	1677722	-	T	Amount Of Spread DiMix	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
172	Amount Of Spread Coarse Grained Calcium	4	Unsigned	0	1677722	-	m³	Amount Of Spread Coarse Grained Calcium	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
173	Amount Of Spread Calcium Chloride	4	Unsigned	0	1677722	-	m³	Amount Of Spread Calcium Chloride	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
174	Amount Of Spread Sodium Chloride	4	Unsigned	0	1677722	-	m³	Amount Of Spread Sodium Chloride	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
176	Amount Of Spread Magnesium Chloride	4	Unsigned	0	1677722	-	m³	Amount Of Spread Magnesium Chloride	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
177	Amount Of Spread Gravel	4	Unsigned	0	1677722	-	T	Amount Of Spread Gravel	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
178	Amount Of Spread Sand	4	Unsigned	0	1677722	-	T	Amount Of Spread Sand	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
183	Width Pouring Left	2	Unsigned	0	655	-	m	Width Pouring Left	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
184	Width Pouring Right	2	Unsigned	0	655	-	m	Width Pouring Right	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
185	Salt Spreader Working Hours	4	Unsigned	0	167722	-	h	Salt Spreader Working Hours	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
186	Distance During Salting	4	Unsigned	0	167722	-	km	Distance During Salting	FMBXXX FMB110 FMB120 FMB122 FMB124 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
187	Load Weight	4	Unsigned	0	16772215	-	kg	Load Weight	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
188	Retarder Load	1	Unsigned	0	130	-	%	Retarded Load in percent	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
189	Cruise Time	4	Unsigned	0	16772215	-	min	Cruise time in minutes	FMBXXX FMB110 FMB120 FMB122 FMB125 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130	ALLCAN300
232	CNG Status	1	Unsigned	0	1	-	-	CNG Status	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, CANCONTROL
233	CNG Used	4	Unsigned	0	16772215	-	kg	CNG used	FMBXXX FMB110 FMB120 FMB122 FMB123 FM0125 FMC125 FMM125 FMB130 FM0130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, CANCONTROL

234	CNG Level	1	Unsigned	0	100	-	%	CNG Level	FMBXXX FMB110 FMB120 FMB122 FMB123 FMB125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150	LVCAN200, CANCONTROL
235	Oil Level	1	Unsigned	0	1	-	-	Engine Oil Level Indicator Status	FMBXXX FMB110 FMB120 FMB123 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
304	Vehicles Range On Battery	4	Unsigned	0	16777215	-	m	Vehicle Range on Battery	FMBXXX FMB110 FMB120 FMB123 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
305	Vehicles Range On Additional Fuel	4	Unsigned	0	16777215	-	m	Vehicle Range On Additional Fuel	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
325	VIN	17	ASCII	0	0xFF	-	-	VIN number	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	CANCONTROL
282	Fault Codes	Variable	-	0	128	-	-	DTC Fault codes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	LV-CAN200 + DTC
517	Security State Flags P4	8	HEX	0	0xffffffffffffffff	-	-	Security state flags protocol 4, more information click here Flags	FMBXXX FMB140	ALLCAN300
518	Control State Flags P4	8	HEX	0	0xffffffffffffffff	-	-	Control state flags protocol 4, more information click here Flags	FMBXXX FMB140	ALLCAN300
519	Indicator State Flags P4	8	HEX	0	0xffffffffffffffff	-	-	Indicator state flags protocol 4, more information click here Flags	FMBXXX FMB140	ALLCAN300
520	Agricultural State Flags P4	8	HEX	0	0xffffffffffffffff	-	-	Agricultural state flags protocol 4, more information click here Flags	FMBXXX FMB140	ALLCAN300
521	Utility State Flags P4	8	HEX	0	0xffffffffffffffff	-	-	Utility state flags protocol 4, more information click here Flags	FMBXXX FMB140	ALLCAN300
522	Cistern State Flags P4	8	HEX	0	0xffffffffffffffff	-	-	Cistern state flags protocol 4, more information click here Flags	FMBXXX FMB140	ALLCAN300
855	LNG Used	4	Unsigned	0	2147483647	-	kg	Total LNG used in kilogramss	FMBXXX FMB140	ALLCAN300, CANCONTROL
856	LNG Used (counted)	4	Unsigned	0	2147483647	-	kg	Total LNG used counted in kg	FMBXXX FMB140	ALLCAN300, CANCONTROL
857	LNG Level	2	Unsigned	0	100	-	%	LNG level in proc	FMBXXX FMB140	ALLCAN300, CANCONTROL
858	LNG Level	2	Unsigned	0	6553	-	kg	LNG level in kg	FMBXXX FMB140	ALLCAN300, CANCONTROL
1100	Total LPG Used	4	Unsigned	0	4294967295	-	l	Total LPG used in liters	FMBXXX FMB140	LVCAN
1101	Total LPG Used Counted	4	Unsigned	0	4294967295	-	l	Total LPG used counted in liters	FMBXXX FMB140	LVCAN
1102	LPG Level Proc	2	Unsigned	0	65535	-	%	LPG level in proc	FMBXXX FMB140	LVCAN
1103	LPG Level Liters	2	Unsigned	0	65535	-	l	LPG level in liters	FMBXXX FMB140	LVCAN
898	SSF Ignition	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
652	SSF KeyInIgnitionLock	1	Unsigned	0	1	-	-	0 - No key in lock 1 - Key in lock	FMBXXX FMB110 FMB120 FMB122 FMB123 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
899	SSF Webasto	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300
900	SSF Engine Working	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
901	SSF Standalone Engine	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300
902	SSF Ready To Drive	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
903	SSF Engine Working On CNG	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
904	SSF Work Mode	1	Unsigned	0	1	-	-	0 - Private 1 - Company	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300
905	SSF Operator	1	Unsigned	0	1	-	-	0 - Not present 1 - Present	FMBXXX FMB110 FMB120 FMB123 FMB122 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300
906	SSF Interlock	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB123 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300
907	SSF Engine Lock Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB124 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	CANCONTROL
908	SSF Request To Lock Engine	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	CANCONTROL
653	SSF Handbrake Is Active	1	Unsigned	0	1	-	-	0 - Handbrake inactive 1 - Handbrake active	FMBXXX FMB110 FMB120 FMB122 FMB123 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
910	SSF Footbrake Is Active	1	Unsigned	0	1	-	-	0 - Footbrake inactive 1 - Footbrake active	FMBXXX FMB110 FMB120 FMB123 FMB125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
911	SSF Clutch Pushed	1	Unsigned	0	1	-	-	0 - Clutch is pushed 1 - Clutch is not pushed	FMBXXX FMB110 FMB120 FMB124 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL
912	SSF Hazard Warning Lights	1	Unsigned	0	1	-	-	0 - Hazard warning lights on 1 - Hazard warning lights off	FMBXXX FMB110 FMB120 FMB122 FMB124 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	ALLCAN300, CANCONTROL

654	SSF Front Left Door Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
655	SSF Front Right Door Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
656	SSF Rear Left Door Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
657	SSF Rear Right Door Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
658	SSF Trunk Door Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
913	SSF Engine Cover Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
909	SSF Roof Open	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
914	SSF Charging Wire Plugged	1	Unsigned	0	1	-	-	0 - Unplugged 1 - Plugged	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
915	SSF Battery Charging	1	Unsigned	0	1	-	-	0 - Not charging 1 - Charging	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
916	SSF Electric Engine State	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
917	SSF Car Closed Factory Remote	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
662	SSF Car Is Closed	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
918	SSF Factory Alarm Actuated	1	Unsigned	0	1	-	-	0 - Not actuated 1 - Actuated	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
919	SSF Factory Alarm Emulated	1	Unsigned	0	1	-	-	0 - Not emulated 1 - Emulated	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
920	SSF Signal Close Factory Remote	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
921	SSF Signal Open Factory Remote	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
922	SSF Rearming Signal	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
923	SSF Trunk Door Opened Factory Remote	1	Unsigned	0	1	-	-	0 - Closed 1 - Open	FMBXXX FMB116 FMB120 FMB122 FMB124 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
924	SSF CAN Module In Sleep	1	Unsigned	0	1	-	-	0 - Not in sleep 1 - In sleep	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300, CANCONTROL
925	SSF Factory Remote 3x	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB124 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
926	SSF Factory Armed	1	Unsigned	0	1	-	-	0 - Not armed 1 - Armed	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	CANCONTROL
660	SSF Parking Gear Active (automatic gear box)	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB116 FMB120 FMB122 FMB124 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
661	SSF Reverse Gear Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB116 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
659	SSF Neutral Gear Active (automatic gear box)	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB116 FMB120 FMB124 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL

927	SSF Drive Is Active (automatic gear box)	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300, CANCONTROL
1083	SSF Engine Working On Dual Fuel	1	Unsigned	0	1	-	-	0 - Not working 1 - Working	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
1084	SSF Engine Working On LPG	1	Unsigned	0	1	-	-	0 - Not working 1 - Working	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
928	CSF Parking Lights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300, CANCONTROL
929	CSF Dipped Head lights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300, CANCONTROL
930	CSF Full Beam Headlights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300, CANCONTROL
931	CSF Rear Fog Lights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300, CANCONTROL
932	CSF Front Fog Lights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300, CANCONTROL
933	CSF Additional Front Lights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
934	CSF Additional Rear Lights	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
935	CSF Light Signal	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
936	CSF Air Conditioning	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
937	CSF Cruise Control	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
938	CSF Automatic Retarder	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
939	CSF Manual Retarder	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
940	CSF Driver's Seatbelt Fastened	1	Unsigned	0	1	-	-	0 - Not fastened 1 - Fastened	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
941	CSF Front Driver's Seatbelt Fastened	1	Unsigned	0	1	-	-	0 - Not fastened 1 - Fastened	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
942	CSF Left Driver's Seatbelt Fastened	1	Unsigned	0	1	-	-	0 - Not fastened 1 - Fastened	FMBXXX EMB110 EMB120 EMB122 EMB124 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
943	CSF Right Driver's Seatbelt Fastened	1	Unsigned	0	1	-	-	0 - Not fastened 1 - Fastened	FMBXXX EMB110 EMB120 EMB122 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
944	CSF Centre Driver's Seatbelt Fastened	1	Unsigned	0	1	-	-	0 - Not fastened 1 - Fastened	FMBXXX EMB110 EMB120 EMB124 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
945	CSF Front Passenger Present	1	Unsigned	0	1	-	-	0 - Not present 1 - Present	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
946	CSF PTO	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX EMB110 EMB120 EMB122 EMB124 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
947	CSF Front Differential Locked	1	Unsigned	0	1	-	-	0 - Unlocked 1 - Locked	FMBXXX EMB110 EMB120 EMB122 EMB123 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300
948	CSF Rear Differential Locked	1	Unsigned	0	1	-	-	0 - Unlocked 1 - Locked	FMBXXX EMB110 EMB120 EMB124 EMB125 EM1025 EMC125 EMM125 EMB130 EM1030 EMC130 EMM130	ALLCAN300

949	CSF Central Differential 4HI Locked	1	Unsigned	0	1	-	-	0 - Unlocked 1 - Locked	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
950	CSF Rear Differential 4LO Locked	1	Unsigned	0	1	-	-	0 - Unlocked 1 - Locked	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
951	CSF Trailer Axle 1 Lift Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
952	CSF Trailer Axle 2 Lift Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1085	CSF Trailer Connected	1	Unsigned	0	1	-	-	0 - Disconnected 1 - Connected	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1086	CSF Start Stop System Inactive	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
953	ISF Check Engine Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
954	ISF ABS Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
955	ISF ESP Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
956	ISF ESP Turned Off	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
957	ISF Stop Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
958	ISF Oil Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300, CANCONTROL
959	ISF Coolant liquid level	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
960	ISF Battery Not Charging Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
961	ISF Handbrake System Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
962	ISF AIRBAG Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
963	ISF EPS Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
964	ISF Warning Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
965	ISF Lights Failure Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
966	ISF Low Tire Pressure Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
967	ISF Wear Of Brake Pads Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
968	ISF Low Fuel Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
969	ISF Maintenence required Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
970	ISF Glow Plug Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300

971	ISF FAP Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
972	ISF EPC (Electronic Power Control) Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
973	ISF Clogged Engine Oil Filter Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
974	ISF Low Engine Oil Pressure Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
975	ISF Too High Engine Oil Temperature Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
976	ISF Low Coolant Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
977	ISF Clogged Hydraulic System Oil filter Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
978	ISF Hydraulic System Low Pressure Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
979	ISF Hydraulic Oil Low Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
980	ISF Hydraulic System High Temperature Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
981	ISF Oil Overflow In Hydraulic Chamber Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
982	ISF Clogged Air Filter Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
983	ISF Clogged Fuel Filter Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
984	ISF Water in Fuel Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
985	ISF Clogged Brake System Filter Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
986	ISF Low Washer Fluid Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300
987	ISF Low AdBlue Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300
988	ISF Low Trailer Tyre Pressure Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
989	ISF Wear Of Trailer Brake Lining Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
990	ISF High Trailer Brake Temperature Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
991	ISF Incorrect Trailer Pneumatic Supply Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
992	ISF Low CNG Level Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	LVCAN, ALLCAN300
993	ASF Right Joystick Moved Right Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
994	ASF Right Joystick Moved Left Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300

995	ASF Right Joystick Moved Forward Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
996	ASF Right Joystick Moved Back Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
997	ASF Left Joystick Moved Right Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FSC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
998	ASF Left Joystick Moved Left Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
999	ASF Left Joystick Moved Forward Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FSB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1000	ASF Left Joystick Moved Back Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1001	ASF First Rear hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FSC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1002	ASF Second Rear hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1003	ASF Third Rear hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FSB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1004	ASF Fourth Rear hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1005	ASF First Front hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FSC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1006	ASF Second Front hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1007	ASF Third Front hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FSB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1008	ASF Fourth Front hydraulic	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1009	ASF Front Three-point Hitch	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FSC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1010	ASF Rear Three-point Hitch	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FSC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1011	ASF Front Power Take-off	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1012	ASF Rear Power Take-off	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FSB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1013	ASF Mowing Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1014	ASF Threshing Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FSC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1015	ASF Grain Release From Hopper	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1016	ASF Grain Tank Is 100% Full	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FSB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1017	ASF Grain Tank Is 70% Full	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300
1018	ASF Grain Tank Is Opened	1	Unsigned	0	1	-	-	0 - Closed 1 - Opened	FMBXXX FMB110 FMB120 FMB124 FMB125 FMD1725 FMC725 FMM125 FMB130 FMD1330 FMC130 FMM130	ALLCAN300

1019	ASF Unloader Drive	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1020	ASF Cleaning Fan Control Turned Off	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1021	ASF Threshing Drum Control Turned Off	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1022	ASF Straw Walker Is Clogged	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1023	ASF Excessive Clearance Under The Threshing Drum	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1024	ASF Low Temperature Of Drive System Hydraulics Less Than 5 Grades	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1025	ASF High Temperature Of Drive System Hydraulics Greater Than 86 Grades	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1026	ASF Ear Auger Speed Below The Norm	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1027	ASF Grain Auger Speed Below The Norm	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1028	ASF Straw Chooper Speed Below The Norm	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1029	ASF Straw Shaker Speed Below The Norm	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1030	ASF Feeder Speed Below The Norm	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1031	ASF Straw Chopper Switched On	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1032	ASF Corn Header Connected	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1033	ASF Grain Header Connected	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1034	ASF Feeder Reverse Switched On	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1035	ASF The Pressure Filter Of The Hydraulic Pump Is Clogged	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1087	ASF Adapter Pressure Filter Sensor	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1088	ASF Service 2 Required Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1089	ASF Drain Filter Clogged Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1090	ASF Section 1 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1091	ASF Section 2 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1092	ASF Section 3 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1093	ASF Section 4 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300

1094	ASF Section 5 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1095	ASF Section 6 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1096	ASF Section 7 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1097	ASF Section 8 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1098	ASF Section 9 Spraying	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1036	USF Spreading	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1037	USF Pouring Chemicals	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1038	USF Conveyor Belt	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1039	USF Salt Spreader's Drive Wheel	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1040	USF Brushes	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1041	USF Vacuum Cleaner	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1042	USF Water Supply	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1043	USF Spreading	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1044	USF Liquid pump	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1045	USF Unloading From The Hopper	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1046	USF Low Salt (Sand) Level In Container Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1047	USF Low Water Level in Container Indicator	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1048	USF Chemicals	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1049	USF Compressor	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1050	USF Water Valve Is Opened	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1051	USF Cabin Moved Up Status Active	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1052	USF Cabin Moved Down Status Active	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1099	USF Hydraulics Work Not Permitted	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMBXXX FMB110 FMB120 FMB122 FMB123 FMD1725 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300
1053	CiSF Section 1 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No prosence 1 - Present	FMBXXX FMB110 FMB120 FMB124 FMB125 FMD125 FMC125 FMM125 FMB130 FMD130 FMC130 FMM130	ALLCAN300

1054	CiSF Section 1 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB124 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1055	CiSF Section 1 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1056	CiSF Section 2 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1057	CiSF Section 2 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1058	CiSF Section 2 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1059	CiSF Section 3 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1060	CiSF Section 3 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1061	CiSF Section 3 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1062	CiSF Section 4 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1063	CiSF Section 4 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1064	CiSF Section 4 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1065	CiSF Section 5 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1066	CiSF Section 5 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1067	CiSF Section 5 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1068	CiSF Section 6 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1069	CiSF Section 6 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1070	CiSF Section 6 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1071	CiSF Section 7 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1072	CiSF Section 7 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1073	CiSF Section 7 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1074	CiSF Section 8 Presence Of Fluid In The Downpipe	1	Unsigned	0	1	-	-	0 - No presence 1 - Present	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1075	CiSF Section 8 Filled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
1076	CiSF Section 8 Overfilled	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMBXXX FMB116 FMB120 FMB122 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	ALLCAN300
400	Distance to Next Service	4	Unsigned	0	4294967295	-	-		FMBXXX FMB116 FMB120 FMB124 FMB125 FM1025 FMC125 FMM125 FMB130 FM1030 FMC130 FMM130	CAN adapters

450	CNG Level Kg	2	Unsigned	0	65535	10	Kg	CNG Level Kg (appears only if CNG level percentage is not available)	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
859	Distance from need of service	4	Unsigned	0	4294967295	-	km	Service - distance elapsed since the occurrence of the need for servicing	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
860	Distance from last service	4	Unsigned	0	4294967295	-	km	Service - distance from the last service	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
861	Time to next service	2	Unsigned	0	65535	-	day	Service - time to next service	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
862	Time from need of service	2	Unsigned	0	65535	-	day	Service - time exceeded since the occurrence of the need for servicing	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
863	Time from last serivce	2	Unsigned	0	65535	-	day	Service - time elapsed since the last service	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
864	Distance to next oil service	4	Unsigned	0	4294967295	-	km	Service - distance to next oil service	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
865	Time to next oil service	2	Unsigned	0	65535	-	day	Service - time to next oil service	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
866	LVCAN Vehicle Range	4	Unsigned	0	4294967295	-	km	Information about vehicle range	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
867	LVCAN Total CNG counted	4	Unsigned	0	65535	-	kg	Information about Total CNG used in counted mode	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1079	Total Bale Count	4	Unsigned	0	0xFFFFFFFF	-	-	Total Bale Count	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1080	Bale Count	4	Unsigned	0	0xFFFFFFFF	-	-	Bale Count	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1081	Cut Bale Count	4	Unsigned	0	0xFFFFFFFF	-	-	Cut Bale Count	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1082	Bale Slices	4	Unsigned	0	0xFFFFFFFF	-	-	Bale Slices	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1116	LVCAN MaxRoadSpeed	1	Unsigned	0	255	-	km/h	Maximum speed from road signs	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1117	LVCAN ExceededRoadSpeed	1	Unsigned	0	255	-	km/h	Exceeded speed from road signs	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1205	LVCAN RSF SpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value" is recognized/canceled	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1206	LVCAN RSF EndOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "End of speed limit with value" is recognized/canceled	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1207	LVCAN RSF SpeedExceeded	1	Unsigned	0	1	-	-	Information if speed is exceeded indicated by road sign "Speed limit with value"	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1208	LVCAN RSF TimeSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Conditional time-specific speed limit with value" is recognized/canceled	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters
1209	LVCAN RSF WthrSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value due to weather conditions" is recognized/cancelled	FMBXXX FMB110 FMB120 FMB122 FMB125 FM3125 FMC125 FMM125 FMB130 FM3130 FMC130 FMM130	CAN adapters