How to read data from TZ-BT04/05/05B sensor

Disclaimer

If you are not using Bluetooth®, **please consider turning it off** or **change Bluetooth® PIN** to remove potential risks.

If you are using Bluetooth® we strongly recommend **using AES encryption** for enhanced security.

Configuration

These are instructions on how to easily read data from **TZ-BT04/05/05B** Bluetooth® LE sensor with Teltonika device.

First the device Bluetooth® settings need to be configured. These are the required steps:

- Press `Bluetooth®` settings.
  - Turn on BT Radio by pressing `Enable (hidden)` or `Enable (visible)`.
- Press `Bluetooth® 4.0` settings.
  - Select `TZ-BT04/05/05B sensor` in BLE connectionless functionalities section.
  - Type your TZ-BT04/05/05B ID in `ID` field.
  - After all these steps press `Save to device` to save configuration.
  - To start BLE scan right away press `Discover BLE`.

To check if the device has already received data from **TZ-BT04/05/05B** Bluetooth® LE sensor,

follow these steps:

- Navigate to`Status` section.
- Press `I/O Info` and look if BLE Temp, BLE Battery and BLE Humidity has any values.