

How to Install FMB641 on DAF XF

[Main Page](#) > [Professional Trackers](#) > [FMB641](#) > [FMB641 Manual](#) > **How to Install FMB641 on DAF XF**



Installation proccess

- Below is shown main installation location:



- Carefully unscrew the fuse panel screws and fold the panel down.



- Where to find the main connector?



- Connect the wires accordingly. It is recommended to use DIN 1 instead of DIN 3 for ignition detection.



- After installation and device configuration of FMB6 (CAN1 should be selected - FMS/TACHO), you can check if the installation is properly made. Turn on the ignition of the vehicle and send SMS command: "tachochck". If the response shows: "Can1:111,F2EF", 111 -means tachograph properly connected, F2EF - or any other value which is not equal to 0000, means FMS data received also.