

MTB100 Teltonika Data Sending Parameters ID

[Main Page](#) > [EOL Products](#) > [MTB100](#) > **MTB100 Teltonika Data Sending Parameters ID**

Document updated according firmware FMB.Ver.03.29.00 and newer.

FMB AVL ID's consist of these **parameters groups**:

□

Contents

- [1 Permanent I/O elements](#)
- [2 Eventual I/O elements](#)
- [3 OBD elements](#)
- [4 OBD OEM elements](#)
- [5 BLE Sensors I/O elements](#)
- [6 CAN adapters elements](#)

Permanent I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
239	Ignition	1	Unsigned	0	1	-	-	0 - Ignition Off 1 - Ignition On	FMBXXX	Permanent I/O Elements
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMB130	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	
									FMU125	
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

										FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
21	GSM Signal	1	Unsigned	0	5	-	-	Value in range 1-5		Permanent I/O Elements	
										FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
200	Sleep Mode	1	Unsigned	0	4	-	-	0 - No Sleep 1 - GPS Sleep 2 - Deep Sleep 3 - Online Sleep 4 - Ultra Sleep		Permanent I/O Elements	
										FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	

									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
69	GNSS Status	1	Unsign ed	0	3	-	-	0 - GNSS OFF 1 - GNSS ON with fix 2 - GNSS ON without fix 3 - GNSS sleep	0	Permanent I/O Elements
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	
									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	
181	GNSS PDOP	2	Unsign ed	0	500	0.1		Coefficient, calculation formula	FMB900	Permanent I/O Elements
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	

182	GNSS HDOP	2	Unsigned	0	500	0.1	Coefficient, calculation formula	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O Elements
66	External Voltage	2	Unsigned	0	65535	0.001	V Voltage	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements

									FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM150	
206	GSM Area Code	2	Unsigned	0	65535	-	-	Location Area code (LAC), it depends on GSM operator. It provides unique number which assigned to a set of base GSM stations.	FMM150 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM800 0 FMM80A	Permanent I/O elements
									FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150	
67	Battery Voltage	2	Unsigned	0	65535	0.001	V	Voltage	FMM150 0 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 0 FMM80A	Permanent I/O elements

										FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
68	Battery Current	2	Unsigned	0	65535	0.001	A	Current		Permanent I/O elements	
241	Active GSM Operator	4	Unsigned	0	42949 67295	-	-	Currently used GSM Operator code		Permanent I/O elements	

[illegible]

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	
1	Digital Input 1	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	

ID	Name	Size	Unit	Address	Value	Scale	Min	Max
12	Fuel Used GPS	4	Unsigned	0	4294967295	0.001	1	Fuel Used
13	Fuel Rate GPS	2	Unsigned	0	32767	0.01	1/100km	Average Fuel Use

										FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
17	Axis X	2	Signed	-8000	8000	-	mG	X axis value	Permanent I/O elements		
18	Axis Y	2	Signed	-8000	8000	-	mG	Y axis value	Permanent I/O elements		

									FMBXXX FMB001 EMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15	
19	Axis Z	2	Signed	-8000	8000	-	mG	Z axis value	0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements
									FMBXXX FMB001 EMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15	
11	ICCID1	8	Unsigned	0	0xffffffff ffffffff	-	-	Value of SIM ICCID, MSB	0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements

										FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 FMBXXX FMB900 FMB910 FMB920 FMC920 FMM92 0 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206 FMB640 FMBXXX FMB110 FMB120 FMB122 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206 FMB640 FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM13 0 FMB140	Permanent I/O elements
10	SD Status	1	Unsigned	0	1	-	-	0 - not present 1 - present			
2	Digital Input 2	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
3	Digital Input 3	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
6	Analog Input 2	2	Unsigned	0	65535	0.001	V	Voltage		Permanent I/O elements	

180	Digital Output 2	1	Unsigned	0	1	-	-	Logic 0/1		FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206	Permanent I/O elements
72	Dallas Temperature 1	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 - Sensor not ready if 2000 - Value read error if 3000 - Not connected if 4000 - ID failed if 5000 - same as 850		FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
73	Dallas Temperature 2	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 - Sensor not ready if 2000 - Value read error if 3000 - Not connected if 4000 - ID failed if 5000 - same as 850		FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
74	Dallas Temperature 3	4	Signed	-550	1150	0.1	°C	Degrees (°C), -55 - +115, if 850 - Sensor not ready if 2000 - Value read error if 3000 - Not connected if 4000 - ID failed if 5000 - same as 850		FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements

								Degrees (°C), -55 - +115, if 850 – Sensor not ready if 2000 – Value read error if 3000 – Not connected if 4000 – ID failed if 5000 – same as 850	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	
75	Dallas Temperature 4	4	Signed	-550	1150	0.1	°C		FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
76	Dallas Temperature ID 1	8	Unsigned	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
77	Dallas Temperature ID 2	8	Unsigned	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
79	Dallas Temperature ID 3	8	Unsigned	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements

									FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5	
71	Dallas Temperature ID 4	8	Unsigned	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206 FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
78	iButton	8	Unsigned	0	0xffffffff ffffffff	-	-	iButton ID	FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206 FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
207	RFID	8	Unsigned	0	0xffffffff ffffffff	-	-	RFID ID	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
201	LLS 1 Fuel Level	2	Signed	-4	32767	-	kV or ltr	Fuel level measured by LLS sensor via RS232/RS485	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
202	LLS 1 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS232/RS485	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
203	LLS 2 Fuel Level	2	Signed	-4	32767	-	kV or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
204	LLS 2 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
210	LLS 3 Fuel Level	2	Unsigned	-4	32767	-	kV or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements
211	LLS 3 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM12 5	Permanent I/O elements

212	LLS 4 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
213	LLS 4 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
214	LLS 5 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
215	LLS 5 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
15	Eco Score	2	Unsigned	0	65535	0.01	-	Average amount of events on some distance	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMB800 FMM800 FMB800 FMM800 FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150	Permanent I/O elements
113	Battery Level	1	Unsigned	0	100	-	%	Battery capacity level	FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMB800 FMM800 FMB800 FMM800 FMB800 FMM800	Permanent I/O elements

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100	
263	BT Status	1	Unsigned	0	4	-	-	0 - BT is disabled 1 - BT Enabled, not device connected 2 - Device connected, BTv3 Only 3 - Device connected, BLE only 4 - Device connected, BLE + BT	Permanent I/O elements		
264	Barcode ID	Variable	ASCII	0	32	-	-	Barcode ID			

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB125 FMB125 FMU125 FMC125 FMM12 5 FMB125 FMB125 FMU125 FMC125 FMM12 5 FMBXXX FMB130 FMU130 FMC130 FMC150 FMM13 0 FMB130 FMU130 FMC130 FMM13 0 FMB140	
303	Instant Movement	1	Unsigned	0	1	-	-	Logic: 0/1 returns movement value		Permanent I/O elements	
327	UL202-02 Sensor Fuel level	2	Signed	-150	32767	0.1	mm	UL202-02 Sensor Fuel level		Permanent I/O elements	
483	UL202-02 Sensor Status	1	Unsigned	0	255	-	-	UL202-02 sensor status codes		Permanent I/O elements	
380	Digital output 3	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
381	Ground Sense	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	

329	AIN Speed	2	Unsigned	0	65535	-	-		MSP500	Permanent I/O elements
500	MSP500 vendor name	40	ASCII	0	40	-	-	Name of the integrator who installed the device	MSP500	Permanent I/O elements
501	MSP500 vehicle number	40	ASCII	0	40	-	-	Vehicle number on which the device is installed	MSP500	Permanent I/O elements
502	MSP500 speed sensor	1	unsigned	0	1	-	-	Status of the speed sensor	MSP500	Permanent I/O elements
637	Wake Reason	1	Unsigned	0	1	-	-	True if device was woken by RTC alarm	FMB965	Permanent I/O elements
FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910										Permanent I/O elements
10800	EYE Temperature 1	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 1		

FMB910

elements

10802	EYE Temperature 3	2	Signed -32768 32767	0.01	°C	Temperature measured by EYE Sensor 3
-------	-------------------	---	---------------------	------	----	--------------------------------------

FMB910

10803	EYE Temperature 4	2	Signed -32768 32767	0.01	°C	Temperature measured by EYE Sensor 4
-------	-------------------	---	---------------------	------	----	--------------------------------------

10809	EYE Magnet 2	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------	---	----------	---	---	---	---	---	--	------------------------

10810	EYE Magnet 3	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------	---	----------	---	---	---	---	---	--	------------------------

10811	EYE Magnet 4	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------	---	----------	---	---	---	---	---	--	------------------------

10812	EYE Movement 1	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10813	EYE Movement 2	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10814	EYE Movement 3	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10815	EYE Movement 4	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10836	EYE Movement count 1	2	Unsign ed	0	32767	-	-	Movement count measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	-------------------------	---	--------------	---	-------	---	---	--	--	---------------------------

10842	EYE Magnet count 3	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------------	---	----------	---	-------	---	---	--	--	------------------------

451	BLE RFID #1	8	HEX	0	0xffffffff ffffffff	-	-	BLE NBL-T RFID ID for Connexionless mode #1 slot	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910 FMP100 FMP1M 1 MSP500 FMC800 FMM80 0 FMC880 FMM88 0 FMM80 A	Permanent I/O elements
-----	-------------	---	-----	---	------------------------	---	---	--	--	------------------------

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

622	Frequency DIN1	2	Unsigned	0	65535	0.1	Hz	Frequency of input signal present on DIN1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 EMP100 EMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements
-----	----------------	---	----------	---	-------	-----	----	---	--	------------------------

										FMBXXX	
										[Expand]	
										FMB001	
										FMB010	
										FMB100	
										FMB110	
										FMB120	
										FMB122	
										FMB125	
										FMB130	
										FMB900	
										FMB920	
										FMB962	
										FMB964	
										FM3001	
										FM3010	
										FMB202	
										FMB204	
										FMB206	
										FMB207	
										FMB208	
										FMB209	
										FMT100	
										MTB100	
										TMT250	
										GH5200	
										FMB140	
										FMB020	
										FMB002	
623	Frequency DIN2	2	Unsigned	0	65535	0.1	Hz	Frequency of input signal present on DIN2	Permanent I/O elements	FMB003	
										FMU120	
										FMU122	
										FMU125	
										FMU126	
										FMU130	
										FMC120	
										FMC122	
										FMC125	
										FMC130	
										FMM125	
										FMM130	
										FMC001	
										FMM001	
										TFT100	
										FMB910	
										FMP100	
										FMP1M1	
										MSP500	
										FMC800	
										FMM800	
										FMC880	
										FMM880	
										FMM800	
										A	

Eventual I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	SW Support	Parameter Group
				Min	Max					
155	Guidance state 01	1	Unsigned	0	3	-	-	0 - target left state 1 - target entered state 2 - over speeding road 3 - over speeding start	FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Eventual I/O elements

156	Confidence zone 02	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
157	Confidence zone 03	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
158	Confidence zone 04	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
159	Confidence zone 05	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
61	Confidence zone 06	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
62	Confidence zone 07	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
63	Confidence zone 08	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
64	Confidence zone 09	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
65	Confidence zone 10	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	
									24/0001	

98	Confidence score 20	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0002	
									24/0003	
									24/0004	
									24/0005	
									24/0006	
									24/0007	
									24/0008	
									24/0009	
99	Confidence score 21	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0010	Eventual IO elements
									24/0010	
									24/0011	
									24/0012	
									24/0013	
									24/0014	
									24/0015	
									24/0016	
									24/0017	
									24/0018	
153	Confidence score 22	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0019	Eventual IO elements
									24/0019	
									24/0020	
									24/0021	
									24/0022	
									24/0023	
									24/0024	
									24/0025	
									24/0026	
									24/0027	
154	Confidence score 23	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0028	Eventual IO elements
									24/0028	
									24/0029	
									24/0030	
									24/0031	
									24/0032	
									24/0033	
									24/0034	
									24/0035	
									24/0036	
190	Confidence score 24	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0037	Eventual IO elements
									24/0037	
									24/0038	
									24/0039	
									24/0040	
									24/0041	
									24/0042	
									24/0043	
									24/0044	
									24/0045	
191	Confidence score 25	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0046	Eventual IO elements
									24/0046	
									24/0047	
									24/0048	
									24/0049	
									24/0050	
									24/0051	
									24/0052	
									24/0053	
									24/0054	
192	Confidence score 26	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0055	Eventual IO elements
									24/0055	
									24/0056	
									24/0057	
									24/0058	
									24/0059	
									24/0060	
									24/0061	
									24/0062	
									24/0063	
193	Confidence score 27	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0064	Eventual IO elements
									24/0064	
									24/0065	
									24/0066	
									24/0067	
									24/0068	
									24/0069	
									24/0070	
									24/0071	
									24/0072	
194	Confidence score 28	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0073	Eventual IO elements
									24/0073	
									24/0074	
									24/0075	
									24/0076	
									24/0077	
									24/0078	
									24/0079	
									24/0080	
									24/0081	

[illegible]

228	Guidance zone 47	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
229	Guidance zone 48	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
230	Guidance zone 49	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
231	Guidance zone 50	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
175	Auto Guidance	1	Unsigned	0	1	-	-	0 - target left zone 1 - target entered zone	Eventual IO elements
210	Trip	1	Unsigned	0	1	-	-	0 - trip stop 1 - trip start From 01.01.14 for version available with BT app new values: 2 - Business Status 3 - Private Status 4-9 - Custom Status	Eventual IO elements
255	Over Speeding	1	Unsigned	0	255	-	km/h	At over speeding start km/h, at over speeding end km/h	Eventual IO elements
217	Crash trace data	Variable	HEX	0	1200	-	-	Crash trace data	Eventual IO elements
285	Blood alcohol content	2	Unsigned	0	9999	-	-	Alcohol content in blood in perfumes and mode. First 14 bits from MSB are perfumes multiplied by 1000 and last to bits are 0 - Passive test; 1 Active test; 2 and 3 are reserved.	Eventual IO elements
231	Idling	1	Unsigned	0	1	-	-	0 - moving 1 - idling	Eventual IO elements

253	Green driving type	1	Unsigned	1	3	-	-	1 - harsh acceleration 2 - harsh braking 3 - harsh cornering	Eventual IO elements
246	Towing	1	Unsigned	0	1	-	-	0 - steady 1 - towing	Eventual IO elements
252	Uplug	1	Unsigned	0	1	-	-	0 - battery present 1 - battery unplugged	Eventual IO elements
247	Crash detection	1	Unsigned	1	6	-	-	1 - real crash detected (device is calibrated) 2 - limited crash trace (device not calibrated) 3 - limited crash trace (device is calibrated) 4 - full crash trace (device not calibrated) 5 - full crash trace (device is calibrated) 6 - real crash detected (device not calibrated)	Eventual IO elements
248	Immobilizer	1	Unsigned	0	2	-	-	0 - (device not connected) 1 - (device connected (tamabilliar)) 2 - (device connected (aftermarket wiring))	Eventual IO elements
254	Green Driving Value	1	Unsigned	0	255	acc and braking 0-01	Green or red	Depending on green driving type: if harsh acceleration or braking - g*100 (value 123 > 1.23g). If Green driving source is „GPS“ - harsh cornering value in rad*100. If source is „Accelerometer“ - g*100.	Eventual IO elements
249	Jumping	1	Unsigned	0	1	-	-	0 - jumping stop 1 - jumping start	Eventual IO elements
14	ICCID2	8	Unsigned	0	0xFFFFFFFFFFFF	-	-	Value of SIM ICCID, LSB	Eventual IO elements
243	Green driving event duration	2	Unsigned	0	65535	-	ms	Duration of event that did generate Green driving	Eventual IO elements
236	Alarm	1	Unsigned	0	1	-	-	0 - Reserved 1 - Alarm event occurred Element stores maximum accelerometer values in mg on all axis during Eeo driving event	Eventual IO elements
238	EeoMaximum	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	8 Bytes 2B Z-axis - X-axis 2B - Y-axis 2B - Z-axis	Eventual IO elements
239	EeoAverage	8	Unsigned	0	0xFFFFFFFFFFFFFFFF	-	-	Element stores average accelerometer values in mg on all axis during Eeo driving event	Eventual IO elements
260	EeoDuration	2	Unsigned	0	65535	-	ms	2B Z-axis 2B - X-axis 2B - Y-axis 2B - Z-axis Duration of Eeo driving event in milliseconds	Eventual IO elements

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
30	Number of DTC	1	Unsigned	0	255	-	-	Number of DTC	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
31	Engine Load	1	Unsigned	0	100	-	%	Calculated engine load value	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
32	Coolant Temperature	1	Signed	-128	127	-	°C	Engine coolant temperature	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
33	Short Fuel Trim	1	Signed	-100	99	-	%	Short term fuel trim 1	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
34	Fuel pressure	2	Unsigned	0	765	-	kPa	Fuel pressure		
35	Intake MAP	1	Unsigned	0	255	-	kPa	Intake manifold absolute pressure		
36	Engine RPM	2	Unsigned	0	16384	-	rpm	Engine RPM		
37	Vehicle Speed	1	Unsigned	0	255	-	km/h	Vehicle speed		

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
38	Timing Advance	1	Signed	-64	64	-	°	Timing advance		OBD elements	
39	Intake Air Temperature	1	Signed	-128	127	-	°C	Intake air temperature		OBD elements	
40	MAF	2	Unsigned	0	65535	0.01	g/sec	MAF air flow rate		OBD elements	
41	Throttle Position	1	Unsigned	0	100	-	%	Throttle position		OBD elements	

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
42	Runtime since engine start	2	Unsigned	0	65535	-	s	Runtime since engine start	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
43	Distance Traveled MIL On	2	Unsigned	0	65535	-	km	Distance ormattin MIL on	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
44	Relative Fuel Rail Pressure	2	Unsigned	0	5178	0.1	kPa	Relative fuel rail pressure	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
45	Direct Fuel Rail Pressure	2	Unsigned	0	65535	10	kPa	Direct Fuel Rail Pressure	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
46	Commanded EGR	1	Unsigned	0	100	-	%	Commanded EGR		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
47	EGR Error	1	Signed	-100	100	-	%	EGR error		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
48	Fuel Level	1	Unsigned	0	100	-	%	Fuel level		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
49	Distance Since Codes Clear	2	Unsigned	0	65535	-	km	Distance traveled since codes cleared		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
50	Barometric Pressure	1	Unsigned	0	255	-	kPa	Barometric pressure		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
51	Control Module Voltage	2	Unsigned	0	65535	0.001	V	Control module voltage		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
52	Absolute Load Value	2	Unsigned	0	25700	-	%	Absolute load value		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
759	Fuel Type	1	Unsigned	0	255	-	-	0 Not available 1 Gasoline 2 Methanol 3 Ethanol 4 Diesel 5 LPG 6 CNG 7 Propane 8 Electric 9 Bifuel running Gasoline 10 Bifuel running Methanol 11 Bifuel running Ethanol 12 Bifuel running LPG 13 Bifuel running CNG 14 Bifuel running Propane 15 Bifuel running Electricity 16 Bifuel running electric and combustion engine 17 Hybrid gasoline 18 Hybrid Ethanol 19 Hybrid Diesel 20 Hybrid Electric 21 Hybrid running electric and combustion engine 22 Hybrid Regenerative 23 Bifuel running diesel		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
53	Ambient Air Temperature	1	Signed	-128	127	-	°C	Ambient air temperature		OBD elements	
54	Time Run With MIL On	2	Unsigned	0	65535	-	min	Time run with MIL on		OBD elements	
55	Time Since Codes Cleared	2	Unsigned	0	65535	-	min	Time since codes cleared		OBD elements	
56	Absolute Fuel Rail Pressure	2	Unsigned	0	65535	0.1	kPa	Absolute fuel rail pressure		OBD elements	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
57	Hybrid battery pack life	1	Unsigned	0	100	-	%	Hybrid battery pack remaining life		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
58	Engine Oil Temperature	1	Unsigned	0	215	-	°C	Engine oil temperature		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
59	Fuel injection timing	2	Signed	-21000	30200	0.01	°	Fuel injection timing		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
540	Throttle position group	1	Unsigned	0	100	-	%	Throttle Position Value From PID Group		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC003 FMC00A FMM003 FMM00A	
541	Commanded Equivalence R	1	Unsigned	0	200	0.01	-	Fuel-Air Commanded Equivalence Ratio		FMBXXX FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements
										FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	
542	Intake MAP 2 bytes	2	Unsigned	0	2048	-	kPa	Intake Manifold Absolute Pressure		FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
543	Hybrid System Voltage	2	Unsigned	0	1024	-	V	Hybrid vehicle system voltage		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
544	Hybrid System Current	2	Signed	-3277	3277	-	A	Hybrid vehicle system current		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
281	Fault Codes	variable	ASCII	0	128	-	-	Fault Codes (values separated via ",")		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
60	Fuel Rate	2	Unsigned	0	32767	0.01	L/h	Engine fuel rate, L/h*100		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

OBD OEM elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
389	OBD OEM Total Mileage	4	Unsigned	0	0xffffffff	-	km	Total mileage received by requesting vehicle specific PID	FMB003	OBD OEM elements
390	OBD OEM Fuel Level	4	Unsigned	0	0xffffffff	0.1	l	Fuel level in litres received by requesting vehicle specific PID	FMB003	OBD OEM elements
402	OEM Distance Until Service	4	Unsigned	0	0xffffffff	-	km	Distance till next service received by requesting vehicle specific PID	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
410	OEM Battery charge state	1	Unsigned	0	1	-	-	0 - Not charging 1 - Charging	FMM003	OBD OEM elements
									FMC003	
									FMM003	
									FMB001	
									FMC001	
411	OEM Battery charge level	1	Unsigned	0	100	-	%	Represents battery charged level	FMM001	OBD OEM elements
									FMB003	
									FMC003	
									FMM003	
									FMB001	
412	OEM Battery power consumption	2	Unsigned	0	65535	-	kWh/100km	Represents battery power consumption	FMC001	OBD OEM elements
									FMM001	
									FMB003	
									FMC003	
									FMM003	
755	OEM Remaining distance	2	Unsigned	0	65535	-	km	Remaining distance until fuel tank empty or battery (EV) depleted	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
1151	OEM Battery State Of Health	2	Unsigned	0	65535	-	%	Battery State of Health	FMM003	OBD OEM elements
									FMC003	
									FMM003	
									FMB001	
									FMC001	
1152	OEM Battery Temperature	2	Signed	-32768	32767	-	°C	Battery pack temperature	FMM001	OBD OEM elements
									FMB003	
									FMC003	
									FMM003	
									FMB001	

BLE Sensors I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					

25	BLE Temperature #1	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

26	BLE Temperature #2	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

27	BLE Temperature #3	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

28	BLE Temperature #4	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

[illegible]

20	BLE Battery #2	1	Unsigned	0	100	-	%	Battery level of sensor #2	FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	Bluetooth Low Energy
----	----------------	---	----------	---	-----	---	---	----------------------------	--	-------------------------

										FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
22	BLE Battery #3	1	Unsigned	0	100	-	%	Battery level of sensor #3		Bluetooth Low Energy	

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						</
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

										FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
472	BLE 3 Custom #3	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy		

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
474	BLE 3 Custom #5	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
477	BLE 4 Custom #4	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
478	BLE 4 Custom #5	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

CAN adapters elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units		Description	ECU Support	Parameter Group
				Min	Max					PHEV01 PHEV02 PHEV03 PHEV04 PHEV05 PHEV06 PHEV07 PHEV08 PHEV09 PHEV10 PHEV11 PHEV12 PHEV13 PHEV14 PHEV15 PHEV16 PHEV17 PHEV18 PHEV19 PHEV20 PHEV21 PHEV22 PHEV23 PHEV24 PHEV25 PHEV26 PHEV27 PHEV28 PHEV29 PHEV30 PHEV31 PHEV32 PHEV33 PHEV34 PHEV35 PHEV36 PHEV37 PHEV38 PHEV39 PHEV40 PHEV41 PHEV42 PHEV43 PHEV44 PHEV45 PHEV46 PHEV47 PHEV48 PHEV49 PHEV50 PHEV51 PHEV52 PHEV53 PHEV54 PHEV55 PHEV56 PHEV57 PHEV58 PHEV59 PHEV60 PHEV61 PHEV62 PHEV63 PHEV64 PHEV65 PHEV66 PHEV67 PHEV68 PHEV69 PHEV70 PHEV71 PHEV72 PHEV73 PHEV74 PHEV75 PHEV76 PHEV77 PHEV78 PHEV79 PHEV80 PHEV81 PHEV82 PHEV83 PHEV84 PHEV85 PHEV86 PHEV87 PHEV88 PHEV89 PHEV90 PHEV91 PHEV92 PHEV93 PHEV94 PHEV95 PHEV96 PHEV97 PHEV98 PHEV99 PHEV100 PHEV101 PHEV102 PHEV103 PHEV104 PHEV105 PHEV106 PHEV107 PHEV108 PHEV109 PHEV110 PHEV111 PHEV112 PHEV113 PHEV114 PHEV115 PHEV116 PHEV117 PHEV118 PHEV119 PHEV120 PHEV121 PHEV122 PHEV123 PHEV124 PHEV125 PHEV126 PHEV127 PHEV128 PHEV129 PHEV130 PHEV131 PHEV132 PHEV133 PHEV134 PHEV135 PHEV136 PHEV137 PHEV138 PHEV139 PHEV140 PHEV141 PHEV142 PHEV143 PHEV144 PHEV145 PHEV146 PHEV147 PHEV148 PHEV149 PHEV150 PHEV151 PHEV152 PHEV153 PHEV154 PHEV155 PHEV156 PHEV157 PHEV158 PHEV159 PHEV160 PHEV161 PHEV162 PHEV163 PHEV164 PHEV165 PHEV166 PHEV167 PHEV168 PHEV169 PHEV170 PHEV171 PHEV172 PHEV173 PHEV174 PHEV175 PHEV176 PHEV177 PHEV178 PHEV179 PHEV180 PHEV181 PHEV182 PHEV183 PHEV184 PHEV185 PHEV186 PHEV187 PHEV188 PHEV189 PHEV190 PHEV191 PHEV192 PHEV193 PHEV194 PHEV195 PHEV196 PHEV197 PHEV198 PHEV199 PHEV200 PHEV201 PHEV202 PHEV203 PHEV204 PHEV205 PHEV206 PHEV207 PHEV208 PHEV209 PHEV210 PHEV211 PHEV212 PHEV213 PHEV214 PHEV215 PHEV216 PHEV217 PHEV218 PHEV219 PHEV220 PHEV221 PHEV222 PHEV223 PHEV224 PHEV225 PHEV226 PHEV227 PHEV228 PHEV229 PHEV230 PHEV231 PHEV232 PHEV233 PHEV234 PHEV235 PHEV236 PHEV237 PHEV238 PHEV239 PHEV240 PHEV241 PHEV242 PHEV243 PHEV244 PHEV245 PHEV246 PHEV247 PHEV248 PHEV249 PHEV250 PHEV251 PHEV252 PHEV253 PHEV254 PHEV255 PHEV256 PHEV257 PHEV258 PHEV259 PHEV260 PHEV261 PHEV262 PHEV263 PHEV264 PHEV265 PHEV266 PHEV267 PHEV268 PHEV269 PHEV270 PHEV271 PHEV272 PHEV273 PHEV274 PHEV275 PHEV276 PHEV277 PHEV278 PHEV279 PHEV280 PHEV281 PHEV282 PHEV283 PHEV284 PHEV285 PHEV286 PHEV287 PHEV288 PHEV289 PHEV290 PHEV291 PHEV292 PHEV293 PHEV294 PHEV295 PHEV296 PHEV297 PHEV298 PHEV299 PHEV300 PHEV301 PHEV302 PHEV303 PHEV304 PHEV305 PHEV306 PHEV307 PHEV308 PHEV309 PHEV310 PHEV311 PHEV312 PHEV313 PHEV314 PHEV315 PHEV316 PHEV317 PHEV318 PHEV319 PHEV320 PHEV321 PHEV322 PHEV323 PHEV324 PHEV325 PHEV326 PHEV327 PHEV328 PHEV329 PHEV330 PHEV331 PHEV332 PHEV333 PHEV334 PHEV335 PHEV336 PHEV337 PHEV338 PHEV339 PHEV340 PHEV341 PHEV342 PHEV343 PHEV344 PHEV345 PHEV346 PHEV347 PHEV348 PHEV349 PHEV350 PHEV351 PHEV352 PHEV353 PHEV354 PHEV355 PHEV356 PHEV357 PHEV358 PHEV359 PHEV360 PHEV361 PHEV362 PHEV363 PHEV364 PHEV365 PHEV366 PHEV367 PHEV368 PHEV369 PHEV370 PHEV371 PHEV372 PHEV373 PHEV374 PHEV375 PHEV376 PHEV377 PHEV378 PHEV379 PHEV380 PHEV381 PHEV382 PHEV383 PHEV384 PHEV385 PHEV386 PHEV387 PHEV388 PHEV389 PHEV390 PHEV391 PHEV392 PHEV393 PHEV394 PHEV395 PHEV396 PHEV397 PHEV398 PHEV399 PHEV400 PHEV401 PHEV402 PHEV403 PHEV404 PHEV405 PHEV406 PHEV407 PHEV408 PHEV409 PHEV410 PHEV411 PHEV412 PHEV413 PHEV414 PHEV415 PHEV416 PHEV417 PHEV418 PHEV419 PHEV420 PHEV421 PHEV422 PHEV423 PHEV424 PHEV425 PHEV426 PHEV427 PHEV428 PHEV429 PHEV430 PHEV431 PHEV432 PHEV433 PHEV434 PHEV435 PHEV436 PHEV437 PHEV438 PHEV439 PHEV440 PHEV441 PHEV442 PHEV443 PHEV444 PHEV445 PHEV446 PHEV447 PHEV448 PHEV449 PHEV450 PHEV451 PHEV452 PHEV453 PHEV454 PHEV455 PHEV456 PHEV457 PHEV458 PHEV459 PHEV460 PHEV461 PHEV462 PHEV463 PHEV464 PHEV465 PHEV466 PHEV467 PHEV468 PHEV469 PHEV470 PHEV471 PHEV472 PHEV473 PHEV474 PHEV475 PHEV476 PHEV477 PHEV478 PHEV479 PHEV480 PHEV481 PHEV482 PHEV483 PHEV484 PHEV485 PHEV486 PHEV487 PHEV488 PHEV489 PHEV490 PHEV491 PHEV492 PHEV493 PHEV494 PHEV495 PHEV496 PHEV497 PHEV498 PHEV499 PHEV500 PHEV501 PHEV502 PHEV503 PHEV504 PHEV505 PHEV506 PHEV507 PHEV508 PHEV509 PHEV510 PHEV511 PHEV512 PHEV513 PHEV514 PHEV515 PHEV516 PHEV517 PHEV518 PHEV519 PHEV520 PHEV521 PHEV522 PHEV523 PHEV524 PHEV525 PHEV526 PHEV527 PHEV528 PHEV529 PHEV530 PHEV531 PHEV532 PHEV533 PHEV534 PHEV535 PHEV536 PHEV537 PHEV538 PHEV539 PHEV540 PHEV541 PHEV542 PHEV543 PHEV544 PHEV545 PHEV546 PHEV547 PHEV548 PHEV549 PHEV550 PHEV551 PHEV552 PHEV553 PHEV554 PHEV555 PHEV556 PHEV557 PHEV558 PHEV559 PHEV560 PHEV561 PHEV562 PHEV563 PHEV564 PHEV565 PHEV566 PHEV567 PHEV568 PHEV569 PHEV570 PHEV571 PHEV572 PHEV573 PHEV574 PHEV575 PHEV576 PHEV577 PHEV578 PHEV579 PHEV580 PHEV581 PHEV582 PHEV583 PHEV584 PHEV585 PHEV586 PHEV587 PHEV588 PHEV589 PHEV590 PHEV591 PHEV592 PHEV593 PHEV594 PHEV595 PHEV596 PHEV597 PHEV598 PHEV599 PHEV600 PHEV601 PHEV602 PHEV603 PHEV604 PHEV605 PHEV606 PHEV607 PHEV608 PHEV609 PHEV610 PHEV611 PHEV612 PHEV613 PHEV614 PHEV615 PHEV616 PHEV617 PHEV618 PHEV619 PHEV620 PHEV621 PHEV622 PHEV623 PHEV624 PHEV625 PHEV626 PHEV627 PHEV628 PHEV629 PHEV630 PHEV631 PHEV632 PHEV633 PHEV634 PHEV635 PHEV636 PHEV637 PHEV638 PHEV639 PHEV640 PHEV641 PHEV642 PHEV643 PHEV644 PHEV645 PHEV646 PHEV647 PHEV648 PHEV649 PHEV650 PHEV651 PHEV652 PHEV653 PHEV654 PHEV655 PHEV656 PHEV657 PHEV658 PHEV659 PHEV660 PHEV661 PHEV662 PHEV663 PHEV664 PHEV665 PHEV666 PHEV667 PHEV668 PHEV669 PHEV670 PHEV671 PHEV672 PHEV673 PHEV674 PHEV675 PHEV676 PHEV677 PHEV678 PHEV679 PHEV680 PHEV681 PHEV682 PHEV683 PHEV684 PHEV685 PHEV686 PHEV687 PHEV688 PHEV689 PHEV690 PHEV691 PHEV692 PHEV693 PHEV694 PHEV695 PHEV696 PHEV697 PHEV698 PHEV699 PHEV700 PHEV701 PHEV702 PHEV703 PHEV704 PHEV705 PHEV706 PHEV707 PHEV708 PHEV709 PHEV710 PHEV711 PHEV712 PHEV713 PHEV714 PHEV715 PHEV716 PHEV717 PHEV718 PHEV719 PHEV720 PHEV721 PHEV722 PHEV723 PHEV724 PHEV725 PHEV726 PHEV727 PHEV728 PHEV729 PHEV730 PHEV731 PHEV732 PHEV733 PHEV734 PHEV735 PHEV736 PHEV737 PHEV738 PHEV739 PHEV740 PHEV741 PHEV742 PHEV743 PHEV744 PHEV745 PHEV746 PHEV747 PHEV748 PHEV749 PHEV750 PHEV751 PHEV752 PHEV753 PHEV754 PHEV755 PHEV756 PHEV757 PHEV758 PHEV759 PHEV760 PHEV761 PHEV762 PHEV763 PHEV764 PHEV765 PHEV766 PHEV767 PHEV768 PHEV769 PHEV770 PHEV771 PHEV772 PHEV773 PHEV774 PHEV775 PHEV776 PHEV777 PHEV778 PHEV779 PHEV780 PHEV781 PHEV782 PHEV783 PHEV784 PHEV785 PHEV786 PHEV787 PHEV788 PHEV789 PHEV790 PHEV791 PHEV792 PHEV793 PHEV794 PHEV795 PHEV796 PHEV797 PHEV798 PHEV799 PHEV800 PHEV801 PHEV802 PHEV803 PHEV804 PHEV805 PHEV806 PHEV807 PHEV808 PHEV809 PHEV810 PHEV811 PHEV812 PHEV813 PHEV814 PHEV815 PHEV816 PHEV817 PHEV818 PHEV819 PHEV820 PHEV821 PHEV822 PHEV823 PHEV824 PHEV825 PHEV826 PHEV827 PHEV828 PHEV829 PHEV830 PHEV831 PHEV832 PHEV833 PHEV834 PHEV835 PHEV836 PHEV837 PHEV838 PHEV839 PHEV840 PHEV841 PHEV842 PHEV843 PHEV844 PHEV845 PHEV846 PHEV847 PHEV848 PHEV849 PHEV850 PHEV851 PHEV852 PHEV853 PHEV854 PHEV855 PHEV856 PHEV857 PHEV858 PHEV859 PHEV860 PHEV861 PHEV862 PHEV863 PHEV864 PHEV865 PHEV866 PHEV867 PHEV868 PHEV869 PHEV870 PHEV871 PHEV872 PHEV873 PHEV874 PHEV875 PHEV876 PHEV877 PHEV878 PHEV879 PHEV880 PHEV881 PHEV882 PHEV883 PHEV884 PHEV885 PHEV886 PHEV887 PHEV888 PHEV889 PHEV890 PHEV891 PHEV892 PHEV893 PHEV894 PHEV895 PHEV896 PHEV897 PHEV898 PHEV899 PHEV900 PHEV901 PHEV902 PHEV903 PHEV904 PHEV905 PHEV906 PHEV907 PHEV908 PHEV909 PHEV910 PHEV911 PHEV912 PHEV913 PHEV914 PHEV915 PHEV916 PHEV917 PHEV918 PHEV919 PHEV920 PHEV921 PHEV922 PHEV923 PHEV924 PHEV925 PHEV926 PHEV927 PHEV928 PHEV929 PHEV930 PHEV931 PHEV932 PHEV933 PHEV934 PHEV935 PHEV936 PHEV937 PHEV938 PHEV939 PHEV940 PHEV941 PHEV942 PHEV943 PHEV944 PHEV945 PHEV946 PHEV947 PHEV948 PHEV949 PHEV950 PHEV	

133	Tachograph Total Vehicle Distance	4	Unsigned	0	4294967295	-	m	Tacho Total Vehicle Distance	ALLCAN300
134	Trip Distance	4	Unsigned	0	4294967295	-	m	Trip distance	ALLCAN300
135	Tachograph Vehicle Speed	2	Unsigned	0	255	-	km/h	Tacho vehicle speed	ALLCAN300
136	Tacho Driver Card Presence	1	Unsigned	0	3	-	-	Tacho Driver Card Presence	ALLCAN300
137	Driver 1 Status	1	Unsigned	0	255	-	-	Driver 1 Status	ALLCAN300
138	Driver 2 Status	1	Unsigned	0	255	-	-	Driver 2 Status	ALLCAN300
139	Driver 1 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Continuous Driving Time, minutes	ALLCAN300
140	Driver 2 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Continuous Driving Time, minutes	ALLCAN300
141	Driver 1 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Break Time, minutes	ALLCAN300
142	Driver 2 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Break Time, minutes	ALLCAN300
143	Driver 1 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 1 Duration Of Selected Activity, minutes	ALLCAN300
144	Driver 2 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 2 Duration Of Selected Activity, minutes	ALLCAN300
145	Driver 1 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Driving Time, minutes	ALLCAN300
146	Driver 2 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Driving Time, minutes	ALLCAN300
147	Driver 1 ID High	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 1 ID High	ALLCAN300
148	Driver 1 ID Low	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 1 ID Low	ALLCAN300
149	Driver 2 ID High	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 2 ID High	ALLCAN300
150	Driver 2 ID Low	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 2 ID Low	ALLCAN300
151	Battery Temperature	2	Signed	400	1270	0.1	°C	Battery temperature in Celsius	ALLCAN300
152	HV Battery Level	1	Unsigned	0	100	-	%	Battery level in percent	ALLCAN300; CANCONTROL
160	DTC Faults	1	Unsigned	0	255	-	-	DTC faults Count	ALLCAN300; CANCONTROL
161	Slope of Arms	2	Signed	-3276	3276	-	Degrees °	Slope Of Arms	ALLCAN200
162	Rotation of Arms	2	Signed	-180	180	-	Degrees °	Rotation Of Arms	ALLCAN200
163	Eject of Arms	2	Unsigned	0	6553	-	m	Eject of arms	ALLCAN200

164	Horizontal Distance Arm Vehicle	2	Unassigned	0	6553	-	m	Horizontal Distance Arm Vehicle	ALLCAN300
165	Height Arm Above Ground	2	Unassigned	0	6553	-	m	Height Arm Above Ground	ALLCAN300
166	Doll RPM	2	Unassigned	0	65535	-	rpm	Doll RPM	ALLCAN300
167	Amount Of Spread Salt Square Meter	2	Unassigned	0	655	-	g/m ²	Amount Of Spread Salt Square Meter	ALLCAN300
168	Battery Voltage	2	Unassigned	0	6553	-	V	Battery Voltage	ALLCAN300
169	Amount Of Spread Fine Grained Salt	4	Unassigned	0	1677722	-	T	Amount Of Spread Fine Grained Salt	ALLCAN300
170	Amount Of Coarse Grained Salt	4	Unassigned	0	1677722	-	T	Amount Of Coarse Grained Salt	ALLCAN300
171	Amount Of Spread Dbls	4	Unassigned	0	1677722	-	T	Amount Of Spread Dbls	ALLCAN300
172	Amount Of Spread Coarse Grained Calcium	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Coarse Grained Calcium	ALLCAN300
173	Amount Of Spread Calcium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Calcium Chloride	ALLCAN300
174	Amount Of Spread Sodium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Sodium Chloride	ALLCAN300
176	Amount Of Spread Magnesium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Magnesium Chloride	ALLCAN300
177	Amount Of Spread Gravel	4	Unassigned	0	1677722	-	T	Amount Of Spread Gravel	ALLCAN300
178	Amount Of Spread Sand	4	Unassigned	0	1677722	-	T	Amount Of Spread Sand	ALLCAN300
183	Width Pouring Left	2	Unassigned	0	655	-	m	Width Pouring Left	ALLCAN300
184	Width Pouring Right	2	Unassigned	0	655	-	m	Width Pouring Right	ALLCAN300
185	Salt Spreader Working Hours	4	Unassigned	0	167722	-	h	Salt Spreader Working Hours	ALLCAN300
186	Distance During Salting	4	Unassigned	0	167722	-	km	Distance During Salting	ALLCAN300
187	Load Weight	4	Unassigned	0	16772215	-	kg	Load Weight	ALLCAN300
188	Retarder Load	1	Unassigned	0	130	-	%	Retarder Load in percent	ALLCAN300
189	Cruise Time	4	Unassigned	0	16772215	-	min	Cruise time in minutes	ALLCAN300
232	CNG Status	1	Unassigned	0	1	-	-	CNG Status	LUCAN200, CANCONTROL
233	CNG Used	4	Unassigned	0	16772215	-	kg	CNG used	LUCAN200, CANCONTROL

234	CNG Level	1	Unsigned	0	100	-	%	CNG Level	FMI00XX FMI001 FMI002 FMI003 FMI004 FMI005 FMI006 FMI007 FMI008 FMI009 FMI010 FMI011 FMI012 FMI013 FMI014 FMI015 FMI016 FMI017 FMI018 FMI019 FMI020	LVCAN200, CANCONTROL
235	Oil Level	1	Unsigned	0	1	-	-	Engine Oil Level Indicator Status	FMI00XX FMI021 FMI022 FMI023 FMI024 FMI025 FMI026 FMI027 FMI028 FMI029 FMI030	ALLCAN300, CANCONTROL
304	Vehicles Range On Battery	4	Unsigned	0	16771215	-	m	Vehicle Range on Battery	FMI00XX FMI031 FMI032 FMI033 FMI034 FMI035 FMI036 FMI037 FMI038 FMI039 FMI040	ALLCAN300, CANCONTROL
305	Vehicles Range On Additional Fuel	4	Unsigned	0	16771215	-	m	Vehicle Range On Additional Fuel	FMI00XX FMI041 FMI042 FMI043 FMI044 FMI045 FMI046 FMI047 FMI048 FMI049	ALLCAN300, CANCONTROL
325	VIN	17	ASCII	0	0aFF	-	-	VIN number	FMI00XX FMI050 FMI051 FMI052 FMI053 FMI054 FMI055 FMI056 FMI057 FMI058 FMI059 FMI060	CANCONTROL
282	Fault Codes	Variable	-	0	128	-	-	DTC Fault codes	FMI00XX FMI061 FMI062 FMI063 FMI064 FMI065 FMI066 FMI067 FMI068 FMI069	LV-CAN200 + DTC
517	Security State Flags P4	8	HEX	0	0a000000	-	-	Security state flags protocol 4, more information click here Link	FMI00XX FMI070	ALLCAN300
518	Control State Flags P4	8	HEX	0	0a000000	-	-	Control state flags protocol 4, more information click here Link	FMI00XX FMI071	ALLCAN300
519	Indicator State Flags P4	8	HEX	0	0a000000	-	-	Indicator state flags protocol 4, more information click here Link	FMI00XX FMI072	ALLCAN300
520	Agricultural State Flags P4	8	HEX	0	0a000000	-	-	Agricultural state flags protocol 4, more information click here Link	FMI00XX FMI073	ALLCAN300
521	Utility State Flags P4	8	HEX	0	0a000000	-	-	Utility state flags protocol 4, more information click here Link	FMI00XX FMI074	ALLCAN300
522	Custom State Flags P4	8	HEX	0	0a000000	-	-	Custom state flags protocol 4, more information click here Link	FMI00XX FMI075	ALLCAN300
855	LNG Used	4	Unsigned	0	214748364	-	kg	Total LNG used in kilograms	FMI00XX FMI076	ALLCAN300, CANCONTROL
856	LNG Used (converted)	4	Unsigned	0	214748364	-	kg	Total LNG used converted in kg	FMI00XX FMI077	ALLCAN300, CANCONTROL
857	LNG Level	2	Unsigned	0	100	-	%	LNG level in perc	FMI00XX FMI078	ALLCAN300, CANCONTROL
858	LNG Level	2	Unsigned	0	6535	-	kg	LNG level in kg	FMI00XX FMI079	ALLCAN300, CANCONTROL
1100	Total LPG Used	4	Unsigned	0	4296987295	-	l	Total LPG used in liters	FMI00XX FMI080	LVCAN
1101	Total LPG Used Counted	4	Unsigned	0	4296987295	-	l	Total LPG used counted in liters	FMI00XX FMI081	LVCAN
1102	LPG Level Prec	2	Unsigned	0	6535	-	%	LPG level in perc	FMI00XX FMI082	LVCAN
1103	LPG Level Liters	2	Unsigned	0	6535	-	l	LPG level in liters	FMI00XX FMI083	LVCAN
898	SSF Ignition	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI084 FMI085 FMI086 FMI087 FMI088 FMI089 FMI090	LVCAN, ALLCAN300, CANCONTROL
852	SSF KeySignalLock	1	Unsigned	0	1	-	-	0 - No key in lock 1 - Key in lock	FMI00XX FMI091 FMI092 FMI093 FMI094 FMI095 FMI096	ALLCAN300, CANCONTROL
899	SSF Windows	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI097 FMI098 FMI099 FMI100 FMI101	ALLCAN300
900	SSF Engine Working	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI102 FMI103 FMI104 FMI105 FMI106	ALLCAN300, CANCONTROL
901	SSF Standalone Engine	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI107 FMI108 FMI109 FMI110	ALLCAN300
902	SSF Ready To Drive	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI111 FMI112 FMI113 FMI114	ALLCAN300, CANCONTROL
903	SSF Engine Working On CNG	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI115 FMI116 FMI117 FMI118	ALLCAN300, CANCONTROL
904	SSF Work Mode	1	Unsigned	0	1	-	-	0 - Private 1 - Company	FMI00XX FMI119 FMI120 FMI121 FMI122	ALLCAN300
905	SSF Operator	1	Unsigned	0	1	-	-	0 - Not present 1 - Present	FMI00XX FMI123 FMI124 FMI125 FMI126	ALLCAN300
906	SSF Interlock	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMI00XX FMI127 FMI128 FMI129 FMI130	ALLCAN300
907	SSF Engine Lock Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMI00XX FMI131 FMI132 FMI133 FMI134	CANCONTROL
908	SSF Request To Lock Engine	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMI00XX FMI135 FMI136 FMI137 FMI138	CANCONTROL
653	SSF Handbrake Is Active	1	Unsigned	0	1	-	-	0 - Handbrake inactive 1 - Handbrake active	FMI00XX FMI139 FMI140 FMI141 FMI142	ALLCAN300, CANCONTROL
910	SSF Footbrake Is Active	1	Unsigned	0	1	-	-	0 - Footbrake inactive 1 - Footbrake active	FMI00XX FMI143 FMI144 FMI145 FMI146	ALLCAN300, CANCONTROL
911	SSF Clutch Pushed	1	Unsigned	0	1	-	-	0 - Clutch is pushed 1 - Clutch is not pushed	FMI00XX FMI147 FMI148 FMI149 FMI150	ALLCAN300, CANCONTROL
912	SSF Hazard Warning Lights	1	Unsigned	0	1	-	-	0 - Hazard warning lights on 1 - Hazard warning lights off	FMI00XX FMI151 FMI152 FMI153 FMI154	ALLCAN300, CANCONTROL

971	ISF FAP Indicator	1	Unassigned	0	1	-	-	0 - Off 1 - On	PMHXXY Page 10 256-100 256-101 256-102 256-103 256-104 256-105 256-106 256-107 256-108 256-109 256-110 256-111 256-112 256-113 256-114 256-115 256-116 256-117 256-118 256-119 256-120 256-121 256-122 256-123 256-124 256-125 256-126 256-127 256-128 256-129 256-130 256-131 256-132 256-133 256-134 256-135 256-136 256-137 256-138 256-139 256-140 256-141 256-142 256-143 256-144 256-145 256-146 256-147 256-148 256-149 256-150 256-151 256-152 256-153 256-154 256-155 256-156 256-157 256-158 256-159 256-160 256-161 256-162 256-163 256-164 256-165 256-166 256-167 256-168 256-169 256-170 256-171 256-172 256-173 256-174 256-175 256-176 256-177 256-178 256-179 256-180 256-181 256-182 256-183 256-184 256-185 256-186 256-187 256-188 256-189 256-190 256-191 256-192 256-193 256-194 256-195 256-196 256-197 256-198 256-199 256-200 256-201 256-202 256-203 256-204 256-205 256-206 256-207 256-208 256-209 256-210 256-211 256-212 256-213 256-214 256-215 256-216 256-217 256-218 256-219 256-220 256-221 256-222 256-223 256-224 256-225 256-226 256-227 256-228 256-229 256-230 256-231 256-232 256-233 256-234 256-235 256-236 256-237 256-238 256-239 256-240 256-241 256-242 256-243 256-244 256-245 256-246 256-247 256-248 256-249 256-250 256-251 256-252 256-253 256-254 256-255 256-256 256-257 256-258 256-259 256-260 256-261 256-262 256-263 256-264 256-265 256-266 256-267 256-268 256-269 256-270 256-271 256-272 256-273 256-274 256-275 256-276 256-277 256-278 256-279 256-280 256-281 256-282 256-283 256-284 256-285 256-286 256-287 256-288 256-289 256-290 256-291 256-292 256-293 256-294 256-295 256-296 256-297 256-298 256-299 256-300 256-301 256-302 256-303 256-304 256-305 256-306 256-307 256-308 256-309 256-310 256-311 256-312 256-313 256-314 256-315 256-316 256-317 256-318 256-319 256-320 256-321 256-322 256-323 256-324 256-325 256-326 256-327 256-328 256-329 256-330 256-331 256-332 256-333 256-334 256-335 256-336 256-337 256-338 256-339 256-340 256-341 256-342 256-343 256-344 256-345 256-346 256-347 256-348 256-349 256-350 256-351 256-352 256-353 256-354 256-355 256-356 256-357 256-358 256-359 256-360 256-361 256-362 256-363 256-364 256-365 256-366 256-367 256-368 256-369 256-370 256-371 256-372 256-373 256-374 256-375 256-376 256-377 256-378 256-379 256-380 256-381 256-382 256-383 256-384 256-385 256-386 256-387 256-388 256-389 256-390 256-391 256-392 256-393 256-394 256-395 256-396 256-397 256-398 256-399 256-400 256-401 256-402 256-403 256-404 256-405 256-406 256-407 256-408 256-409 256-410 256-411 256-412 256-413 256-414 256-415 256-416 256-417 256-418 256-419 256-420 256-421 256-422 256-423 256-424 256-425 256-426 256-427 256-428 256-429 256-430 256-431 256-432 256-433 256-434 256-435 256-436 256-437 256-438 256-439 256-440 256-441 256-442 256-443 256-444 256-445 256-446 256-447 256-448 256-449 256-450 256-451 256-452 256-453 256-454 256-455 256-456 256-457 256-458 256-459 256-460 256-461 256-462 256-463 256-464 256-465 256-466 256-467 256-468 256-469 256-470 256-471 256-472 256-473 256-474 256-475 256-476 256-477 256-478 256-479 256-480 256-481 256-482 256-483 256-484 256-485 256-486 256-487 256-488 256-489 256-490 256-491 256-492 256-493 256-494 256-495 256-496 256-497 256-498 256-499 256-500 256-501 256-502 256-503 256-504 256-505 256-506 256-507 256-508 256-509 256-510 256-511 256-512 256-513 256-514 256-515 256-516 256-517 256-518 256-519 256-520 256-521 256-522 256-523 256-524 256-525 256-526 256-527 256-528 256-529 256-530 256-531 256-532 256-533 256-534 256-535 256-536 256-537 256-538 256-539 256-540 256-541 256-542 256-543 256-544 256-545
-----	-------------------	---	------------	---	---	---	---	-------------------	--

995	ASF Right Joystick Moved Forward Active	1	Unassigned	0	1	-	-	0 - Inactive 1 - Active	PMBXNXX 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 1060142 1060143 1060144 1060145 1060146 1060147 1060148 1060149 1060150 1060151 1060152 1060153 1060154 1060155 1060156 1060157 1060158 1060159 1060160 1060161 1060162 1060163 1060164 1060165 1060166 1060167 1060168 1060169 1060170 1060171 1060172 1060173 1060174 1060175 1060176 1060177 1060178 1060179 1060180 1060181 1060182 1060183 1060184 1060185 1060186 1060187 1060188 1060189 1060190 1060191 1060192 1060193 1060194 1060195 1060196 1060197 1060198 1060199 1060200 1060201 1060202 1060203 1060204 1060205 1060206 1060207 1060208 1060209 1060210 1060211 1060212 1060213 1060214 1060215 1060216 1060217 1060218 1060219 1060220 1060221 1060222 1060223 1060224 1060225 1060226 1060227 1060228 1060229 1060230 1060231 1060232 1060233 1060234 1060235 1060236 1060237 1060238 1060239 1060240 1060241 1060242 1060243 1060244 1060245 1060246 1060247 1060248 1060249 1060250 1060251 1060252 1060253 1060254 1060255 1060256 1060257 1060258 1060259 1060260 1060261 1060262 1060263 1060264 1060265 1060266 1060267 1060268 1060269 1060270 1060271 1060272 1060273 1060274 1060275 1060276 1060277 1060278 1060279 1060280 1060281 1060282 1060283 1060284 1060285 1060286 1060287 1060288 1060289 1060290 1060291 1060292 1060293 1060294 1060295 1060296 1060297 1060298 1060299 1060300 1060301 1060302 1060303 1060304 1060305 1060306 1060307 1060308 1060309 1060310 1060311 1060312 1060313 1060314 1060315 1060316 1060317 1060318 1060319 1060320 1060321 1060322 1060323 1060324 1060325 1060326 1060327 1060328 1060329 1060330 1060331 1060332 1060333 1060334 1060335 1060336 1060337 1060338 1060339 1060340 1060341 1060342 1060343 1060344 1060345 1060346 1060347 1060348 1060349 1060350 1060351 1060352 1060353 1060354 1060355 1060356 1060357 1060358 1060359 1060360 1060361 1060362 1060363 1060364 1060365 1060366 1060367 1060368 1060369 1060370 1060371 1060372 1060373 1060374 1060375 1060376 1060377 1060378 1060379 1060380 1060381 1060382 1060383 1060384 1060385 1060386 1060387 1060388 1060389 1060390 1060391 1060392 1060393 1060394 1060395 1060396 1060397 1060398 1060399 1060400 1060401 1060402 1060403 1060404 1060405 1060406 1060407 1060408 1060409 1060410 1060411 1060412 1060413 1060414 1060415 1060416 1060417 1060418 1060419 1060420 1060421 1060422 1060423 1060424 1060425 1060426 1060427 1060428 1060429 1060430 1060431 1060432 1060433 1060434 1060435 1060436 1060437 1060438 1060439 1060440 1060441 1060442 1060443 1060444 1060445 1060446 1060447 1060448 1060449 1060450 1060451 1060452 1060453 1060454 1060455 1060456 1060457 1060458 1060459 1060460 1060461 1060462 1060463 1060464 1060465 1060466 1060467 1060468 1060469 1060470 1060471 1060472 1060473 1060474 1060475 1060476 1060477 1060478 1060479 1060480 1060481 1060482 1060483 1060484 1060485 1060486 1060487 1060488 1060489 1060490 1060491 1060492 1060493 1060494 1060495 1060496 1060497 1060498 1060499 1060500 1060501 1060502 1060503 1060504 1060505 1060506 1060507 1060508 1060509 1060510 1060511 1060512 1060513 1060514 1060515 1060516 1060517 1060518 1060519 1060520 1060521 1060522 1060523 1060524 1060525 1060526 1060527 1060528 1060529 1060530 1060531 1060532 1060533 1060534 1060535 1060536 1060537 1060538 1060539 1060540 1060541 1060542 1060543 1060544 1060545 1060546 1060547 1060548 1060549 1060550 1060551 1060552 1060553 1060554 1060555 10
-----	---	---	------------	---	---	---	---	----------------------------	--

1019	ASF Unloader Drive	1	Unspnd	0	1	-	0 - Off 1 - On	PMBXN1 106110 106111 106112 106113 106114 106115 106116 106117 106118 106119 106120 106121 106122 106123 106124 106125 106126 106127 106128 106129 106130 106131 106132 106133 106134 106135 106136 106137 106138 106139 106140 106141 106142 106143 106144 106145 106146 106147 106148 106149 106150 106151 106152 106153 106154 106155 106156 106157 106158 106159 106160 106161 106162 106163 106164 106165 106166 106167 106168 106169 106170 106171 106172 106173 106174 106175 106176 106177 106178 106179 106180 106181 106182 106183 106184 106185 106186 106187 106188 106189 106190 106191 106192 106193 106194 106195 106196 106197 106198 106199 106200 106201 106202 106203 106204 106205 106206 106207 106208 106209 106210 106211 106212 106213 106214 106215 106216 106217 106218 106219 106220 106221 106222 106223 106224 106225 106226 106227 106228 106229 106230 106231 106232 106233 106234 106235 106236 106237 106238 106239 106240 106241 106242 106243 106244 106245 106246 106247 106248 106249 106250 106251 106252 106253 106254 106255 106256 106257 106258 106259 106260 106261 106262 106263 106264 106265 106266 106267 106268 106269 106270 106271 106272 106273 106274 106275 106276 106277 106278 106279 106280 106281 106282 106283 106284 106285 106286 106287 106288 106289 106290 106291 106292 106293 106294 106295 106296 106297 106298 106299 106300 106301 106302 106303 106304 106305 106306 106307 106308 106309 106310 106311 106312 106313 106314 106315 106316 106317 106318 106319 106320 106321 106322 106323 106324 106325 106326 106327 106328 106329 106330 106331 106332 106333 106334 106335 106336 106337 106338 106339 106340 106341 106342 106343 106344 106345 106346 106347 106348 106349 106350 106351 106352 106353 106354 106355 106356 106357 106358 106359 106360 106361 106362 106363 106364 106365 106366 106367 106368 106369 106370 106371 106372 106373 106374 106375 106376 106377 106378 106379 106380 106381 106382 106383 106384 106385 106386 106387 106388 106389 106390 106391 106392 106393 106394 106395 106396 106397 106398 106399 106400 106401 106402 106403 106404 106405 106406 106407 106408 106409 106410 106411 106412 106413 106414 106415 106416 106417 106418 106419 106420 106421 106422 106423 106424 106425 106426 106427 106428 106429 106430 106431 106432 106433 106434 106435 106436 106437 106438 106439 106440 106441 106442 106443 106444 106445 106446 106447 106448 106449 106450 106451 106452 106453 106454 106455 106456 106457 106458 106459 106460 106461 106462 106463 106464 106465 106466 106467 106468 106469 106470 106471 106472 106473 106474 106475 106476 106477 106478 106479 106480 106481 106482 106483 106484 106485 106486 106487 106488 106489 106490 106491 106492 106493 106494 106495 106496 106497 106498 106499 106500 106501 106502 106503 106504 106505 106506 106507 106508 106509 106510 106511 106512 106513 106514 106515 106516 106517 106518 106519 106520 106521 106522 106523 106524 106525 106526 106527 106528 106529 106530 106531 106532 106533 106534 106535 106536 106537 106538 106539 106540 106541 106542 106543 106544 106545 106546 106547 106548 106549 106550 106551 106552 106553 106554 106555 106556 106557 106558 106559 106560 106561 106562 106563 106564 106565 106566 106567 106568 106569 106570 106571 106572 106573 106574 106575 106576 106577 106578 106579 106580 106581 106582 106583 106584 106585 106586 106587 106588 106589 106590 106591 106592 106593 106594 106595 106596 106597 106598 106599 106600 106601 106602 106603 106604 106605 106606 106607 106608 106609 106610 106611 106612 106613 106614 106615 106616 106617 106618 106619 106620 106621 106622 106623 106624 106625 106626 106627 106628 106629 106630 106631 106632 106633 106634 106635 106636 106637 106638 106639 106640 106641 106642 106643 106644 106645 106646 106647 106648 106649 106650 106651 106652 106653 106654 106655 106656 106657 106658 106659 106660 106661 106662 106663 106664 106665 106666 106667 106668 106669 106670 106671 106672 106673 106674 106675 106676 106677 106678 106679 106680 106681 106682 106683 106684 106685 106686 106687 106688 106689 106690 106691 106692 106693 106694 106695 106696 106697 106698 106699 106700 106701 106702 106703 106704 106705 106706 106707 106708 106709 106710 106711 106712 106713 106714 106715 106716 106717 106718 106719 106720 106721 106722 106723 106724 106725 106726 106727 106728 106729 106730 106731 106732 106733 106734 106735 106736 106737 106738 106739 106740 106741 106742 106743 106744 106745 106746 106747 106748 106749 106750 106751 106752 106753 106754 106755 106756 106757 106758 106759 106760 106761 106762 106763 106764 106765 106766 106767 106768 106769 106770 106771 106772 106773 106774 106775 106776 106777 106778 106779 106780 106781 106782 106783 106784 106785 106786 106787 106788 106789 106790 106791 106792 106793 106794 106795 106796 106797 106798 106799 106800 106801 106802 106803 106804 106805 106806 106807 106808 106809 106810 106811 106812 106813 106814 106815 106816 106817 106818 106819 106820 106821 106822 106823 106824 106825 106826 106827 106828 106829 106830 106831 106832 106833 106834 106835 106836 106837 106838 106839 106840 106841 106842 106843 106844 106845 106846 106847 106848 106849 106850 106851 106852 106853 106854 106855 106856 106857 106858 106859 106860 106861 106862 106863 106864 106865 106866 106867 106868 106869 106870 106871 106872 106873 106874 106875 106876 106877 106878 106879 106880 106881 106882 106883 106884 106885 106886 106887 106888 106889 106890 106891 106892 106893 106894 106895 106896 106897 106898 106899 106900 106901 106902 106903 106904 106905 106906 106907 106908 106909 106910 106911 106912 106913 106914 106915 106916 106917 106918 106919 106920 106921 106922 106923 106924 106925 106926 106927 106928 106929 106930 106931 106932 106933 106934 106935 106936 106937 106938 106939 106940 106941 106942 106943 106944 106945 106946 106947 106948 106949 106950 106951 106952 106953 106954 106955 106956 106957 106958 106959 106960 106961 106962 106963 106964 106965 106966 106967 106968 106969 106970 106971 106972 106973 106974 106975 106976 106977 106978 106979 106980 106981 106982 106983 106984 106985 106986 106987 106988 106989 106990 106991 106992 106993 106994 106995 106996 106997 106998 106999 107000 107001 107002 107003 107004 107005 107006 107007 107008 107009 107010 107011 107012 107013 107014 107015 107016 107017 107018 107019 107020 107021 107022 107023 107024 107025 107026 107027 107028 107029 107030 107031 107032 107033 107034 107035 107036 107037 107038 107039 107040 107041 107042 107043 107044 107045 107046 107047 107048 107049 107050 107051 107052 107053 107054 107055 107056 107057 107058 107059 107060 107061 107062 107063 107064 107065 107066 107067 107068 107069 107070 107071 107072 107073 107074 107075 107076 107077 107078 107079 107080 107081 107082 107083 107084 107085 107086 107087 107088 107089 107090 107091 107092 107093 107094 107095 107096 107097 107098 107099 107100 107101 107102 107103 107104 107105 107106 107107 107108 107109 107110 107111 107112 107113 107114 107115 107116 107117 107118 107119 107120 107121 107122 107123 107124 107125 107126 107127 107128 107129 107130 107131 107132 107133 107134 107135 107136 107137 107138 107139 107140 107141 107142 107143 107144 107145 107146 107147 107148 107149 107150 107151 107152 107153 107154 107155 107156 107157 107158 107159 107160 107161 107162 107163 107164 107165 107166 107167 107168 107169 107170 107171 107172 107173 107174 107175 107176 107177 107178 107179 107180 107181 107182 107183 107184 107185 107186 107187 107188 107189 107190 107191 107192 107193 107194 107195 107196 107197 107198 107199 107200 107201 107202 107203 107204 107205 107206 107207 107208 107209 107210 107211 107212 107213 107214 107215 107216 107217 107218 107219 107220 107221 107222 107223 107224 107225 107226 107227 107228 107229 107230 107231 107232 107233 107234 107235 107236 107237 107238 107239 107240 107241 107242 107243 107244 107245 107246 107247 107248 107249 107250 107251 107252 107253 107254 107255 107256 107257 107258 107259 107260 107261 107262 107263 107264 107265 107266 107267 107268 107269 107270 107271 107272 107273 107274 107275 107276 107277 107278 107279 107280 107281 107282 107283 107284 107285 107286 107287 107288 107289 107290 107291 107292 107293 107294 107295 107296 107297 107298 107299 107300 107301 107302 107303 107304 107305 107306 107307 107308 107309 107310 107311 107312 107313 107314 107315 107316 107317 107318 107319 107320 107321 107322 107323 107324 107325 107326 107327 107328 107329 107330 107331 107332 107333 107334 107335 107336 107337 107338 107339 107340 107341 107342 107343 107344 107345 107346 107347 107348 107349 107350 107351 107352 107353 107354 107355 107356 107357 107358 107359 107360 107361 107362 107363 107364 107365 107366 107367 107368 107369 107370 107371 107372 107373 107374 107375 107376 107377 107378 107379 107380 107381 107382 107383 107384 107385 107386 107387 107388 107389 107390 107391 107392 107393 107394 107395 107396 107397 107398 107399 107400 107401 107402 107403 107404 107405 107406 107407 107408 107409 107410 107411 107412 107413 107414 107415 107416 107417 107418 107419 107420 107421 107422 107423 107424 107425 107426 107427 107428 107429 107430 107431 107432 107433 107434 107435 107436 107437 107438 107439 107440 107441 107442 107443 107444 107445 107446 107447 107448 107449 107450 107451 107452 107453 107454 107455 107456 107457 107458 107459 107460 107461 107462 107463 107464 107465 107466 107467 107468 107469 107470 107471 107472 107473 107474 107475 107476 107477 107478 107479 107480 107481 107482 107483 107484 107485 107486 107487 107488 107489 107490 107491 107492 107493 107494 107495 107496 107497 107498 107499 107500 107501 107502 107503 107504 107505 107506 107507 107508 107509 107510 107511 107512 107513 107514 107515 107516 107517 107518 107519 107520 107521 107522 107523 107524 107525 107526 107527 107528 107529 107530 107531 107532 107533 107534 107535 107536 107537 107538 107539 107540 107541 107542 107543 107544 107545 107546 107547 107548 107549 107550 107551 107552 107553 107554 107555 107556 107557 107558 107559 107560 107561 107562 107563 107564 107565 107566 107567 107568 107569 107570 107571 107572 107573 107574 107575 107576 107577 107578 107579 107580 107581 107582 107583 107584 107585 107586 107587 107588 107589 107590 107591 107592 107593 107594 107595 107596 107597 107598 107599 107600 107601 107602 107603 107604 107605 107606 107607 107608 107609 107610 107611 107612 107613 107614 107615 107616 107617 107618 107619 107620 107621 107622 107623 107624 107625 107626 107627 107628 107629 107630 107631 107632 107633 107634 107635 107636 107637 107638 107639 107640 107641 107642 107643 107644 107645 107646 107647 107648
------	--------------------	---	--------	---	---	---	-------------------	---

Item ID	Item Name	Quantity	Unit	Material	Part Number	Manufacturer	Notes	Comments	Location
1004	ASF Section 5 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1005	ASF Section 6 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1006	ASF Section 7 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1007	ASF Section 8 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1008	ASF Section 9 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1009	USF Spreading	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1010	USF Paving Chemicals	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1011	USF Conveyor Belt	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1012	USF Salt Spreader's Drive Wheel	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1013	USF Brushes	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1014	USF Vacuum Cleaner	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1015	USF Water Supply	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1016	USF Spreading	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1017	USF Liquid pump	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1018	USF Unloading From The Hopper	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1019	USF Low Salt (Sand) Level in Container Indicator	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1020	USF Low Water Level in Container Indicator	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1021	USF Chemicals	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1022	USF Compressor	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1023	USF Water Valve is Opened	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1024	USF Cabin Moved Up Status Active	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1025	USF Cabin Moved Down Status Active	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1026	USF Hydraulics Work Not Permitted	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1027	OSF Section 1 Presence Of Fluid In The Downspout	1	Unsprayed	0	1	-	0 - No pressure 1 - Present		ALLCAN000

ID	Section	Status	0 - No	1 - Yes
1014	CSP Section 1 Filled	Unassigned	0 - No 1 - Yes	
1015	CSP Section 1 Overfilled	Unassigned	0 - No 1 - Yes	
1016	CSP Section 2 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1017	CSP Section 2 Filled	Unassigned	0 - No 1 - Yes	
1018	CSP Section 2 Overfilled	Unassigned	0 - No 1 - Yes	
1019	CSP Section 3 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1020	CSP Section 3 Filled	Unassigned	0 - No 1 - Yes	
1021	CSP Section 3 Overfilled	Unassigned	0 - No 1 - Yes	
1022	CSP Section 4 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1023	CSP Section 4 Filled	Unassigned	0 - No 1 - Yes	
1024	CSP Section 4 Overfilled	Unassigned	0 - No 1 - Yes	
1025	CSP Section 5 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1026	CSP Section 5 Filled	Unassigned	0 - No 1 - Yes	
1027	CSP Section 5 Overfilled	Unassigned	0 - No 1 - Yes	
1028	CSP Section 6 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1029	CSP Section 6 Filled	Unassigned	0 - No 1 - Yes	
1030	CSP Section 6 Overfilled	Unassigned	0 - No 1 - Yes	
1031	CSP Section 7 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1032	CSP Section 7 Filled	Unassigned	0 - No 1 - Yes	
1033	CSP Section 7 Overfilled	Unassigned	0 - No 1 - Yes	
1034	CSP Section 8 Presence Of Fluid In The Dowscope	Unassigned	0 - No presence 1 - Present	
1035	CSP Section 8 Filled	Unassigned	0 - No 1 - Yes	
1036	CSP Section 8 Overfilled	Unassigned	0 - No 1 - Yes	
1037	Datasheet to Next Service	Unassigned	0 - No 1 - Yes	

430	CNG Level Kg	2	Unsigned	0	65535	10	Kg	CNG Level Kg (appears only if CNG level percentage is not available)	CAN adapters
839	Distance from need of service	4	Unsigned	0	4294967295	-	km	Service - distance elapsed since the occurrence of the need for servicing	CAN adapters
840	Distance from last service	4	Unsigned	0	4294967295	-	km	Service - distance from the last service	CAN adapters
861	Time to next service	2	Unsigned	0	65535	-	day	Service - time to next service	CAN adapters
862	Time from need of service	2	Unsigned	0	65535	-	day	Service - time elapsed since the occurrence of the need for servicing	CAN adapters
863	Time from last service	2	Unsigned	0	65535	-	day	Service - time elapsed since the last service	CAN adapters
864	Distance to next oil service	4	Unsigned	0	4294967295	-	km	Service - distance to next oil service	CAN adapters
865	Time to next oil service	2	Unsigned	0	65535	-	day	Service - time to next oil service	CAN adapters
866	LVCAN Vehicle Range	4	Unsigned	0	4294967295	-	km	Information about vehicle range	CAN adapters
867	LVCAN Total CNG counted	4	Unsigned	0	65535	-	kg	Information about Total CNG used in counted mode	CAN adapters
1079	Total Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Total Bule Count	CAN adapters
1080	Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Bule Count	CAN adapters
1081	Cut Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Cut Bule Count	CAN adapters
1082	Bule Slices	4	Unsigned	0	0aFFFFFF	-	-	Bule Slices	CAN adapters
1116	LVCAN MaxRoadSpeed	1	Unsigned	0	255	-	km/h	Maximum speed from road signs	CAN adapters
1117	LVCAN ExceededRoadSpeed	1	Unsigned	0	255	-	km/h	Exceeded speed from road signs	CAN adapters
1205	LVCAN RSP SpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value" is recognized/cancelled	CAN adapters
1206	LVCAN RSP EndOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "End of speed limit with value" is recognized/cancelled	CAN adapters
1207	LVCAN RSP SpeedExceeded	1	Unsigned	0	1	-	-	Information if speed is exceeded indicated by road sign "Speed limit with value"	CAN adapters
1208	LVCAN RSP TimeOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Conditional time-specific speed limit with value" is recognized/cancelled	CAN adapters
1209	LVCAN RSP WthrSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value due to weather conditions" is recognized/cancelled	CAN adapters