Company and User role structure

This chapter explains company and user structure, as well as privileges for user roles.

COMPANY STRUCTURE

FOTA WEB has two tiers of companies.

TIER	USER ROLES	DESCRIPTION
Root	Integrator	This is a top-level company, usually a Distributor.
Child	User	This is a second level company, usually an end-customer.

Child companies are their own separate domains, whereas **root** company oversees all of the **child** companies.



USER ROLES

Following is a general overview of User roles (privileges) in the FOTA WEB platform.

USER ROLE			
ACTIONS	INTEGRATOR	USER	
CREATE COMPANY	~	×	
CREATE USER	~	~	
ADD FILES	✓	~	
CREATE GROUPS	~	~	

Unlike **integrator**, a **user** cannot create additional companies.

The only other difference between **user** and **integrator**, is that the former can not download **continuous logs**.

 $Next\ chapter\ \underline{Account\ Settings}$