

FM36 flush

Initiates all data sending by GPRS to specified target server. Comma separated parameters go as numbered:

1. - IMEI
2. - APN
3. - GPRS LOGIN
4. - GPRS PASSWORD
5. - IP
6. - PORT
7. - MODE (0-TCP/1-UDP)

Parameters are separated by comma (no spaces needed). In case you don't need to enter parameter (Login/Pass) - do not put space, simply put comma and write next parameter.

- Example: opa opa flush 353976012555151,banga,,,212.47.99.62,12050,0

Response details	Description
FLUSH SMS Accepted	FLUSH SMS Accepted
# records found on FLASH	Number of records found on FLASH
Minimum Records to Send:	Number of minimum saved records to send
#	
GPRS Enabled:	State of the GPRS connection, 0 - disabled; 1 - enabled
#	
Time Sync: #	Indicates time synchronization on the device, 0 - not synchronized; 1 - synchronized

- Example: FLUSH SMS Accepted. 11 records found on FLASH. Minimum Records to Send: 1. GPRS Enabled: 1. Time Sync: 1.