

# FM36 flush

Initiates all data sending by GPRS to specified target server. Comma separated parameters go as numbered:

1. - IMEI
2. - APN
3. - GPRS LOGIN
4. - GPRS PASSWORD
5. - IP
6. - PORT
7. - MODE (0-TCP/1-UDP)

Parameters are separated by comma (no spaces needed). In case you don't need to enter parameter (Login/Pass) - do not put space, simply put comma and write next parameter.

- Example: opa opa flush 353976012555151,banga,,,212.47.99.62,12050,0

Response details	Description
<b>FLUSH SMS Accepted</b>	FLUSH SMS Accepted
<b># records found on FLASH</b>	Number of records found on FLASH
<b>Minimum Records to Send:</b>	Number of minimum saved records to send
<b>#</b>	
<b>GPRS Enabled:</b>	State of the GPRS connection, 0 - disabled; 1 - enabled
<b>#</b>	
<b>Time Sync: #</b>	Indicates time synchronization on the device, 0 - not synchronized; 1 - synchronized

- Example: FLUSH SMS Accepted. 11 records found on FLASH. Minimum Records to Send: 1. GPRS Enabled: 1. Time Sync: 1.