

https://wiki.teltonika-gps.com/view/FM36_setparam

FM36 setparam

Sets new value for parameter. ID consists of 3 or 4 digits. Detailed list of parameters and IDs can be found in chapter number 8 "Parameter List"

- Example: 'setparam 1245 127.0.0.1' will change configured IP address.