

https://wiki.teltonika-gps.com/view/FM36_sn

FM36 sn

Enables or disables Static navigation. 1 - enable, 0 - disable.