

[https://wiki.teltonika-gps.com/view/FM36\\_sn](https://wiki.teltonika-gps.com/view/FM36_sn)

## **FM36 sn**

Enables or disables Static navigation. 1 - enable, 0 - disable.