

FM6320 SMS Events

FM6320 is able to send SMS messages to PreDefined phone numbers from *SMS Events Numbers* tab (recipients) if any of selected events are triggered. User can send SMS alert message of selected event to maximum 10 preDefined phone numbers. AVL ID of parameter has to be entered in configuraton to receive its SMS event. PreDfined phone numbers must be entered in SMS Events Numbers list. Maximum 10 recipients are allowed in SMS Events Numbers list:



In the SMS Events section, user can connect specific AVL ID with number from PreDefined numbers list and custom SMS message text to make a single combination of SMS event parameters whose will be triggered after any event with that AVL ID is generated.

