

https://wiki.teltonika-gps.com/view/FMA_getio

FMA getio

Example:

"DI1:0 DI2:0 DI3:0 AIN:0.0611 DO1:0 DO2:0"

Response details	Description
DI#	Digital Input state.
AIN#	Analog Input state.
DO#	Digital Output state.