

https://wiki.teltonika-gps.com/view/FMA_readops

FMA readops

readops #

Send from device Operator List.

1 - send first 20 operator codes.

2 - send from 21st to 40th operator codes.

3 - send all other operator codes.