

https://wiki.teltonika-gps.com/view/FMA_sn

FMA sn

sn #

Enables or disables Static navigation. 1 - enable, 0 - disable.