

[https://wiki.teltonika-gps.com/view/FMB125\\_getio](https://wiki.teltonika-gps.com/view/FMB125_getio)

## FMB125 getio

Example:

"DI1:0 AIN1:0 DO1:0"

Response details	Description
<b>DI1</b>	Digital input 1 value.
<b>AIN1</b>	Analog input 1 value.
<b>DO1</b>	Digital output 1 value.