

FMB910 Basic LED status

[FMB910 Basic](#) > [FMB910 Basic Manual](#) > **FMB910 Basic LED status**

This section is an explanation of LED indications on a FMB910 device.

Status LED Indications

Behaviour	Meaning
Blinking every second	Normal mode
Blinking every two seconds	Sleep mode
Blinking fast for a short time	Modem activity
Off	Device is not working or Device is in boot mode