

# FMB braminfo

<b>Response details</b>	<b>Description</b>
<b>Boot</b>	Bootloader parameter
<b>Uptime</b>	Device uptime
<b>RST</b>	Device reset counter
<b>IWDF_RST</b>	Independent watchdog reset counter
<b>BadRec</b>	Bad record counter
<b>AD</b>	Authorized driving state
<b>GD</b>	ECO driving/Green driving state
<b>IM</b>	Immobilizer state