

## FMB flush



Initiates all data sending by GPRS to specified target server. Comma separated parameters go as numbered:

1. # - IMEI
2. # - APN
3. # - GPRS LOGIN
4. # - GPRS PASSWORD
5. # - IP
6. # - PORT
7. # - MODE (0-TCP/1-UDP)

Example:

```
user psw flush 353976012555151,banga,,,212.47.99.62,12050,0
```

Answer:

FLUSH SMS Accepted. 11 records found on FLASH. Minimum Records to Send: 1.  
GPRS Enabled: 1. Time Sync: 1

<b>Response details</b>	<b>Description</b>	<b>Description</b>
<b>FLUSH SMS Accepted</b>	FLUSH SMS Accepted	FLUSH SMS Accepted
<b># records found on FLASH</b>	Number of records found on FLASH	11 records found on FLASH
<b>Minimum Records to Send: #</b>	Number of minimum saved records to send	Minimum Records to Send: 1
<b>GPRS Enabled: #</b>	State of the GPRS connection: 0 - Disabled 1 - Enabled	GPRS Enabled: 1
<b>Time Sync: #</b>	Indicates time synchronization on the device: 0 - Not synchronized 1 - Synchronized	Time Sync: 1

**NOTE!** Parameters are separated by comma (no spaces needed). In case you do not need to enter parameter (APN Login/APN Pass) - do not put space, simply put comma and enter next parameter.