

FMB flush



Initiates all data sending by GPRS to specified target server. Comma separated parameters go as numbered:

1. # - IMEI
2. # - APN
3. # - GPRS LOGIN
4. # - GPRS PASSWORD
5. # - IP
6. # - PORT
7. # - MODE (0-TCP/1-UDP)

Example:

```
user psw flush 353976012555151,banga,,,212.47.99.62,12050,0
```

Answer:

FLUSH SMS Accepted. 11 records found on FLASH. Minimum Records to Send: 1.
GPRS Enabled: 1. Time Sync: 1

Response details	Description	Description
FLUSH SMS Accepted	FLUSH SMS Accepted	FLUSH SMS Accepted
# records found on FLASH	Number of records found on FLASH	11 records found on FLASH
Minimum Records to Send: #	Number of minimum saved records to send	Minimum Records to Send: 1
GPRS Enabled: #	State of the GPRS connection: 0 - Disabled 1 - Enabled	GPRS Enabled: 1
Time Sync: #	Indicates time synchronization on the device: 0 - Not synchronized 1 - Synchronized	Time Sync: 1

NOTE! Parameters are separated by comma (no spaces needed). In case you do not need to enter parameter (APN Login/APN Pass) - do not put space, simply put comma and enter next parameter.