

[https://wiki.teltonika-gps.com/view/FMB\\_getimeiccid](https://wiki.teltonika-gps.com/view/FMB_getimeiccid)

# FMB getimeiccid



**NOTE!**Response is sent to the SMS/GPRS command sender and also to GSM number provided (If provided).

This command can be sent without providing a GSM number in the command.

Response:

"IMEI: #####, CCID: #####"

## **Example of command and response without providing the GSM number:**

Command:

"SMSlogin SMSpass getimeiccid"

Response:

"IMEI: 358480084593450, CCID: 8937002180500123456"

## **Example of command and response with provided GSM number:**

Command:

"SMSlogin SMSpass getimeiccid 37055464928136"

Response received by sender:

"IMEI: 358480084593450, CCID: 8937002180500123456"

Response received by the GSM number provided:

"IMEI: 358480084593450, CCID: 8937002180500123456"