

[https://wiki.teltonika-gps.com/view/FMB\\_getops](https://wiki.teltonika-gps.com/view/FMB_getops)

# FMB getops

Returns list of current available allowed operators.

## Response:

```
(2,"24602","24602","24602",0),(3,"24601","24601","24601",0),(3,"24603","24603","24603",0),
```

## Operator type:

- 0 Unknown
- 1 Operator available
- 2 Current operator
- 3 Operator forbidden

## Access Networks:

- 0 GSM
- 2 UTRAN
- 3 GSM W/EGPRS
- 4 UTRAN W/HSDPA
- 5 UTRAN W/HSUPA
- 6 UTRAN W/HSDPA and HSUPA
- 7 E-UTRAN
- 100 CDMA

## Example:

```
"(2,"LT BITE GSM","BITE","24602",0),(3,"TELE2","TELE2","24603",0)"
```