

# FMC640 Configuration

[Main Page](#) > [EOL Products](#) > [FMC640](#) > **FMC640 Configuration**

## Teltonika Configurator

- [Status info](#) **[Show more]**
  - [Device Info](#)
  - [GNSS Info](#)
  - [GSM Info](#)
  - [I/O Info](#)
  - [FMS I/O Info](#)
  - [Tachograph Data Info](#)
  - [Maintenance](#)
  - [LLS Calibration](#)
  - [CAN Adapter Info](#)
- [Security info](#)
- [System settings](#) **[Show more]**
  - [Sleep Mode](#)
  - [System Settings](#)
  - [IO Global Settings](#)
  - [Protocol Settings](#)
  - [Records Settings](#)
  - [Static Navigation Settings](#)
  - [Ignition Source](#)
  - [Time Synchronization Settings](#)
- [GPRS settings](#)
- [Data acquisition settings](#)
- [SMS/Call settings](#) **[Show more]**
  - [SMS commands](#)
  - [Incoming Call settings](#)
  - [Hands Free Call settings](#)
- [SMS events](#)

- [GSM Operators settings](#)
- [Features settings](#) **[Show more]**
  - [Green Driving](#)
  - [Over Speeding](#)
  - [Jamming](#)
  - [DOUT Control via Call](#)
  - [Authorized driving/Immobilizer](#)
  - [iButton read notification](#)
  - [Short burst data settings](#)
- [Accelerometer Features settings](#) **[Show more]**
  - [Accelerometer Calibration](#)
  - [Excessive Idling](#)
  - [Towing Detection](#)
  - [Crash Detection](#)
- [Auto Geofence settings](#)
- [Manual Geofence settings](#)
- [Manual Geofence Zones](#)
- [Trip/Odometer settings](#) **[Show more]**
  - [Trip Settings](#)
  - [Advanced Trip Settings](#)
  - [Odometer](#)
- [iButton List settings](#)
- [I/O settings](#) **[Show more]**
  - [Operands](#)
  - [Avg Const](#)
- [LVCAN, FMS and Tachograph serial I/O](#) **[Show more]**
  - [LVCAN](#)
  - [FMS](#)

- [Tachograph Data](#)
  
- [Manual CAN IO](#) **[Show more]**
  - [Introduction](#)
  - [General description](#)
  - [Configuration](#)
  - [Example](#)
  
- [RS232 \ RS485](#) **[Show more]**
  - [RS-485 Interface](#)
  - [RS-232 Interface](#)
  - [LLS Sensor](#)
  - [Garmin protocols](#)
  
- [CAN \ Tachograph](#) **[Show more]**
  - [CAN \ Tachograph](#)
  - [Tachograph Settings](#)
  - [WEB Tacho Settings](#)
  - [FMS settings](#)
  
- [ContiPressureCheck](#) **[Show more]**
  - [Description](#)
  - [Configuration](#)
  - [External Links](#)
  
- [Custom scenarios](#)
- [Mobileye](#) **[Show more]**
  - [Introduction](#)
  - [Physical connection to Mobileye 5 CAN-A port](#)

- [FMB640 device configuration](#)
  
- [Reefer IO](#)
- [Bluetooth 4.0 Settings](#)
- [Beacon List](#) **[Show more]**
  - [Beacon Settings](#)
  - [Beacon List](#)