

# FMM250 SMS/GPRS Commands

[FMM250 Manual](#) > **FMM250 SMS/GPRS Commands**

## Commands apply for these devices:

[FMB001](#) [FMB010](#) [FMB002](#) [FMB020](#) [FMB003](#) [FMB110](#) [FMB120](#) [FMB122](#) [FMB125](#) [FMB130](#) [FMB202](#) [FMB204](#) [FMB208](#) [FMB900](#) [FMB920](#) [FMB962](#) [FMB964](#) [FM3001](#) [FMT100](#) [FMC001](#) [FMC003](#) [FMC00A](#) [FMM001](#) [FMM003](#) [FMM00A](#) [FMC125](#) [FMC130](#) [FMC150](#) [FMM125](#) [FMM130](#) [FMM150](#) [FMU125](#) [FMU126](#) [FMU130](#) [MTB100](#) [FMB140](#)

All commands are case sensitive. When user tries to send SMS/GPRS message to device that operates in Deep Sleep mode, it cannot arrive to it because the GSM/GPRS module is disabled most of the time. Device will receive the SMS message when it exits Deep Sleep mode, but GPRS commands will not be received after exiting Deep Sleep Mode.

If the device is in GPS Sleep or Online Deep Sleep mode, sent SMS/GPRS message will arrive to the device.

SMS command structure:

<SMS login><space><SMS password><space><command><space><value>

SMS command [getinfo](#) example:

- If you have set SMS login and password: login pass getinfo
- If SMS login and password are not set leave two spaces before command: getinfo

GPRS commands require [Codec 12](#) protocol.

□

## Contents

- [1 Commands apply for these devices:](#)
- [2 Common commands](#)
- [3 Bluetooth® Commands](#)
- [4 Commands Related to Features](#)
- [5 OBD Commands](#)
- [6 CAN Adapter Commands](#)

To search for compatible products, [Expand all content](#)

## Common commands

---

| Command | Description | Response | HW Support | Parameter Group |
|---------|-------------|----------|------------|-----------------|
|---------|-------------|----------|------------|-----------------|

|                           |   |     |  |                 |
|---------------------------|---|-----|--|-----------------|
| <a href="#">getinfo</a>   | Device runtime system information.  | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">getver</a>    | Returns code version, device IMEI, modem app version, RTC time, Init time, Uptime and BT MAC address. | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   | Common commands |
| <a href="#">getstatus</a> | Modem Status information.   | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   | Common commands |

|                        |   |     |  |                 |
|------------------------|---|-----|--|-----------------|
| <a href="#">getgps</a> | Current GPS data, date and time.                    | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">getio</a>  | Readout analog input,digital input and output.      | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">gaps</a>   | Returns location information with Google maps link. | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |

|                          |                                |     |  |                 |
|--------------------------|--------------------------------|-----|--|-----------------|
| <a href="#">radio #</a>  | Returns IO status, # AVL ID.   | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">cpureset</a> | Resets device                  | No  | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">fwstats</a>  | Get data about FW and restarts | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |

|                               |  |     |  |
|-------------------------------|--|-----|--|
| <a href="#">getrecord</a>     | SMS command initiates saving and sending of high priority record.  | No  | <p>Common commands</p> <p>FMBXXX<br/> FMB001<br/> FMC001<br/> FMB010<br/> FMB110<br/> FMB120<br/> FMB122<br/> FMB125<br/> FMB130<br/> FMB140<br/> FMB150<br/> FMC150<br/> FMM150<br/> FMB900<br/> FMB920<br/> FMB202<br/> FMB204<br/> FMB206<br/> FMT100<br/> FMP100<br/> FMC001<br/> FMC125<br/> FMC130<br/> FMM001<br/> FMM125<br/> FMM130<br/> FMC800<br/> FMM800<br/> FMM80A<br/> FMC880<br/> FMM880<br/> FMC250</p> |
| <a href="#">getimeiccid #</a> | Response is sent to SMS/GPRS command sender and also to GSM number provided. #<br>- GSM number using international format e.g. 37069012345   | Yes | <p>Common commands</p> <p>FMBXXX<br/> FMB001<br/> FMC001<br/> FMB010<br/> FMB110<br/> FMB120<br/> FMB122<br/> FMB125<br/> FMB130<br/> FMB140<br/> FMB150<br/> FMC150<br/> FMM150<br/> FMB900<br/> FMB920<br/> FMB202<br/> FMB204<br/> FMB206<br/> FMT100<br/> FMP100<br/> FMC001<br/> FMC125<br/> FMC130<br/> FMM001<br/> FMM125<br/> FMM130<br/> FMC800<br/> FMM800<br/> FMM80A<br/> FMC880<br/> FMM880<br/> FMC250</p> |
| <a href="#">getimsi</a>       | Sends the IMSI number of the SIM card inserted as a response to the sender.<br><br>If two SIM cards are inserted in the device, the response will be the IMSI number of the currently active SIM card.<br><br><b>Note: This command is supported from 03.10.02 firmware version.</b> | Yes | <p>Common commands</p> <p>FMBXXX<br/> FMB001<br/> FMC001<br/> FMB010<br/> FMB110<br/> FMB120<br/> FMB122<br/> FMB125<br/> FMB130<br/> FMB140<br/> FMB150<br/> FMC150<br/> FMM150<br/> FMB900<br/> FMB920<br/> FMB202<br/> FMB204<br/> FMB206<br/> FMT100<br/> FMP100<br/> FMC001<br/> FMC125<br/> FMC130<br/> FMM001<br/> FMM125<br/> FMM130<br/> FMC800<br/> FMM800<br/> FMM80A<br/> FMC880<br/> FMM880<br/> FMC250</p> |

|                                     |   |     |                 |  |
|-------------------------------------|---|-----|-----------------|--|
| <a href="#">allver</a>              | Responds with information about hardware and firmware versions and storage space  | Yes | Common commands | FMBXXX<br>FMB001<br>FMC001<br>FMB010<br>FMB110<br>FMB120<br>FMB122<br>FMB125<br>FMB130<br>FMB140<br>FMB150<br>FMC150<br>FMM150<br>FMB900<br>FMB920<br>FMB202<br>FMB204<br>FMB206<br>FMT100<br>FMP100<br>FMC001<br>FMC125<br>FMC130<br>FMM001<br>FMM125<br>FMM130<br>FMC800<br>FMM800<br>FMM80A<br>FMC880<br>FMM880<br>FMC250 |
| <a href="#">getparam #</a>          | Returns selected parameter value.<br># - first <a href="#">ID value</a> . # - second <a href="#">ID value</a> . # - third <a href="#">ID value</a> .<br>SMS command is limited to 160 characters. | Yes | Common commands | FMBXXX<br>FMB001<br>FMC001<br>FMB010<br>FMB110<br>FMB120<br>FMB122<br>FMB125<br>FMB130<br>FMB140<br>FMB150<br>FMC150<br>FMM150<br>FMB900<br>FMB920<br>FMB202<br>FMB204<br>FMB206<br>FMT100<br>FMP100<br>FMC001<br>FMC125<br>FMC130<br>FMM001<br>FMM125<br>FMM130<br>FMC800<br>FMM800<br>FMM80A<br>FMC880<br>FMM880<br>FMC250 |
| <a href="#">getparam #;#;#...</a>   |   |     |                 | FMBXXX<br>FMB001<br>FMC001<br>FMB010<br>FMB110<br>FMB120<br>FMB122<br>FMB125<br>FMB130<br>FMB140<br>FMB150<br>FMC150<br>FMM150<br>FMB900<br>FMB920<br>FMB202<br>FMB204<br>FMB206<br>FMT100<br>FMP100<br>FMC001<br>FMC125<br>FMC130<br>FMM001<br>FMM125<br>FMM130<br>FMC800<br>FMM800<br>FMM80A<br>FMC880<br>FMM880<br>FMC250 |
| <a href="#">setparam #;#</a>        | Sets selected parameter value<br>[Parameter ID] ; [New Parameter Value] ; [Parameter ID] ; [New Parameter Value]...<br>SMS command is limited to 160 characters.                                  | Yes | Common commands | FMBXXX<br>FMB001<br>FMC001<br>FMB010<br>FMB110<br>FMB120<br>FMB122<br>FMB125<br>FMB130<br>FMB140<br>FMB150<br>FMC150<br>FMM150<br>FMB900<br>FMB920<br>FMB202<br>FMB204<br>FMB206<br>FMT100<br>FMP100<br>FMC001<br>FMC125<br>FMC130<br>FMM001<br>FMM125<br>FMM130<br>FMC800<br>FMM800<br>FMM80A<br>FMC880<br>FMM880<br>FMC250 |
| <a href="#">setparam #;#;#;#...</a> |   |     |                 | FMBXXX<br>FMB001<br>FMC001<br>FMB010<br>FMB110<br>FMB120<br>FMB122<br>FMB125<br>FMB130<br>FMB140<br>FMB150<br>FMC150<br>FMM150<br>FMB900<br>FMB920<br>FMB202<br>FMB204<br>FMB206<br>FMT100<br>FMP100<br>FMC001<br>FMC125<br>FMC130<br>FMM001<br>FMM125<br>FMM130<br>FMC800<br>FMM800<br>FMM80A<br>FMC880<br>FMM880<br>FMC250 |

|                                       |   |     |                 |
|---------------------------------------|---|-----|-----------------|
| <a href="#">flush #.#.#.#.#.#.#.#</a> | <p>Redirects device to other server.</p> <p>1.# - IMEI.<br/> 2.# - APN.<br/> 3.# - LOGIN.<br/> 4.# - PASS.<br/> 5.# - IP.<br/> 6.# - PORT.<br/> 7.# - MODE (0-TCP/1-UDP).</p> | Yes | Common commands |
| <a href="#">countrecs</a>             | Returns records number.   | Yes | Common commands |
| <a href="#">web_connect</a>           | Forces device to connect to Fota WEB immediately.   | Yes | Common commands |

FMBXXX  
FMB001  
EMC001  
FMB010  
FMB110  
FMB120  
FMB122  
FMB125  
FMB130  
FMB140  
FMB150  
FMC150  
FMM150  
FMB900  
FMB920  
FMB202  
FMB204  
FMB206  
FMT100  
FMP100  
FMC001  
EMC125  
EMC130  
FMM001  
EMM125  
EMM130  
FMC800  
FMM800  
FMM80A  
FMC880  
FMM880  
FMC250

FMBXXX  
FMB001  
FMC001  
FMB010  
FMB110  
FMB120  
FMB122  
FMB125  
FMB130  
FMB140  
FMB150  
FMC150  
FMM150  
FMB900  
FMB920  
FMB202  
FMB204  
FMB206  
FMT100  
FMP100  
FMC001  
FMC125  
FMC130  
FMM001  
EMM125  
EMM130  
FMC800  
FMM800  
FMM80A  
FMC880  
FMM880  
FMC250

FMBXXX  
FMB001  
EMC001  
FMB010  
FMB110  
FMB120  
FMB122  
FMB125  
FMB130  
FMB140  
FMB150  
FMC150  
FMM150  
FMB900  
FMB920  
FMB202  
FMB204  
FMB206  
FMT100  
FMP100  
FMC001  
EMC125  
EMC130  
FMM001  
EMM125  
EMM130  
FMC800  
FMM800  
FMM80A  
FMC880  
FMM880  
FMC250

|  |  |     |  |                 |
|--|--|-----|--|-----------------|
|  |  |     | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">EMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   |                 |
| <a href="#">deleterecords</a>            | Delete all records from SD card.   | Yes |  | Common commands |
|  |  |     | <a href="#">FMBXXX</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB900</a><br><a href="#">FMB910</a><br><a href="#">FMB920</a><br><a href="#">FMB962</a><br><a href="#">FMB964</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB209</a><br><a href="#">FMC125</a><br><a href="#">FMM125</a><br><a href="#">FMU125</a><br><a href="#">FMC130</a><br><a href="#">FMM130</a><br><a href="#">FMU130</a><br><a href="#">FMU126</a><br><a href="#">MSP500</a>   |                 |
| <a href="#">setdigout</a> ## Y1 Y2 Z1 Z2 | <p>Set digital output.</p> <p>1.# - 0; 1 or ? (0 - OFF, 1 - ON, ? - Ignore) for DOUT1.</p> <p>2.# - 0; 1 or ? (0 - OFF, 1 - ON, ? - Ignore) for DOUT2.</p> <p>Y1 - timeout value for DOUT1 if needed (in seconds).</p> <p>Y2 - timeout value for DOUT2 if needed (in seconds).</p> <p>Z1 - maximum speed value for DOUT1 if needed.</p> <p>Z2 - maximum speed value for DOUT2 if needed.</p> | Yes |  | Common commands |
|  |  |     | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">EMC001</a><br><a href="#">FMM001</a><br><a href="#">FMB002</a><br><a href="#">FMB003</a><br><a href="#">FMB010</a><br><a href="#">FMB020</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB910</a><br><a href="#">FMB920</a><br><a href="#">FMB962</a><br><a href="#">FMB964</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB208</a><br><a href="#">FMB209</a><br><a href="#">FMC125</a><br><a href="#">FMM125</a><br><a href="#">FMU125</a><br><a href="#">FMU126</a><br><a href="#">FMC130</a><br><a href="#">FMM130</a><br><a href="#">FMU130</a><br><a href="#">MSP500</a><br><a href="#">FMT100</a><br><a href="#">EMP100</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a> |                 |
| <a href="#">battery</a>                  | Returns battery state info.  | Yes |  | Common commands |



|                   |  |     |  |                 |
|-------------------|--|-----|--|-----------------|
| <i>wdlog</i>      | Returns all information about 'watch dogs'   | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <i>defaultcfg</i> | Load default configuration.  | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   | Common commands |
| <i>setkey # #</i> | Add new or change current configuration keyword. If device is locked, keyword cannot be changed.<br>1.# - old keyword (if adding new keyword space).<br>2.# - new keyword. | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   | Common commands |

|                          |   |     |  |                 |
|--------------------------|---|-----|--|-----------------|
| <a href="#">delkey</a> # | Remove existing keyword (If device is locked, keyword cannot be changed).<br># - old keyword.   | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">bbread</a> # | Return black box information (HEX value of event ID and HEX value of custom data field (optional)).<br># - returns entered number of latest events. When # is omitted the latest events are packed to single SMS. | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
| <a href="#">bbinfo</a> # | Return same information as bbread command but additional all events timestamp is written in HEX.<br># - returns entered number of latest events. When # is omitted the latest events are packed to single SMS.    | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |

|                 |                 |     |  |                 |
|-----------------|-----------------|-----|--|-----------------|
| <i>sdformat</i> | Format SD card. | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Common commands |
|-----------------|-----------------|-----|--|-----------------|

## Bluetooth® Commands

| Command                     | Description   | Response | HW Support   | Parameter Group     |
|-----------------------------|---|----------|--|---------------------|
| <a href="#">btgetlist</a> # | Returns requested Bluetooth® list.<br># - 0,1 or 2 (0 - Discovered, 1 - Paired, 2 - Connected, 3 - Discovered BT4/BLE devices). | Yes      | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Bluetooth® commands |
| <i>btscan</i>               | Starts Bluetooth® scan.   | Yes      | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>  | Bluetooth® commands |

|                    |  |     |   |                     |
|--------------------|--|-----|---|---------------------|
| <i>btvisible #</i> | Sets Bluetooth® to visible with TMO.<br># - visibility TMO (from 1 to 255 seconds).  | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Bluetooth® commands |
| <i>btrelease #</i> | Disconnects from current device and pauses auto connect functionality for TMO.<br># - none or TMO (from 1 to 255 seconds).   | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Bluetooth® commands |
| <i>btunpair #</i>  | Unpair Bluetooth® device.<br># - all, BT address (all - unpair all devices, BT address - unpair only specified MAC address). | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Bluetooth® commands |

## Commands Related to Features

---

| Command | Description | Response | HW Support | Parameter Group |
|---------|-------------|----------|------------|-----------------|
|---------|-------------|----------|------------|-----------------|

|                                    |  |     |   |                              |
|------------------------------------|--|-----|---|------------------------------|
| <a href="#">fc_reset</a>           | Resets fuel consumption parameters.                        | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Commands related to features |
| <a href="#">towingreact</a>        | Towing reactivation.                                       | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Commands related to features |
| <a href="#">auto_calibrate:get</a> | Returns the state of calibration.                          | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Commands related to features |
| <a href="#">odomet:#</a>           | Set total odometer value.<br># - new odometer value in km. | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Commands related to features |

|                                     |  |     |   |                              |
|-------------------------------------|--|-----|---|------------------------------|
| <a href="#">odoget</a>              | Display current odometer value.  | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Commands related to features |
| <a href="#">on_demand_trackingX</a> | <p>X=0 - Stops Tracking on Demand functionality.<br/> X=1 - Starts Tracking on Demand functionality.<br/> X=2 - Generates one high priority record and initiates data sending to server.</p> <p><b>Note: This command is supported from 03.25.06 firmware version.</b></p> | Yes | <a href="#">FMBXXX FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | Commands related to features |

## OBD Commands

| Command                 | Description   | Response | HW Support   | Parameter Group |
|-------------------------|---|----------|--|-----------------|
| <a href="#">obdinfo</a> | Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth® OBD dongle. Response displays all available information from OBD. | Yes      | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | OBD Commands    |

|                            |  |     |  |              |
|----------------------------|--|-----|--|--------------|
| <a href="#">faultcodes</a> | Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth® OBD dongle. Response displays all visible fault codes.     | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a> | OBD Commands |
| <i>cleardtc</i>            | Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth® OBD dongle. Command clears all vehicle stored fault codes. | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a><br><a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   | OBD Commands |
| <i>getvin</i>              | Command works on OBD trackers with data reading capabilities (FMX00Y). On other trackers it works only if connected with Bluetooth® OBD dongle. Response displays vehicle VIN code.            | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB001</a><br><a href="#">FMC001</a><br><a href="#">FMB010</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMB130</a><br><a href="#">FMB140</a><br><a href="#">FMB150</a><br><a href="#">FMC150</a><br><a href="#">FMM150</a><br><a href="#">FMB900</a><br><a href="#">FMB920</a><br><a href="#">FMB202</a><br><a href="#">FMB204</a><br><a href="#">FMB206</a><br><a href="#">FMT100</a><br><a href="#">FMP100</a><br><a href="#">FMC001</a><br><a href="#">FMC125</a><br><a href="#">FMC130</a><br><a href="#">FMM001</a><br><a href="#">FMM125</a><br><a href="#">FMM130</a><br><a href="#">FMC800</a><br><a href="#">FMM800</a><br><a href="#">FMM80A</a><br><a href="#">FMC880</a><br><a href="#">FMM880</a><br><a href="#">FMC250</a>   | OBD Commands |

## CAN Adapter Commands

---

| Command | Description | Response | HW Support | Parameter Group |
|---------|-------------|----------|------------|-----------------|
|---------|-------------|----------|------------|-----------------|

|                              |  |     |  |                      |
|------------------------------|--|-----|--|----------------------|
| <a href="#">lvcangetinfo</a> | <p>UniqID: 0031C22F41400014000535305039594D53, FWVer: 00010000, BLVer: 00000300, GIT-SHA1: 2490222, Rev: 0, FW date: 2022-05-16, Kernel: 473, Option: 01</p> <p><b>Explanation of values:</b> UniqID - contains the unique ID of the CAN MCU, generated from internal registers</p> <p>FWVer - CAN MCU firmware version. Example: 00010000here 00 - BRANCH version, 01 - MAJOR version, 00 - MINOR version, 00 - PATCH version</p> | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMU125</a><br><a href="#">FMC125</a><br><a href="#">FMM125</a><br><a href="#">FMB130</a><br><a href="#">FMU130</a><br><a href="#">FMC130</a><br><a href="#">FMM130</a> | CAN Adapter Commands |
| <a href="#">lvcanreset #</a> | <p>This command forces CAN adapter reset. Note: This command is supported from 03.25.16.Rev.281 firmware version.</p>  | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB110</a><br><a href="#">FMB120</a><br><a href="#">FMB122</a><br><a href="#">FMB125</a><br><a href="#">FMU125</a><br><a href="#">FMC125</a><br><a href="#">FMM125</a><br><a href="#">FMB130</a><br><a href="#">FMU130</a><br><a href="#">FMC130</a><br><a href="#">FMM130</a> | CAN Adapter Commands |
| <a href="#">oeminfo</a>      | <p><b>Vehicle:</b> Mazda/6 FL2/2019, GenTime: 1970-1-1 0:0:0, LS:0, DB:0, DBG:0, LE:41, FVer:1</p> <p><b>Explanation of values:</b> Vehicle - contains the vehicle, the OEM CAN file is intended forGenTime - contains the CAN OEM file generation date/time</p>   | Yes | <a href="#">FMBXXX</a><br><a href="#">FMB150</a>   | CAN Adapter Commands |
| <a href="#">lvcancheck</a>   | <p>This command reports CAN lines connection information.</p>  | Yes | <a href="#">FMM150</a>   | CAN Adapter Commands |