

# FMM650 Dual SIM

[Main Page](#) > [Professional Trackers](#) > [FMM650](#) > [FMM650 Manual](#) > **FMM650 Dual SIM**

## Introduction to Dual SIM Functionality

FMM650 is able to operate in DUAL SIM switching mode to minimize the bill accounts for GSM/GPRS services.

SIM1 card has higher priority than SIM2. For one SIM card using it must be placed in SIM1 slot for FMM650 to switch minimum times. (SIM1 SLOT is closer to PCB, SIM2 SLOT is the upper one). If SIM card is inserted into SIM 2 slot and 1 SIM operator list mode is used, FMM650 will work normally, but there will be more switching activities. In addition, APN settings in GPRS should be entered for SIM 1 and SIM 2 to avoid not sending records over GPRS.

SIM 1 and SIM 2 APN settings are set in the GPRS tab (Figure). Information about APN and authentication type should be provided by your GSM operator.



- **Dual SIM algorithm**

Two SIM cards use algorithm is shown in the diagram below :



- **Home Network**

FMM650 gets possible operator codes list from the network and compares them with the operator codes inserted in Home profile's list. At first, it tries to connect to SIM 1 Home Operator, if operator is unreachable; the device switches to SIM 2 slot and tries to connect to SIM 2 Home Operator. When the connection procedure is successful, FMM650 stays connected to the available Home operator using the SIM card, which was inserted for and works according to the Home profile parameter settings. If none of the Home operators could be connected with, FMM650 switches to the SIM 1 card tries to connect to its roaming operators from SIM 1 Roaming profile.