

Getting Started With TachoSync

[TachoSync](#) > **Getting Started With TachoSync**



Contents

- [1 Fleet management Device requirements](#)
- [2 Device configuration](#)
- [3 Network requirements](#)
- [4 How to access TachoSync](#)

Here you will find all needed information related to requirements of the devices and their configuration. Additionally, you will familiarize with network requirements and will find a login link, so you could easily start using TachoSync platform.

Fleet management Device requirements

Supported models FMB640, FMC640, FMM640, FMB641, FMC650, FMM650.

Minimal Firmware version 01.02.11 or later, works with every firmware

Device configuration

In order for a device to connect to TachoSync the domain and port must be configured in configurator:



Network requirements

If your SIM cards are within Mobile Operator's VPN (private APN), the following must be ensured and paid special attention.

1. Must ensure that domain <https://tacho.teltonika.lt/> can be resolved from within Operator's network.
2. Following domain and port must be allowed by the operator:

- Domain: tacho.teltonika.lt
- Port: 29000

When using VPN SIM cards, you should still configure <https://tacho.teltonika.lt/> domain in your configurator, not the plain IP address.

How to access TachoSync

Link to login: <https://tacho.teltonika.lt/dashboard>