

[https://wiki.teltonika-gps.com/view/Iridium\\_Edge\\_Data\\_Sending\\_Parameters\\_ID](https://wiki.teltonika-gps.com/view/Iridium_Edge_Data_Sending_Parameters_ID)

# Iridium Edge Data Sending Parameters ID

[Test Iridium page](#) > **Iridium Edge Data Sending Parameters ID**

Parameter ID	Parameter name	Min values	Max values	Default values	Description
99420	Iridium Edge	0	1	0	This parameter enables or disables Iridium Edge functionality
99421	Save/Send period	0	1440	1440	This parameter lets to configure Iridium Edge sending period
99422	SBD IO source	0	6	0	SBD IO elements which when enabled are included into the SBD record
151	RS232 Mode	0	26	0	Implement ability to select "Satellite backup"
99423	SBD Upload Limit	0	30000	8000	Limit to save user from exceeding the monthly plan. Max limit of 30000 due to 30KB plan. If set to 0 - limit will be off.