

# TachoSync Getting started

[TachoSync](#) > TachoSync Getting started



## Contents

- [1 Fleet management Device requirements](#)
- [2 Device configuration](#)
- [3 Network requirements](#)
- [4 How to access TachoSync](#)

Here you will find all needed information related to requirements of the devices and their configuration. Additionally, you will familiarize with network requirements and will find a login link, so you could easily start using TachoSync platform.

## Fleet management Device requirements

**Supported models** FMB640, FMC640, FMM640, FMB641, FMC650, FMM650.

**Minimal Firmware version** 01.02.11 or later, works with every firmware

## Device configuration

In order for a device to connect to TachoSync the domain and port must be configured in configurator:



## Network requirements

If your SIM cards are within Mobile Operator's VPN (private APN), the following must be ensured and paid special attention.

1. Must ensure that domain <https://tacho.teltonika.lt/> can be resolved from within Operator's network.
2. Following domain and port must be allowed by the operator:

- Domain: tacho.teltonika.lt
- Port: 29000

When using VPN SIM cards, you should still configure <https://tacho.teltonika.lt/> domain in your configurator, not the plain IP address.

## How to access TachoSync

Link to login: <https://tacho.teltonika.lt/dashboard>