

https://wiki.teltonika-gps.com/view/Talk:FM36_getstatus

Talk:FM36 getstatus

hi, this is ok, but there are values in brackets in the response sms message. What is this? what does this mean? e.g. data link:1(0), data link 1(1) also data link:1(b2)