

Talk:FMA120

Hello, can you please provide any solution that will be able to inform when the car doors are opened or any alarm system is triggered via SMS from Teltonika, with the rule that it will send only SMS when another person using a vehicle.

Example. I set the parameter to send sms when Ignition is ON. So anytime ignition is ON i'm getting SMS notification. I would like that it will send sms only when ignition is turned on by any other person but not me.

Car alarm is triggered SMS is sent via teltonika.

Otherwise I'm getting SMS notifications all the time (daily stops, any engine off - on by me) I would like to avoid these messages. So want to use teltonika as SMS notification unit to alert me when car is triggered by any other person.