Talk:FMB001

out param

Hello, Can someone give me the meaning of each out parameter given by the FMB001 . exparam 13=43 . What is param 13? Thank you

<u>Tia</u> (<u>talk</u>) 21:21, 12 August 2018 (EEST)

FMB001. FMB0YY-6-1PWR

Hi Dose anyone know if you have to have a SIM in the GPS to enable it to conect to the Config softwhere? Ive downloded and installed the windows drivers but the cofig softwhere cant find the GPS unit.